SERVICE MANUAL

SERVICE MANUAL SECTION

CF 500, CF 600 Models Starting September 1, 2007 — ELECTRICAL CIRCUIT DIAGRAMS

Model: CF 500

Start Date: 09/01/2007

Model: CF 600

Start Date: 09/01/2007

S08332


03/18/2008

Table of Contents

1. TABLE OF CONTENTS (CHAPTER 1)	••••
2. INSTRUCTIONS AND CHARTS (CHAPTER 2)	'
2.1. ABBREVIATIONS, P. 1	
2.2. ACRONYMS, P. 2	
2.3. CIRCUIT DIAGRAM INSTRUCTIONS, P. 3.	
2.4. CIRCUIT NUMBER IDENTIFICATION AND COLOR, P. 4	
2.5. CIRCUIT NUMBER IDENTIFICATION AND COLOR, P. 5	
2.6. CIRCUIT NUMBER IDENTIFICATION AND COLOR, P. 6	
2.7. LAMP BULB CHART, P. 7	
2.8. RELAY FUNCTION AND WIRING GUIDE, P. 8	
2.9. SCHEMATIC SYMBOL CHART, P. 9	
2.10. SCHEMATIC SYMBOL CHART, P. 10	
2.11. SCHEMATIC SYMBOL CHART, P. 11	
2.12. SCHEMATIC SYMBOL CHART, P. 12	1
3. 12 VOLT DISTRIBUTION, GROUNDS, AND DATA LINKS (CHAPTER 3)	4
3.1. BATTERY FEEDS, POWER DISTRIBUTION BOX, P. 1	۰۰۰۱۰ ۱
3.2. BATTERY FEEDS, POWER DISTRIBUTION BOX, P. 2	
3.3. BATTERY FEEDS, POWER DISTRIBUTION BOX, P. 3	
3.4. KEY SWITCH, P. 4	10
3.5. IGNITION FEEDS (RUN), P. 5	
3.6. IGNITION FEEDS (START), P. 6	
3.7. IGNITION FEEDS (RUN-START), P. 7.	
3.8. IGNITION FEEDS (RUN-ACCESSORY), P. 8	
3.9. GROUNDS (MAIN CHASSIS), P. 9	
3.10. GROUNDS (MAIN CHASSIS), P. 10	
3.11. GROUNDS (REAR CHASSIS), P. 11	
3.12. GROUNDS (IP), P. 12	2
3.13. GROUNDS (IP), P. 13	2
3.14. CAB GROUNDS (ROOF, FLOOR), P. 14	2
3.15. J1708 DATA LINK, P. 15	
3.16. J1939 DATA LINK, P. 16	
3.17. J2284 DATA LINK, P. 17	
3.18. DIAGNOSTIC CONNECTORS, P. 18.	
4. CAB ACCESSORIES (CHAPTER 4)	
4.1. CIGAR LIGHTER, P. 1	
4.2. POWER WINDOWS, P. 2	3
4.3. POWER DOORS, P. 3	3
4.4. HORN AND COMBINATION SWITCH B, P. 4	34
4.5. RADIO, P. 5	
4.6. WINDSHIELD WIPER AND WASHER PUMP, P. 6	3
4.7. DOOR AJAR SWITCH AND DOME LIGHT, P. 7.	
5. CHARGING AND CRANKING SYSTEM (CHAPTER 5)	3
5.1. CHARGING AND CRANKING — INTERNATIONAL V6 ENGINE, P. 1	

6.	ENGINE ACCESSORIES (CHAPTER 6)	39
	6.1. HFCM MODULE — INTERNATIONAL V6 ENGINE, P. 1	39
	6.2. FUEL TANKS — DUAL TANK, P. 2	
	6.3. FUEL TANKS — LEFT AND AUXILIARY TANK, P. 3	41
7.	ELECTRONIC ENGINES (CHAPTER 7)	
	7.1. INTERNATIONAL V6 POWER AND GROUND SYSTEM, P. 1	
	7.2. INTERNATIONAL V6 CRUISE CONTROL, P. 2	
	7.3. INTERNATIONAL V6 ACCELERATOR PEDAL, P. 3	
	7.4. INTERNATIONAL V6 ENGINE SENSOR, P. 4	45
	7.5. INTERNATIONAL V6 GLOW PLUG AND ENGINE FAN, P. 5	
	7.6. INTERNATIONAL V6 AFTERTREATMENT, P. 6	
	7.7. INTERNATIONAL V6 INJECTORS, P. 7	
	7.8. INTERNATIONAL V6 INJECTORS, P. 8	49
8.	CLUSTERS AND WARNING LIGHTS (CHAPTER 8)	
	8.1. CLUSTER CONNECTOR A, P. 1	
	8.2. CLUSTER CONNECTOR A, P. 2	
	8.3. CLUSTER CONNECTOR B, P. 3	
	8.4. CLUSTER CONNECTOR B, P. 4	
	8.5. MULTIPLEX SWITCH MODULE AND AFTERTREATMENT SYSTEM, P. 5	54
9.	LIGHT SYSTEMS (CHAPTER 9)	
	9.1. COMBINATION SWITCH A, HAZARD SWITCH, P. 1	
	9.2. MARKER, FRONT PARK AND TURN LIGHTS, P. 2	
	9.3. REAR TAIL, TURN, STOP AND BACKUP LIGHTS, P. 3	
	9.4. REAR TAIL, TURN, STOP AND BACKUP LIGHTS, P. 3A	
	9.6. HEADLIGHTS, P. 5	
	9.7. PANEL LIGHTS, P. 6.	
10). CHASSIS ACCESSORIES (CHAPTER 10)	
	10.1. ANTILOCK BRAKE SYSTEM (ABS), P. 1	
	10.2. BODY BUILDER CUSTOMER ACCESS CIRCUITS (BOC), P. 2	
	10.3. BODY BUILDER LIGHTING CIRCUITS (BOC), P. 3	
	10.4. BODY BUILDER (EOF), P. 4	65
	10.5. BRAKE SYSTEMS: FLUID, PRESSURE AND PEDAL SWITCH, P. 5	00
	10.0. BRAKE STSTEMS. ELECTRIC TRAILER BRAKES, F. 0	01
11	. TRANSMISSION (CHAPTER 11)	
	11.1. TRANSMISSION CONTROL MODULE, P. 1	
	11.2. TRANSMISSION CONTROL MODULE, P. 1A	69
	11.3. TCM TO TRANSMISSION BULKHEAD CONNECTOR, P. 2	70
12	2. CLIMATE CONTROL (CHAPTER 12)	
	12.1. HVAC SYSTEM, P. 1	
	12.2. A/C CLUTCH, P. 2	
	12.3. PUSHER FAN, P. 3	73
13	B. CONNECTOR COMPOSITES (CHAPTER 13)	74
	13.1. CONNECTOR COMPOSITES (1), (2), (3), P. 1	74
	13.2. CONNECTOR COMPOSITES (71), (72), (101), (102), P. 2	
	13.3. CONNECTOR COMPOSITES (103), (104), (105), (106), P. 3	76

13.4. CONNECTOR COMPOSITES (201), (202A), (202C), P. 4	77
13.5. CONNECTOR COMPOSITES (203), (204), (205A), P. 5	78
13.6. CONNECTOR COMPOSITES (205B), (206), (207), (208), P. 6	79
13.7. CONNECTOR COMPOSITES (211), (212), (213), P. 7	80
13.8. CONNECTOR COMPOSITES (214), (215), (217A), (217B), P. 8	81
13.9. CONNECTOR COMPOSITES (220), (222), (223), (225), P. 9	
13.10. CONNECTOR COMPOSITES (226), (227), (228), (229), P. 10	
13.11. CONNECTOR COMPOSITES (233), (234), (235), P. 11	
13.12. CONNECTOR COMPOSITES (236A), P. 12	
13.13. CONNECTOR COMPOSITES (236B), (237), (238), P. 13	
13.14. CONNECTOR COMPOSITES (239), (240), (241), (243), P. 14	
13.15. CONNECTOR COMPOSITES (244), (245), (246), (247), (248), P. 15	
13.16. CONNECTOR COMPOSITES (249), (250), (251), P. 16	
13.17. CONNECTOR COMPOSITES (252), (253), (254), P. 17	
13.18. CONNECTOR COMPOSITES (301), (301A), (301B), (301D), (303), P. 18	
13.19. CONNECTOR COMPOSITES (304), P. 19	
13.20. CONNECTOR COMPOSITES (306), P. 20	
13.21. CONNECTOR COMPOSITES (308), (309), (310), (313), P. 21	
13.22. CONNECTOR COMPOSITES (315), P. 22	95
13.23. CONNECTOR COMPOSITES (316), (317), (318), (320), P. 23	
13.24. CONNECTOR COMPOSITES (321), (322), (323), (401), P. 24	
13.25. CONNECTOR COMPOSITES (402), (403), (404), (410), P. 25	
13.26. CONNECTOR COMPOSITES (411), (412), (413), P. 26	
13.27. CONNECTOR COMPOSITES (500), (503), P. 27	
13.28. CONNECTOR COMPOSITES (506), (507), (508), P. 28	
13.29. CONNECTOR COMPOSITES (509), (510), (602), P. 29	
13.30. CONNECTOR COMPOSITES (700), P. 30	
13.31. CONNECTOR COMPOSITES (701), P. 31	
13.32. CONNECTOR COMPOSITES (702A), P. 32	
13.33. CONNECTOR COMPOSITES (702B), P. 33	
13.34. CONNECTOR COMPOSITES (702D), P. 34	
13.35. CONNECTOR COMPOSITES (703), (704), P. 35	
13.36. CONNECTOR COMPOSITES (705), P. 36	
13.37. CONNECTOR COMPOSITES (706), P. 37	
13.38. CONNECTOR COMPOSITES (720), (720A), P. 38	
13.39. CONNECTOR COMPOSITES (720), (720A), P. 39	
13.40. CONNECTOR COMPOSITES (720), (720A), (829M), P. 40	113



1. TABLE OF CONTENTS (CHAPTER 1)

2. INSTRUCTIONS AND CHARTS (CHAPTER 2)

2.1. ABBREVIATIONS, P. 1

ABBREVIATION ACCESS ACCUM AC AIR CLNR ALT ACCEL AC AFTR AMM AMP AMP HR AMPL ARM ARM ARM ARM ARSR	DESCRIPTION ACCESSORY ACCUMULATOR AIR CONDITIONING AIR CLEANER ALTERNATOR ACCELERATOR ALTERNATING CURRENT AFTERTREATMENT AMMETER AMPERE AMPERE AMPLIFIER	ABBREVIAT CRUS CUR DPNL DFTR DEG DIAG DIAG DIL DIFF DIMR	FION	DESCRIPTION CRUISE CURRENT DASHPANEL DEFLECTOR DEFROSTER DEGREE	ABBREVIATION PWR PRESS RAD RLY	DESCRIPTION POWER PRESSURE RADIO RELAY
ACCESS ACCUM AC AIR CLNR ALT ACCEL AC AFTR AMM AMP AMP HR AMPL ARM	ACCESSORY ACCUMULATOR AIR CONDITIONING AIR CLEANER ALTERNATOR ACCELERATOR ALTERNATING CURRENT AFTERTREATMENT AMMETER AMPERE AMPERE AMPERE HOUR	CRUS CUR DPNL DFTR DFR DEG DIAG DSL DIFF	TION	CRUISE CURRENT DASHPANEL DEFLECTOR DEFROSTER	PWR PRESS RAD RLY	POWER PRESSURE RADIO
ACCUM AC AIR CLNR ALT ACCEL AC AFTR AMM AMP AMP HR AMPL ARM	ACCUMULATOR AIR CONDITIONING AIR CLEANER ALTERNATOR ACCELERATOR ALTERNATING CURRENT AFTERTREATMENT AMMETER AMPERE AMPERE AMPERE HOUR	CUR DPNL DFTR DFR DEG DIAG DSL DIFF		CURRENT DASHPANEL DEFLECTOR DEFROSTER	PRESS RAD RLY	PRESSURE RADIO
AC AIR CLNR ALT ACCEL AC AFTR AMM AMP AMP HR AMPL ARM	AIR CONDITIONING AIR CLEANER ALTERNATOR ACCELERATOR ALTERNATING CURRENT AFTERTREATMENT AMMETER AMPERE AMPERE AMPERE HOUR	DPNL DFTR DFR DEG DIAG DSL DIFF		DASHPANEL DEFLECTOR DEFROSTER	RAD RLY	RADIO
AIR CLNR ALT ACCEL AC AFTR AMM AMP AMP HR AMPL ARM	AIR CLEANER ALTERNATOR ACCELERATOR ALTERNATING CURRENT AFTERTREATMENT AMMETER AMPERE AMPERE AMPERE HOUR	DFTR DFR DEG DIAG DSL DIFF		DEFLECTOR DEFROSTER	RLY	
ALT ACCEL AC AFTR AMM AMP AMP HR AMPL ARM	ALTERNATOR ACCELERATOR ALTERNATING CURRENT AFTERTREATMENT AMMETER AMPERE AMPERE AMPERE	DFR DEG DIAG DSL DIFF		DEFROSTER		RELAY
ACCEL AC AFTR AMM AMP AMP HR AMPL ARM	ACCELERATOR ALTERNATING CURRENT AFTERTREATMENT AMMETER AMPERE AMPERE HOUR	DEG DIAG DSL DIFF				
AC AFTR AMM AMP AMP HR AMPL ARM	ALTERNATING CURRENT AFTERTREATMENT AMMETER AMPERE AMPERE HOUR	DIAG DSL DIFF		DEGREE	RES REGEN	RESISTOR REGENERATE
AFTR AMM AMP AMP HR AMPL ARM	AFTERTREATMENT AMMETER AMPERE AMPERE HOUR	DSL DIFF		DIAGRAM	R	RIGHT
AMP AMP HR AMPL ARM	AMMETER AMPERE AMPERE HOUR			DIESEL	RTR	ROTOR
AMP HR AMPL ARM	AMPERE HOUR	DIMP		DIFFERENTIAL	SNSR	SENSOR
AMPL ARM		DIIVIR		DIMMER	SHLD	SHIELD
ARM	AMPLIFIER	ELEC		ELECTRICAL	SHFT	SHIFTER
		ELEX		ELECTRONIC	SLPR	SLEEPER
AKSR	ARMATURE	ENG		ENGINE	SLV	SLEEVE
ACCV	ARRESTER	EXH		EXHAUST	SPKR	SPEAKER
ASSY AUX	ASSEMBLY AUXILIARY	FL FWD		FLUID FORWARD	SPR STD	SPRING STANDARD
B/U	BACK-UP	FR		FRONT	STRG	STEERING
BTRY	BATTERY	FREQ		FREQUENCY	STLITE	SATELLITE
ВМ	BENCHMARKING	GA		GAUGE	SUNSH	SUNSHADE
BLK	BLOCK	GEN		GENERATOR	SW	SWITCH
BOOS	BOOSTER	GND		GROUND	SYS	SYSTEM
ВОТ	воттом	HARN		HARNESS	TACH	TACHOMETER
BK	BRAKE	HDLP		HEADLAMP	TEMP	TEMPERATURE
BRKR	BREAKER	HTD		HEATED	TERM	TERMINAL
BRTHR BRI	BREATHER BRIGHT	HT TR		HEAT TREAT	THROT	THROTTLE
BUZ	BUZZER	HTR HP		HEATER HORSEPOWER	TRAC	THROUGH TRACTION
CA	CABLE	HYD		HYDRAULIC	TRLR	TRAILER
CD	CANDELA	ID		IDENTIFICATION	XDCR	TRANSDUCER
CP	CANDLEPOWER	IGN		IGNITION	XFER	TRANSFER
CAP	CAPACITOR	ILLUM		ILLUMINATION	XFMR	TRANSFORMER
CAT	CATERPILLAR	IND		INDICATOR	XSTR	TRANSISTOR
CHAS	CHASSIS	INST		INSTRUMENT	XMSN	TRANSMISSION
CH	CHOKE	INT		INTERMITTENT	XMTR	TRANSMITTER
CIRC CLK	CIRCUIT	LT		LEFT	TRK UPR	TRUCK UPPER
CW	CLOCKWISE	LTR		LIGHTER	VLV	VALVE
CLSTR	CLUSTER	LWR		LOWER	VERT	VERTICAL
CL	CLUTCH	MAG		MAGNET	VM	VOLTMETER
COL	COLUMN	MOD		MODULATOR	VOL	VOLUME
СОММ	COMMUTATOR	MDL		MODULE	WSHR	WASHER
CMPNT	COMPONENT	MOT		MOTOR	WHL	WHEEL
CPRSR	COMPRESSOR	MTD		MOUNTED	WDO	WINDOW
CONN CONT	CONNECTOR	NEG N/		NEGATIVE NOT WITH	WSHLD WPR	WINDSHIELD WIPER
CONT	CONTINUED	NO.		NUMBER	WPR W/	WITH
CONT	CONTACT	PASS		PASSENGER	W/O	WITHOUT
CONT	CONTROL	POSN		POSITION		
CONV	CONVERTER	POS		POSITIVE		
CLR	COOLER	POT		POTENTIOMETER		
CTSY	COURTESY					
DATE	CHANGE F	EV REFERENCE	DRAWN	NAME		

Figure 1 Abbreviations

2.2. ACRONYMS, P. 2

RINT IS PROVIDED ON A RESTRICTED BASIS AND TO BE USED IN ANY WAY DETRIMENTAL TO THE OF INTERNATIONAL TRUCK AND ENGINE CORPORATION.			ACRONY	MS		
DESCRIPTION		ACRONYN		DESC	CRIPTION	ACRONYM
ANTILOCK BRAKING SYSTEM		ABS		VY DUTY DIESE		HDD
ANTENNA COMMUNICATION UNIT		ACU		PERFORMANC		HPT
ALTERNATING CURRENT		AC	HIGH	SIDE DRIVER		HSD
AXLE TO BACK OF CAB		AC	HEA'	TING, VENTILAT	ION, AND	HVAC
AXLE TO FRAME		AF	_	CONDITIONING		
ACCELERATOR PEDAL MODULE		APM		CTOR DRIVE MO	DDULE	IDM
ACCELERATOR POSITION SENSOR		APS		IT/OUTPUT		1/0
AUXILIARY POWER UNIT		APU		GRATED MOBIL		IMCT
AMERICAN TRUCKING ASSOCIATION		ATA		MUNICATION TO RUMENT PANE		I/P
AUTOMATIC TRACTION CONTROL		ATC		PENDENT POW		IPTO
AUDIO VIDEO INTERFACE		AVI		IT SPEED SENS		ISS
BAROMETRIC ATMOSPHERE PRESSURE		BAP			TRANSMISSION	LCT
BRAKE HORSEPOWER		BHP		PRESSURE MC		LPM
BACK OF CAB		BOC		SIDE DRIVE		LSD
CITIZEN BAND		CB		IUM DUTY		MD
COLD CRANKING AMPERES		CCA	MOM	IENTARY ENGIN	IE IGNITION	
CLEAN POWER ELECTRICAL CONNECTOR		CEC	INTE	RRUPT RELAY		MEIIR
CENTRAL PROCESSING UNIT		CPU	MAL	FUNCTION INDIC	CATION LAMP	MIL
CAB OVER ENGINE		DC	MUL	TIPLEX SWITCH	MODULE	MSM
DIRECT CURRENT				PUT SPEED SEN		oss
DRIVER CONTROL MODULE		DCM		OMETER AMME		PAM
DIGITAL DATA LINK DIESEL OXIDATION CATALYST INLET		DDL		ER DISTRIBUTION		PDC
TEMPERATURE		DOCT	1		OGIC CONTROLLER	PLC
DIESEL PARTICULATE FILTER		DPF	1 -	ER TAKE-OFF		PTO
DIESEL PARTICULATE FILTER		DDEDD		SE WIDTH MODU	ILATION	PWM
DELTA PRESSURE		DPFDP		RAXLE		RA
DIESEL PARTICULATE		DPFT	1 -	O FREQUENCY		RF RSP
FILTER TEMPERATURE DIESEL TURBOCHARGED		DT		L STABILITY PRO ERE SERVICE	JGRAM	SS
DAY TIME RUNNING LIGHTS		DTRL			NTROL MODULE	TCM
ELECTRONIC CONTROL MODULE		ECM			MUNICATION UNIT	TCU
ELECTRONIC CONTROL UNIT		ECU		RESTRIAL MOBIL		
EXHAUST GAS RECIRCULATION		EGR		MUNICATION T		TMCT
EXHAUST GAS TEMPERATURE		EGT	THE	RMAL OVERCRA	NK PROTECTION	TOCP
ELECTRO MAGNETIC INTEFERENCE		EMI	THR	OTTLE POSITIO	N SENSOR	TPS
END OF FRAME		EOF	TUR	BINE SPEED SE	NSOR	TSS
ELECTRIC TRAILER BRAKE		ETB	VEH	CLE SPEED OU	TPUT	vso
FRONT AXLE		FA		CLE SPEED SE		vss
FRONT END		FE		LD TRANSMISSI		WTEC
FRONT OF DASH		FOD		CTRONIC CONTI		71/10
FULL POWER BRAKE		FPB	LZER	O VOLT REFERE	INCE	ZVR
GLOBAL POSITIONING SYSTEM		GPS	_			
HYDRAULIC CONTROL UNIT		HCU	_			
HEAVY DUTY		НВ				
	REV	REFERENCE D	RAWN	NAME		
DATE CHANGE	ILL.	_	00JAHP	CIRCUIT DIAGRAN		

Figure 2 Acronyms

2.3. CIRCUIT DIAGRAM INSTRUCTIONS, P. 3




Figure 3 Circuit Diagram Instructions

2.4. CIRCUIT NUMBER IDENTIFICATION AND COLOR, P. 4

E USED IN ANY WAY DETR ITERNATIONAL TRUCK AND				CIRCUI	T NUMBER IDE	ENTIFICATION AND COLOR	
TERNATIONAL TROCK AND	DENGINE COR	OKATION.					
CIRCUIT							1
NUMBER	COLOR			DES	CRIPTION		4
1	LTBL		OR - FIELD				4
2	RD		OR - CHARGE				1
3	DKBL GY			IICATION J1587 IICATION J1587			1
	DKBL			IICATION J1922			1
4	GY			IICATION J1922]
5	YL	SERIAL / D	ATA COMMUN	IICATION J1939	/11 / J1939/15	(+)]
-	GN				/11 / J1939/15		4
6	GY				SS THAN 9 VOL	TS)	-
7	RD	ALTERNAT	OR - RESISTA	NCE			1
8	GY	LOWING	AGE ELECTR	ONIC GROUND			1
10	WH		ENGINE GRO				1
11	WH		EPER GROUNI				1
12	LTBL	ACCESSO]
	PK	IGNITION F				-	1
13	вк			UILDER CONNE	ECTOR)		4
14	RD	BATTERY I					4
15	RD	KEY SWIT	CH FEED				4
16	+						-
17	PK	STARTER					1
18	PK		IG / PREHEAT	ER			1
19 20	GY LTGN	ENGINE SH	OWER MODU	-			1
21	TN		RT CONTROLS				1
22	TN			ORING / CONTR	ROL		1
23	TN		N / SHUTTERS]
24	GY		KHAUST BRAK]
25	TN	PYROMET	ER				4
26	TN	AMMETER					4
27	TN	VOLTMETE					4
28 29	TN		NTS AND GAL				1
30	TN		ATER TEMPEI L TEMPERATI				1
31	TN		SION OIL TEM				1
32	TN		EMPERATURE]
33	TN	ENGINE O					1
34	TN	COOLANT	LEVEL				4
35	TN		L PRESSURE				4
36	TN	FUEL LEVE					1
37	TN	FUEL PUM					┪
38	GY	LIFT AXLE					1
39 40		AIR DRYE		PNING			1
40	TN	AIR TEMPE	RESSURE WA	DAIINIZ			1
42			LE ENGAGED				1
43				PDL) WARNING	;		1
44	GY	PARK BRA	KE WARNING]
45	LTGN	ANTITHEF	[WARNING]
<u></u>							
	HANGE	R	EV PEETDENOT	DRAWN	NAME		
G07 REVISED AND	HANGE		60785Z	U00JAHP	CIRCUIT DIAGRA	M, LCF	

Figure 4 Circuit Number Identification and Color

2.5. CIRCUIT NUMBER IDENTIFICATION AND COLOR, P. 5

	ATIONAL TRUCI OVIDED ON A RESTRICTED I ED IN ANY WAY DETRIMENT	BASIS AND				T NUMBER ID	ENTIFICATION AND COLOR	
TEREST OF INTER	NATIONAL TRUCK AND ENG	INE CORPOR	ATION.		(CONT)			
	CIRCUIT							7
	NUMBER	COLOR			DE	SCRIPTION		
	46	GY	POWER T	AKE-OFF WA	RNING			
	47	GY	SPEEDON					
	48	GY	ТАСНОМЕ					
	49	GY		NTIAL LOCK W	VARNING			
	50	YL		ITCH FEED				
	51	YL		SWITCH FEED)			
	52	YL		HT HI - BEAM				
	53	YL		HT LO - BEAM				
	54	BN		/ MARKER LIG				
	55	OR		NAL - FEED				
	- 55	OR		NAL LIGHTS	- LEFT			7
	56	YL				BUILDER CON	NECTION)	7
		OR		NAL LIGHTS		_ J.LDLIK GOIN		╗
	57	LTGN				BUILDER CO	NINECTION	
	58	BN	1		ICATION LIGH		NNECTION)	_
	59	GY			ICATION LIGH	15		_
			SOLENOI					_
	60	OR	HAZARD L					-
	61	GY	AIR SUSP					-
	62	DKBL	PANEL LIC					-
	63	DKBL		SY / DOME LIG				-
	64	YL	1	VING LIGHTS				-
	65	OR		R FLOOD LIGI				-
	66	YL		RUNNING LIC				-
	67	GY	1		E / REMOTE S	ENSOR		_
	68	BN	TAIL LIGH					_
	69	BN		PLATE LIGHT	·			_
	70	OR	STOP LIG					-
		RD			UILDER CONN	IECTION)		_
	71	OR	BACK-UP					_
		LTBL			DY BUILDER (_
	72	OR	TRAILER	AUXILIARY FE	ED - BATTER	Y		_
	73	LTGN	PWM					⊣
	74	LTGN		RECIRCULATI				⊢
	75	LTGN		BLOWER MOT	OR			⊢
	76	LTGN	AUXILIAR'	Y FAN				⊣
	77	LTGN	AIR CONE					⊣
	78	LTGN		- HEATED, M	IOTORIZED			⊣
	79	GY	SEAT BEL	.TS				⊣
	80	вк	SLEEPER	BOX RELAY	- FEED			⊣
	81	LTGN	POWER D	OOR LOCKS				⊣
	82	GY	WINDSHIE	ELD WIPER				_
	83	LTGN	POWER W	VINDOWS				_
	84	LTGN	CIGAR LIC	SHTER				_
	85	GY	HORN					
DATE	CHANGE		REV	REFERENCE	DRAWN	NAME		
A1 28AUG07		2B 4 14/4 1	В	60785Z	U00JAHP	CIRCUIT DIAGRA		
	REVISED AND RED	JKAVVIN	IB	100705Z			PART NO.	
AT 28AUGU7					RELEASE NO.	DATE	PART NO.	SHEET

Figure 5 Circuit Number Identification and Color

2.6. CIRCUIT NUMBER IDENTIFICATION AND COLOR, P. 6

от то	BE USED I	N ANY WA	RESTRICTED BASI Y DETRIMENTAL T	O THE			CIRCUIT (CONT)	T NUMBER IDE	NTIFICATION AND COLOR			
STOFI	NTERNAT	ONAL TRU	ICK AND ENGINE	CORPORATION			(00.11)					
		_										
			IRCUIT NUMBER	COLO	R			DESCRIPTION				
			86 86	LTGN	J	RADIO - F	NTERTAINMEN	NT / CLOCK				
			87	GY			LD WASHER					
			88	LTGN	1	CLOCK / F	OURMETER					
		\vdash	89	VT		AIR BAG						
		-	90	GY			IC BRAKE PUN	1P				
		\vdash	91	VT			MUNICATION					
		\vdash	92 93	TN TN			SSION CONTROL	OLS - ELECTRO	INICS			
			93	GY			BRAKE SYSTE	-м				
			95	TN			EMISSION					
			96	YL				RUISE CONTRO	DLS			
			97	VT		1	ONTROLS - EL					
		\vdash	98	BK			AND DIAGNO					
		\vdash	99	VT				N SENSOR (AF				
		\vdash	100	GY				DLENOID ACTU	ATED)			
		\vdash	101 102	TN YL		FLASH TO	PPLICATION AI	R				
			103		J		LDER AUXILIA	RY FEED				
		103 LTGN 104 DKBL				START / STOP						
		105 LTG		LTGN	1	HEATED S	HEATED SEATS					
		\vdash	106	OR		HIGH VOL	TAGE ALTERN	ATOR AC CHAP	RGE			
		\vdash	106 OR 107 GY			INSTRUMENT CLUSTER ELECTRONIC FEED (5V)						
		\vdash	108	GY			D WEAR SENS					
			109 110	GY GY			ROKE / SLAC	ELECTRONIC (SPOLIND			
			111	TN				ION TRANSDUC				
			112	GY		LIFT GATE						
	PR	FIX					LOCAT	ON				
		Α	CAB - INSTI	RUMENT PA	ANEL	MODULE						
		В	CAB - DRIV	ER CONTRO	OL MC	DULE						
		С	CAB - HEAD	DER / CLEA	RANC	E LIGHTS						
	-	D	CAB - ROOI									
		E F	CAB - LEFT CAB - RIGH									
		Н	CAB - SLEE		OOKS	,						
		J	CAB - DASH)							
		K	ENGINE / R									
	_	L	TRANSMISS	SION								
	_	M					L FORWARD)					
	-	N					PANEL TO CA	B REAR CROSS	S MEMBER)			
		P R	CHASSIS / \			EAR AXLE / A	VIEC					
		S				OP / TAIL / TU						
		T	TRAVEL DO									
		U	HOOD MTD	HEADLIGH	TS / M	ARKER LIGH	TS					
		V	SLEEPER R	OOF / BAC	K PAN	IEL WIRING						
		W	WARDROB	CABINET	WIRIN	IG						
							T					
T												
DATE			CHANGE D AND REDRA		REV A	REFERENCE 60785Z	U00JAHP	CIRCUIT DIAGRAM	M, LCF			

Figure 6 Circuit Number Identification and Color

2.7. LAMP BULB CHART, P. 7

		IONAL TRUCK AND ENG			_	
IS N	OT TO BE USED I	DED ON A RESTRICTED BASIS AND N ANY WAY DETRIMENTAL TO THE		LAMP BULB CHART		
ERE	ST OF INTERNAT	ONAL TRUCK AND ENGINE CORPORATION.		2 mm 2022 6/7/11		
						7
		BULB APPLICATION	CAI	NDLEPOWER OR WATTS	BULB TRADE NUMBER	4
		ASHTRAY		1.4 WATT	74T-5	1
		DOME		15 WATT	211-2	┪
		FOG LIGHTS		55 WATT	64151	1
		ROOF MARKER LIGHTS HIGH BEAM HEADLIGHT		5 WATT 65 WATT	0194 9007 LL	1
		LOW BEAM HEADLIGHT		55 WATT	9007 LL	1
		PARK LAMP		27 WATT	1157NA	1
		FRONT TURN SIGNAL		8 WATT	1157NA]
		SIDE MARKER LIGHTS		5 WATT	168	1
		REVERSE LIGHT		32 WATT	1156]
		STOP / TAIL LIGHTS		32 WATT / 3 WATT	1157	
A1	DATE 28AUGO7	CHANGE REVISED AND REDRAWN		DRAWN NAME UOOJAHP CIRCUIT DIAGRAM	LCF	

Figure 7 Lamp Bulb Chart

2.8. RELAY FUNCTION AND WIRING GUIDE, P. 8




Figure 8 Relay Function and Wiring Guide

2.9. SCHEMATIC SYMBOL CHART, P. 9




Figure 9 Schematic Symbol Chart

2.10. SCHEMATIC SYMBOL CHART, P. 10




Figure 10 Schematic Symbol Chart

2.11. SCHEMATIC SYMBOL CHART, P. 11




Figure 11 Schematic Symbol Chart

2.12. SCHEMATIC SYMBOL CHART, P. 12




Figure 12 Schematic Symbol Chart

3. 12 VOLT DISTRIBUTION, GROUNDS, AND DATA LINKS (CHAPTER 3)

3.1. BATTERY FEEDS, POWER DISTRIBUTION BOX, P. 1




Figure 13 Battery Feeds, Power Distribution Box

3.2. BATTERY FEEDS, POWER DISTRIBUTION BOX, P. 2




Figure 14 Battery Feeds, Power Distribution Box

3.3. BATTERY FEEDS, POWER DISTRIBUTION BOX, P. 3




Figure 15 Battery Feeds, Power Distribution Box

3.4. KEY SWITCH, P. 4




Figure 16 Key Switch

3.5. IGNITION FEEDS (RUN), P. 5




Figure 17 Ignition Feeds (Run)

3.6. IGNITION FEEDS (START), P. 6




Figure 18 Ignition Feeds (Start)

3.7. IGNITION FEEDS (RUN-START), P. 7




Figure 19 Ignition Feeds (Run-Start)

3.8. IGNITION FEEDS (RUN-ACCESSORY), P. 8




Figure 20 Ignition Feeds (Run-Accessory)

3.9. GROUNDS (MAIN CHASSIS), P. 9




Figure 21 Grounds (Main Chassis)

3.10. GROUNDS (MAIN CHASSIS), P. 10




Figure 22 Grounds (Main Chassis)

3.11. GROUNDS (REAR CHASSIS), P. 11




Figure 23 Grounds (Rear Chassis)

3.12. GROUNDS (IP), P. 12




Figure 24 Grounds (IP)

3.13. GROUNDS (IP), P. 13




Figure 25 Grounds (IP)

3.14. CAB GROUNDS (ROOF, FLOOR), P. 14




Figure 26 Cab Grounds (Roof, Floor)

3.15. J1708 DATA LINK, P. 15




Figure 27 J1708 Data Link

3.16. J1939 DATA LINK, P. 16




Figure 28 J1939 Data Link

3.17. J2284 DATA LINK, P. 17




Figure 29 J2284 Data Link

3.18. DIAGNOSTIC CONNECTORS, P. 18




Figure 30 Diagnostic Connectors

4. CAB ACCESSORIES (CHAPTER 4)

4.1. CIGAR LIGHTER, P. 1




Figure 31 Cigar Lighter

4.2. POWER WINDOWS, P. 2




Figure 32 Power Windows

4.3. POWER DOORS, P. 3




Figure 33 Power Doors

4.4. HORN AND COMBINATION SWITCH B, P. 4




Figure 34 Horn and Combination Switch B

4.5. RADIO, P. 5




Figure 35 Radio

4.6. WINDSHIELD WIPER AND WASHER PUMP, P. 6




Figure 36 Windshield Wiper and Washer Pump

4.7. DOOR AJAR SWITCH AND DOME LIGHT, P. 7




Figure 37 Door Ajar Switch and Dome Light

5. CHARGING AND CRANKING SYSTEM (CHAPTER 5)

5.1. CHARGING AND CRANKING — INTERNATIONAL V6 ENGINE, P. 1




Figure 38 Charging and Cranking — International V6 Engine

6. ENGINE ACCESSORIES (CHAPTER 6)

6.1. HFCM MODULE — INTERNATIONAL V6 ENGINE, P. 1




Figure 39 HFCM Module — International V6 Engine

6.2. FUEL TANKS — DUAL TANK, P. 2




Figure 40 Fuel Tanks — Dual Tank

6.3. FUEL TANKS — LEFT AND AUXILIARY TANK, P. 3




Figure 41 Fuel Tanks — Left and Auxiliary Tank

7. ELECTRONIC ENGINES (CHAPTER 7)

7.1. INTERNATIONAL V6 POWER AND GROUND SYSTEM, P. 1




Figure 42 International V6 Power and Ground System

7.2. INTERNATIONAL V6 CRUISE CONTROL, P. 2




Figure 43 International V6 Cruise Control

7.3. INTERNATIONAL V6 ACCELERATOR PEDAL, P. 3




Figure 44 International V6 Accelerator Pedal

7.4. INTERNATIONAL V6 ENGINE SENSOR, P. 4




Figure 45 International V6 Engine Sensor

7.5. INTERNATIONAL V6 GLOW PLUG AND ENGINE FAN, P. 5




Figure 46 International V6 Glow Plug and Engine Fan

7.6. INTERNATIONAL V6 AFTERTREATMENT, P. 6




Figure 47 International V6 Aftertreatment

7.7. INTERNATIONAL V6 INJECTORS, P. 7




Figure 48 International V6 Injectors

7.8. INTERNATIONAL V6 INJECTORS, P. 8




Figure 49 International V6 Injectors

8. CLUSTERS AND WARNING LIGHTS (CHAPTER 8)

8.1. CLUSTER CONNECTOR A, P. 1




Figure 50 Cluster Connector A

8.2. CLUSTER CONNECTOR A, P. 2




Figure 51 Cluster Connector A

8.3. CLUSTER CONNECTOR B, P. 3




Figure 52 Cluster Connector B

8.4. CLUSTER CONNECTOR B, P. 4




Figure 53 Cluster Connector B

8.5. MULTIPLEX SWITCH MODULE AND AFTERTREATMENT SYSTEM, P. 5




Figure 54 Multiplex Switch Module and Aftertreatment System

9. LIGHT SYSTEMS (CHAPTER 9)

9.1. COMBINATION SWITCH A, HAZARD SWITCH, P. 1




Figure 55 Combination Switch A, Hazard Switch

9.2. MARKER, FRONT PARK AND TURN LIGHTS, P. 2




Figure 56 Marker, Front Park and Turn Lights

9.3. REAR TAIL, TURN, STOP AND BACKUP LIGHTS, P. 3




Figure 57 Rear Tail, Turn, Stop and Backup Lights

9.4. REAR TAIL, TURN, STOP AND BACKUP LIGHTS, P. 3A




Figure 58 Rear Tail, Turn, Stop and Backup Lights

9.5. FOG LIGHTS, P. 4




Figure 59 Fog Lights

9.6. HEADLIGHTS, P. 5




Figure 60 Headlights

9.7. PANEL LIGHTS, P. 6




Figure 61 Panel Lights

10. CHASSIS ACCESSORIES (CHAPTER 10)

10.1. ANTILOCK BRAKE SYSTEM (ABS), P. 1




Figure 62 Antilock Brake System (ABS)

10.2. BODY BUILDER CUSTOMER ACCESS CIRCUITS (BOC), P. 2




Figure 63 Body Builder Customer Access Circuits (BOC)

10.3. BODY BUILDER LIGHTING CIRCUITS (BOC), P. 3




Figure 64 Body Builder Lighting Circuits (BOC)

10.4. BODY BUILDER (EOF), P. 4




Figure 65 Body Builder (EOF)

10.5. BRAKE SYSTEMS: FLUID, PRESSURE AND PEDAL SWITCH, P. 5




Figure 66 Brake Systems: Fluid, Pressure and Pedal Switch

10.6. BRAKE SYSTEMS: ELECTRIC TRAILER BRAKES, P. 6




Figure 67 Brake Systems: Electric Trailer Brakes

11. TRANSMISSION (CHAPTER 11)

11.1. TRANSMISSION CONTROL MODULE, P. 1




Figure 68 Transmission Control Module

11.2. TRANSMISSION CONTROL MODULE, P. 1A




Figure 69 Transmission Control Module

11.3. TCM TO TRANSMISSION BULKHEAD CONNECTOR, P. 2




Figure 70 TCM to Transmission Bulkhead Connector

12. CLIMATE CONTROL (CHAPTER 12)

12.1. HVAC SYSTEM, P. 1




Figure 71 HVAC System

12.2. A/C CLUTCH, P. 2




Figure 72 A/C Clutch

12.3. PUSHER FAN, P. 3




Figure 73 Pusher Fan

13. CONNECTOR COMPOSITES (CHAPTER 13)

13.1. CONNECTOR COMPOSITES (1), (2), (3), P. 1




Figure 74 Connector Composites (1), (2), (3)

13.2. CONNECTOR COMPOSITES (71), (72), (101), (102), P. 2




Figure 75 Connector Composites (71), (72), (101), (102)

13.3. CONNECTOR COMPOSITES (103), (104), (105), (106), P. 3




Figure 76 Connector Composites (103), (104), (105), (106)

13.4. CONNECTOR COMPOSITES (201), (202A), (202C), P. 4




Figure 77 Connector Composites (201), (202A), (202C)

13.5. CONNECTOR COMPOSITES (203), (204), (205A), P. 5




Figure 78 Connector Composites (203), (204), (205A)

13.6. CONNECTOR COMPOSITES (205B), (206), (207), (208), P. 6




Figure 79 Connector Composites (205B), (206), (207), (208)

13.7. CONNECTOR COMPOSITES (211), (212), (213), P. 7




Figure 80 Connector Composites (211), (212), (213)

13.8. CONNECTOR COMPOSITES (214), (215), (217A), (217B), P. 8




Figure 81 Connector Composites (214), (215), (217A), (217B)

13.9. CONNECTOR COMPOSITES (220), (222), (223), (225), P. 9




Figure 82 Connector Composites (220), (222), (223), (225)

13.10. CONNECTOR COMPOSITES (226), (227), (228), (229), P. 10




Figure 83 Connector Composites (226), (227), (228), (229)

13.11. CONNECTOR COMPOSITES (233), (234), (235), P. 11




Figure 84 Connector Composites (233), (234), (235)

13.12. CONNECTOR COMPOSITES (236A), P. 12




Figure 85 Connector Composites (236A)

13.13. CONNECTOR COMPOSITES (236B), (237), (238), P. 13




Figure 86 Connector Composites (236B), (237), (238)

13.14. CONNECTOR COMPOSITES (239), (240), (241), (243), P. 14




Figure 87 Connector Composites (239), (240), (241), (243)

13.15. CONNECTOR COMPOSITES (244), (245), (246), (247), (248), P. 15




Figure 88 Connector Composites (244), (245), (246), (247), (248)

13.16. CONNECTOR COMPOSITES (249), (250), (251), P. 16




Figure 89 Connector Composites (249), (250), (251)

13.17. CONNECTOR COMPOSITES (252), (253), (254), P. 17




Figure 90 Connector Composites (252), (253), (254)

13.18. CONNECTOR COMPOSITES (301), (301A), (301B), (301D), (303), P. 18




Figure 91 Connector Composites (301), (301A), (301B), (301D), (303)

13.19. CONNECTOR COMPOSITES (304), P. 19




Figure 92 Connector Composites (304)

13.20. CONNECTOR COMPOSITES (306), P. 20




Figure 93 Connector Composites (306)

13.21. CONNECTOR COMPOSITES (308), (309), (310), (313), P. 21




Figure 94 Connector Composites (308), (309), (310), (313)

13.22. CONNECTOR COMPOSITES (315), P. 22




Figure 95 Connector Composites (315)

13.23. CONNECTOR COMPOSITES (316), (317), (318), (320), P. 23




Figure 96 Connector Composites (316), (317), (318), (320)

13.24. CONNECTOR COMPOSITES (321), (322), (323), (401), P. 24




Figure 97 Connector Composites (321), (322), (323), (401)

13.25. CONNECTOR COMPOSITES (402), (403), (404), (410), P. 25




Figure 98 Connector Composites (402), (403), (404), (410)

13.26. CONNECTOR COMPOSITES (411), (412), (413), P. 26




Figure 99 Connector Composites (411), (412), (413)

13.27. CONNECTOR COMPOSITES (500), (503), P. 27




Figure 100 Connector Composites (500), (503)

13.28. CONNECTOR COMPOSITES (506), (507), (508), P. 28




Figure 101 Connector Composites (506), (507), (508)

13.29. CONNECTOR COMPOSITES (509), (510), (602), P. 29




Figure 102 Connector Composites (509), (510), (602)

13.30. CONNECTOR COMPOSITES (700), P. 30




Figure 103 Connector Composites (700)

13.31. CONNECTOR COMPOSITES (701), P. 31




Figure 104 Connector Composites (701)

13.32. CONNECTOR COMPOSITES (702A), P. 32




Figure 105 Connector Composites (702A)

13.33. CONNECTOR COMPOSITES (702B), P. 33




Figure 106 Connector Composites (702B)

13.34. CONNECTOR COMPOSITES (702D), P. 34




Figure 107 Connector Composites (702D)

13.35. CONNECTOR COMPOSITES (703), (704), P. 35




Figure 108 Connector Composites (703), (704)

13.36. CONNECTOR COMPOSITES (705), P. 36




Figure 109 Connector Composites (705)

13.37. CONNECTOR COMPOSITES (706), P. 37




Figure 110 Connector Composites (706)

13.38. CONNECTOR COMPOSITES (720), (720A), P. 38




Figure 111 Connector Composites (720), (720A)

13.39. CONNECTOR COMPOSITES (720), (720A), P. 39

	IN ANY WAY D	STRICTED BASIS A ETRIMENTAL TO AND ENGINE CO	THE			CONNECT	OR CO	MPOSITES	- MATING	VIEW SH	OWN	
	CONT FRO	OM SHEET 38				_						
	CAV	CIRCUIT	GAUGE	COLOR	TERMIN	AL	CAV	CIRCUIT	GAUGE	COLOR	TERMINAL	
	50-1	-	-	_	-		62-1			-	-	
	50-2	-	-	-	_		62-2	-	-	-	-	
	50-3	-	-	-	_	— ⊢	62-3	-	-	-	-	
	50-4	50-4		— ⊢	62-4	-	-	-				
	50-5	-	-	-	_	-	62-5	-	-	-	-	
	51-1	N297C	14	BK	35924910		62-6	-	-	-	-	
	51-2	N57AA	18	BK	35924910	21	62-7	-	 -	-		
	51-3	N1662	16	YL	35924900		62-8	<u> </u>	+ -	-		
	51-4		 .		·		62-9		+ -	- -	+	
	51-5	N653	16	DKBL	35924900		2-10	+ -	+ -	<u> </u>	\vdash	
	52-1	N297F	14	BK	35924910		2-11	+	+ -	<u> </u>	\vdash	
	52-2	N57AB	18	BK RD	35924910		62-12 62-13	 	 	<u> </u>	 	
	52-3 52-4	N1861B	18	KD.	35924900		62-13 62-14		1:		 	
	52-4	N462	18	PL	35924900		32-15	_		-		
	53-1	N297B	14	BK	35924900		2-15			-	<u> </u>	
	53-2	N321	18	GY	35924910		2-17					
	53-3	N883	18	PK	35924900		2-18			-	_	
	53-4	_	-	-	-		2-19	-	-	-	-	
	53-5	N1810	18	LTGN	35924900	C1 6	2-20			-	-	
	54-1	N477	18	LTBL	35924910)1 E	2-21	-	-	-	-	
	54-2	N57AC	18	BK	35924910	:16	32-22		-	-	-	
	54-3	N475	18	WH	35924900	21						
	54-4	-	-	-	-							
	54-5	N1721	18	LTBL	35924900							
	55-30	N1854B	12	WH	35934410							
	55-85	N1769	18	BN	35924920							
	55-86	N1854C	18	RD	35924920							
	55-87	N1683A	10	LTGN	35924930	21						
	55-87A 56-30	N1672	14	DKBL	35924920	`1						
	56-85	N298F	12	GY	35934410							
	56-86	N57AE	18	BK	35924920							
	56-87	N1671	14	RD	35924920							
	56-87A	-	-	-	_							
	57-30	N329	12	PK	35934410	1						
	57-85	N32	12	RD	35934410							
	57-86	N1093	18	TN	35924920							
	57-87	N113	16	YL	35924920	21						
	57-87A	+ -	+	 -	+	\dashv						
	58-30	+ -	 	-	 							
	58-85 58-86	+ -	 		 	\dashv						
	58-86	+ :			<u> </u>	$\overline{}$						
	59-1	N1057B	16	OR	35924910	:1						
	59-1	N1037B	18	WH	35924910							
	59-3	N1057C	16	OR	35924900							
	59-4											
	59-5	N14C	16	BN	35924900	21						
	60-1	N297D	14	BK	35924940							
	60-2	N297F	14	BK	35924940	21						
	61-1	-	-	 								
	61-2	-							CONT	ON SHEE	T 40	
				REV RE	FERENCE	DRAWN	1 CIRCUIT DIAGRAM, LCF					_

Figure 112 Connector Composites (720), (720A)

13.40. CONNECTOR COMPOSITES (720), (720A), (829M), P. 40




Figure 113 Connector Composites (720), (720A), (829M)