

SAI ENTERPRISES

G-20, Vikas Surya, Janak Plaza, Plot-C6B Market Janakpuri
New Delhi-110058 Tel- 011-46025513 Ph: +91 9312175513, 9716115513,
Email: msrao@saienterprises.info, GSTIN: 07ABCFS5634D1ZC

Angular/Common Box Stitching Machine Size 52"



Angular Box Stitcher (ABS) is the most widely used stitcher in Indian and South Asian market. We bring forth the best in class ABS stitchers running today in thousands of corrugation manufacturing unit.

Straight Model Available for Smaller Boxes. Bottom sealing attachment is also available on order.

Selection of size can be decided on the basis of size of box. Machine is used with flat wire.

OPERATION MANUAL

The first essential to good stitching is a clean cut-off. Keep the knives sharp and see that the Cutting Tube is in contact with the Cutting Knife.

CUTTING KNIFE

This is a rectangular plate having its four cutting edges. By the change of three hole at the position of one edge: One Cutting Knife can be used twelve times. So, it has a long life.

This is an electronic message, hence signature not required.

Hyderabad

Pune

Vizag

Nairobi-kenya

SAI ENTERPRISES

G-20, Vikas Surya, Janak Plaza, Plot-C6B Market Janakpuri
New Delhi-110058 Tel- 011-46025513 Ph: +91 9312175513, 9716115513,
Email: msrao@saienterprises.info, GSTIN: 07ABCFS5634D1ZC

CUTTING TUBE

The having particularly only one cutting edge made re-grindable. Care must be taken when grinding to see that the hole is the foremost point.

SETTING THE CUT OFF

After adjustment of cutting edge, the Cutting Tube should be replaced such that it contacts with the cutting knife. Then clamp up.

Make sure that contact is secured and also that it is not so tight as to interfere with the free movement of the cutting knife under the action of cut-off slide.

THREADING

The path of the wire is between the two strips and third hole of wire guide spring, then under 'two rollers fitted with head and over the Roller fitted with slider with adjusting nut. After that under the Feeder roller and over the Gripper Block then in the mouth of Cutting Tube.

Care must be taken to push forward the end of the wire, only just to protrude beyond the mouth of the Cutting Tube. If it is pushed too forward, buckling may occur due to the end of the wire arriving at the Loop Bar before this is in the position to receive it.

SETTING FOR THICKNESS

According to the thickness of the job; the supply of wire can be adjusted from Feed Adjusting Screw. If short supply is needed then tight the adjusting screw.

If job is thick then loose the adjusting screw. Make sure that the Cutting Knife should not touch with the Former Driver when screw is to be tightened, and should not touch to the Cutter Slide when screw is to be loosed.

Thickness between former driver and Clinches Ram can be adjusted from Eccentric Adjuster by the graduation mark indicated on the Arm.

LUBRICATION

Do not neglect to lubricate both in the oil cups and in other obvious places. Remember that this is light and fast machine

This is an electronic message, hence signature not required.

Hyderabad

Pune

Vizag

Nairobi-kenya