



# DT Print Agent — Setup Guide

Connects DigitalTouch POS to a USB thermal receipt printer on Windows.

## 1. Install the agent

- 1 Download **dt-print-agent-setup.exe** from Settings → Receipt printer → Download in DigitalTouch POS.
- 2 Run it. If Windows shows a SmartScreen warning, click *More info* → *Run anyway* (this is expected for a new, unsigned installer).
- 3 Leave both checkboxes ticked: *Start automatically when Windows starts* and *Open the USB driver setup guide*.
- 4 A teal “DT” icon should appear in the system tray (bottom-right, near the clock). That means the agent is running.

## 2. One-time USB driver setup (Zadig)

Windows automatically attaches its own driver to the printer the first time it's plugged in, and that driver keeps other programs — including this agent — from talking to it directly. This step hands that one interface to the agent instead. It's done once per printer, not every time you print.

- 1 Download Zadig from **zadig.akeo.ie** (no install needed, just run it).
- 2 In Zadig, go to *Options* → tick *List All Devices*.
- 3 From the dropdown, select your receipt printer (usually named after the printer model or brand).
- 4 Make sure the target driver on the right shows **WinUSB**, then click **Replace Driver** (or *Install Driver*).
- 5 Wait for it to finish, then unplug and replug the printer.

Only do this for the receipt printer. Don't replace drivers for any other USB device in the list.

## 3. Connect it in DigitalTouch POS

- 1 Open DigitalTouch POS → Settings → Receipt printer.
- 2 Click **Connect via DT Print Agent**.
- 3 It should find the printer automatically and show it as connected.
- 4 Click **Test print** to confirm a receipt comes out.

## Troubleshooting

| Symptom                       | What to try                                                                |
|-------------------------------|----------------------------------------------------------------------------|
| No tray icon after installing | Open the Start Menu → DigitalTouch → DT Print Agent to launch it manually. |

|                                                              |                                                                                                            |
|--------------------------------------------------------------|------------------------------------------------------------------------------------------------------------|
| “Can’t reach the DT Print Agent” in the POS                  | Check the tray icon is present. If not, relaunch it from the Start Menu.                                   |
| “No USB printer detected by the agent”                       | Check the cable and power, then redo step 2 (Zadig) — the printer may still be on Windows' default driver. |
| “Access denied” / “Couldn't reach the printer” when printing | Unplug and replug the printer, then try again. If it persists, redo step 2.                                |
| Printer worked before, stopped after a Windows update        | Windows updates sometimes reset the driver binding — redo step 2.                                          |

Still stuck? Check the agent's log file at %LOCALAPPDATA%\DigitalTouch\PrintAgent\logs\agent.log (right-click the tray icon → Open logs folder), or contact DigitalTouch support.