AQUACLEAN DELUXE DISHWASHER - TECHNICAL GUIDE & USER MANUAL

Appliance: Dishwasher | **Model Series:** DW-600 Built-In & Freestanding

1. Critical Safety & Flood Prevention Guidelines

Always shut off the water supply stopcock and isolate electrical power at the circuit breaker before attempting any internal filter or pump servicing.

WARNING: Internal heating element reaches high temperatures (65°C - 75°C). Never open door during drying cycle to avoid steam scalds.

2. Common Faults and Solutions

Error Code E15: AquaStop Flood Protection Sensor Triggered

Possible Cause: Water has leaked into the internal bottom drip tray beneath the machine, lifting the safety styrofoam float switch.

Recommended Solution: 1. Turn off water tap and unplug electrical power. 2. Gently tilt dishwasher backward by 45 degrees over a towel to drain trapped water from bottom base pan. 3. Check inlet water connection and door gasket for visible leaks. 4. If E15 recurs, call authorized technician.

Error Code E24 / E25: Dishwasher Not Draining (Standing Water in Sump)

Possible Cause: Triple fine filter in floor is clogged with food grease, or foreign object (glass shard, bone piece) jammed in drain pump impeller.

Recommended Solution: 1. Remove lower rack. 2. Turn central cylindrical filter counter-clockwise and pull out. 3. Wash mesh filter under hot running water with liquid soap. 4. Remove white plastic pump impeller cover; inspect impeller wheel with a flashlight and remove any debris with tweezers. 5. Click cover firmly back into place before running.

Dishes Coming Out Dirty or With White Film / Water Spots

Possible Cause: Clogged spray arm nozzles, incorrect detergent dosing, empty rinse aid dispenser, or low dishwasher salt in water softener unit.

Recommended Solution: 1. Unclip upper and lower spray arms; use a wooden toothpick to poke out mineral seeds from spray jet holes. 2. Refill rinse aid reservoir until indicator turns dark. 3. In hard water areas, fill the salt container with special coarse dishwasher regenerating salt.

3. Monthly Maintenance & Filter Hygiene

Run an empty Intensive cycle (70°C) with a specialized dishwasher cleaning tablet every 30 cycles to remove hidden grease and limescale deposits inside pipes.