QuickAlignment — Beamline Staff Guide

ANTARES beamline (SOLEIL) · calibrating the stage model with InitialCalibration, and looking after the program

Contents

1. What the staff are responsible for
2. The stage model and its constants
3. When to recalibrate
4. Starting InitialCalibration
5. Optics only (the usual case)
6. Optics + motors (full calibration)
7. Test points: checking and correcting
8. Saving and how QuickAlignment uses the file
9. Looking after the program
10. Troubleshooting

What the staff are responsible for

Users only *read* the stage calibration: QuickAlignment loads the newest **configuration file** for the chosen optic and has no way to change it. The configuration is made by beamline staff with the separate program **InitialCalibration** and stored in `configs/`:

```
configs/calibration_YYYY-MM-DD_HHMMSS_<optic>.json      optic: zone_plate or capillary
```

One file per calibration, never overwritten. What remains for a user (mostly the error of drawing a sample on the plate) is corrected by *Found here* in the Stage & Optics tab.

The stage model and its constants

Stack, bottom to top: ST / SN / SZ translations → SRz → SRn → PIX / PIY piezo → plate. Top view: the beam runs along +y, the analyzer focal plane at 45°, ST along it and SN perpendicular to it.

constant	meaning	determined by
ST0, SZ0	ST / SZ putting the plate centre on the beam (SRn 120°, SRz 0°)	set 1
SN_f	SN putting the standard plate's raised surface (5.0 mm) in the analyzer focal plane	set 1
SRn axis x, y	position of the SRn rotation axis on the plate	a set with SRn rotated
SRz offset ST, SN	offset of the SRz axis from the plate-surface centre line	a set with SRz rotated
optic reference	optic position putting the focus on the analyzer focus	optic position noted in the sets


SRn = 120° (plate vertical, tab up) is the mechanical reference; PIX = PIY = 150 µm during calibration. The optic is modelled as a focus point moving along the beam: ST, SZ and SRn do not change the surface plane, so they need no optic move; SN, SRz and the sample height do (1 mm along SN moves the spot √2 mm along the beam).

When to recalibrate

situation	mode
capillary or zone plate realigned (beam meets the plate elsewhere, focus moved)	**optics only**
motors re-homed / reset, manipulator maintenance, receptacle changed	**optics + motors**
first use, or no configuration for this optic yet	**optics + motors**
users' *Found here* corrections above ~0.3 mm, same shift for several samples	check with optics only; full if the residuals stay large


Starting InitialCalibration

Double-click **`InitialCalibration.py`** (Windows: `InitialCalibration.pyw`). The first question is what was recalibrated:




Optics only is offered only when a configuration exists already (the mechanics are taken from it).

In both modes, first enter the **reference feature**: one small, sharp feature that can be found with the beam (the corner of a reference sample, a mark), close to the plate centre so that it stays reachable when rotating. Enter its plate coordinates x, y (mm, from the centre of the back plate, front view, tab up) and its height H above the plate surface, and choose the **focusing optic**. **Show front / side view** draws the plate with the feature and lists where each set should find it with the current configuration (motor ranges checked):



Use the **same feature in every set**.

Optics only (the usual case)



Fitted: ST0, SZ0 and the optic reference. Kept from the newest configuration of the chosen optic: SN_f, the SRn axis and the SRz axis offsets. For every set, as the stage is normally run:

1. Set SRn and SRz of the set; PIX = PIY = 150 µm.
2. **Leave SN as it is** (it does not have to be at the analyzer focus).
3. Bring the feature onto the beam with ST / SZ.
4. Refocus the optic on the feature.
5. Write down ST, SZ, SN and the optic position.

Set 1 (SRn 120°, SRz 0°) is enough. Sets 2–3 (SRn and SRz rotated) are recommended: they check the kept axes. If their residuals stay above ~0.05 mm the mechanics have changed: restart the program and choose *optics + motors*.

Optics + motors (full calibration)

All 7 constants and the optic reference are fitted. The feature is put **at the analyzer focus** in every set.


set	SRn	SRz	purpose
1	120	0	ST0, SZ0, SN_f, optic reference
2	140	0	SRn axis
3	120	−10	SRz axis
4	100	0	check (recommended)
5	120	+10	check (recommended)

Minimum 3 sets (each gives ST, SZ, SN); **5 recommended**, so that a wrong measurement shows up in the residuals. Larger rotations give more precise axes (|SRn − 120| ≥ 20°, |SRz| ≥ 10° as far as the geometry allows). Untick a set that was not measured; *Add set* adds one at other angles.

For every set:

1. Set SRn and SRz; PIX = PIY = 150 µm.
2. Bring the feature onto the beam with ST / SZ (scan across it, take the centre of the edge or feature).
3. Bring it to the analyzer focus with SN.
4. Repeat 2–3 until stable; write down ST, SZ, SN.
5. Optimise the optic focus on the feature and write down the optic position: at least in set 1, preferably in every set (+ moves the optic towards the sample).


Press **Compute**:



- **Fitted constants** with their 1σ uncertainty, the value of the newest configuration and the change.
- **Residuals** per set (model − measured, mm) for ST, SZ, SN and the optic. With 5 sets they should be ≲ 0.01–0.02 mm. One large residual usually means that set was measured on another point or out of focus: re-measure it, or untick it.
- Warnings: *Not enough data* (which constants the sets cannot determine), *minimum data set* (mistakes cannot be detected), residuals above 0.05 mm, no optic position entered (optic reference not calibrated).
- A fit on impossible numbers (typing errors, NaN) is reported instead of being saved.

Test points: checking and correcting

After *Compute*, the **Test points** tab predicts rotations not used in the sets (SRn ± 30°, SRz ± 15°, SRn and SRz combined) with the ST, SZ, SN and optic position where the configuration puts the feature:



For each test point:

1. Go to the predicted SRn, SRz, ST, SZ, SN and optic position.
2. If the feature is on the beam and in focus **within 0.05 mm**, tick **Found**.
3. If not: keep SRn, SRz and SN, bring the feature onto the beam with ST / SZ, focus the optic and enter the **real ST, SZ and optic position** (optic optional). Red predictions are outside a motor range: change the angles of that test point (it is predicted again).

Correct the configuration with the test results → new test points adds the real positions to the fit (found points only confirm), fits all constants again and predicts a new round. Answered rounds stay in the table, read-only, with their deviations. Repeat until all test points of a round are found, or the deviations are small enough; a set that stays an outlier was probably measured wrongly: untick it and correct again.

Saving and how QuickAlignment uses the file

Add a comment (date, reason, what was measured) and press **Save as new configuration**. The file is written atomically (a failed write leaves no partial file) and contains the constants, the optics reference, the sets, the test points and their residuals, for the record.

- QuickAlignment loads, at every start, the **newest file of the optic chosen** by the user. A zone-plate configuration does not replace the capillary one and vice versa.
- If there is no file for that optic, the stage constants of the newest file are used and the optic position is shown as uncalibrated.
- Damaged or foreign files in `configs/` are skipped. To withdraw a bad configuration, move its file out of `configs/` (do not edit it).
- Users can choose an older configuration for their session in *Configuration…* (read-only).

Anti-collision solids

The analyzer nose, the zone plate and OSA and the capillary are modelled as simple solids (README, *Anti-collision*). The zone plate / OSA dimensions are **placeholders** and the capillary working distance an estimate: measure them (distance of each front from the focus, width, thickness; for the OSA, the OSA_S position they belong to) and put them in the configuration under `"collision"` (edit a copy, then save it as a new file). InitialCalibration keeps the solids of the previous configuration of the same optic.

Looking after the program

Installation (Python ≥ 3.9): `pip install -r requirements.txt` (PyQt5 or PySide6, numpy, matplotlib; pytest for the tests). Start with `QuickAlignment.py` / `InitialCalibration.py` (`.pyw` on Windows without console).

Tests: `python -m pytest` in the QuickAlignment folder (about 120 tests, ~15 s; Qt runs off-screen). They cover the stage model, rotations, calibration fits, file loading and the main windows.

Limits that may need editing (one place each):

what	where
motor travel ranges ST, SN, SZ (input fields and warnings)	`MOTOR_SPECS` in `quickalignment/ui/stage_panel.py`
usable SRn / SRz, deflector limits, accepted offsets, photon energy range, zone-plate energy, work function	constants at the top of `quickalignment/bz_target.py`
analyzer slit orientation and the signs of slit / deflector angles	`AnalyzerGeometry` in `quickalignment/rotation.py`
plate drawings (standard, gating)	`quickalignment/geometry.py`

Robustness: an unexpected error in the program is shown in a dialog (with details) and the program keeps running, so that entered positions are not lost; please collect these details. Sessions and configurations are written atomically; unreadable sessions give a message instead of a crash; impossible table entries (nan, inf, text) are refused.

Guides: the screenshots are made by `python devtools/guide_screenshots.py`, the PDFs by `python devtools/build_guides.py` (needs pandoc and Playwright with Chromium). Sources: `docs/USER_GUIDE_*.md`, `docs/STAFF_GUIDE_*.md`.

Troubleshooting

symptom	likely cause / action
all samples found shifted by the same amount	ST0 / SZ0 changed (optic realigned): *optics only*
shift depends on the rotation	axes changed (motors re-homed): *optics + motors*
Optics only residuals of sets 2–3 above 0.05 mm	mechanics changed: *optics + motors*
one set with a large residual	wrong point, out of focus or typing error: re-measure or untick
Not enough data: …	the listed constants need a set with SRn and/or SRz rotated

symptom	likely cause / action
a set needs SN below the collision limit	the feature is too low; use a feature on a higher sample
QuickAlignment shows *default* configuration	no readable file in `configs/` for any optic