ARCA DEVICES SERVICE INTERFACE (ARCADevsvc.dll)

By
ARCA Technologies s.r.l.
Via Statale 17
10012 Bollengo (TO)

tel. ++390125235611
fax. ++390125235623
web site: www.arca.com
e-mail: techsupp.it@arca.com

Last revision: December 16, 2021

Contents

Interface Functions Description 4
ARCAInitializeSrv 5
ARCALibraryVersion 6
ARCAUpdateVersion 7
ARCAexeCassetteInit 9
ARCAexeCassetteAssing 11
ARCAsetDeviceLAN 13
ARCAgetDeviceLAN 14
ARCAexeRecoverySuspend 15
ARCAexeRecoveryContinue 16
ARCAexeJournalInit 17
ARCAgetDevicePhoto 18
ARCAsetDevicePhoto 20
ARCAexeFileTransfer 21
ARCAgetPocketOutput 23
ARCAsetPocketOutput 24
ARCAgetDispenseSecurityLimit 25
ARCAsetDelays 26
ARCACassette 27
ARCAgetCommunicationLAN 29
ARCAsetCommunicationLAN 31
ARCAsetCassette 33
ARCAsetCassetteChangheKey 35
ARCAsetLogServiceRecord 36
ARCAsetCassetteDenomination 38
ARCAsetReaderSettings 40
ARCAsetDeviceIdentification 42
ARCAsetDeviceSettings 43
ARCAgetShiftCenterSettings 45
ARCAsetShiftCenterSettings 46
ARCAsetDeviceProtocolType 47
ARCAgetInputSetting 48
ARCAsetInputSetting 49
ARCAsetDeviceSerialNumber 50
ARCAsetAudioSettings 51
ARCAgetOperatingHours 52
ARCAsetOperatingHours 54
ARCAsetReaderThreshold 56
ARCAgetTimeZone 57
ARCAsetTimeZone 58
ARCAsetCommunicationsUsb 59
ARCAgetCommunicationsUsb 60
ARCAsetCommunicationsSerial 62
ARCAgetDevicePhotoNovus 63
Coin Section 65

ARCAgetCoinCashData 66
ARCACoinInventory 67
ARCACoinDispense 69
ARCAgetCoinConfiguration 72

Interface Functions Description

All functions are exported in C-Language compatible application programming interface (API).

The API is independent from the physical connection technology, whether it be TCP/IP, USB or RS232 used to connect the check scanners to the host system.

To start an application program that uses this service it is necessary to install in the application directory the files listed below:

- ARCADevInt.dll
- ARCALnk.dll

ARCAInitializeSrv

#include “ARCADevInt.h"

Result API ARCAInitializeSrv (**float** *versioning* , **char** **inData*);

Description

First function that the application MUST call for open the communication with the device.

Parameters

versioning (I)

The value must be set to **LIBRARY_VERSION_1_0**.
Less than 1.0 for alpha and beta versions.

inData (I)

JSON input data structure:

```
{
        “pathtrace” : “xxxx”
}
```

Pathtrace = path where the trace file is stored

Return Value

AR_OKAY if successful.
AR_LIBRARY_INVALID_INITIALIZATION

Comments

ARCALibraryVersion

#include “ARCADevsvc.h”

Result API ARCALibraryVersion(**char** ***LibraryVersion**,
short *lenLibraryVersion*);

Description

Return the version of the library.

Parameters

LibraryVersion (O)

This string will contains the release of the library.

lenLibraryVersion (I)

Length of the buffer give in *Libraryersion* parameter.

Return Value

AR_OKAY if successful.
AR_STRING_TRUNCATED

Comments

ARCAUpdateVersion

#include “ARCADevsvc.h”

Result API ARCAUpdateVersion (**int** *hConnect,*
string * *inData,*
int lloutData**,**
string **outData)*;

Description

Parameters
hConnect (I)

Handle returned by ARCAConnect.

inData (I)
JSON output data structure:
{
“cmdMode”: “xxx”,
"updateMode ":”xxx”
"updateType":”xxx”,
“FileName” : “xxx” ,
“FileSize” : “xxx” ,
“FilePath” : “xxx” ,
}

Accepted values for :
cmdMode = deposit mode execution, “SYNC” or “ASYNC”.
updateMode: init , activate , check
updateType: Suite , Reference, SSLprivatekey , SSLcertificate

in case of init you must compile the other 3 parameter :
FileName = name of the file will be transferred on the device
FileSize = is the number of byte to transfer
FilePath= is the complete path of the file
in case of activate you must compile the other parameter :
FileName = name of the file will be transferred on the device
In case of check no parameter needed (to be implemented)

lloutData (I)
Specifies the size of the outData parameter.

OutData(O)

```
reply: {
"replyCode": "xxxx" ,
"replyCodeDescription": "xxxx"
}
```

Return Value
AR_OKAY
AR_UNIT_ALREADY_RESERVED

AR_UNIT_BUSY
AR_KO
AR_WAIT_DOWNLOAD_TIME_ELAPSED
Refer to chapter Reply codes of ArcadevInt for the full list and description of return codes.

Comment : **to perform the download , in case of LAN connection you must connect to the port 8101 before the start of download**

ARCAexeCassetteInit

#include “ARCADevsvc.h”

Result API ARCAexeCassetteInit (**int** *hConnect,*
string * *inData,*
int lloutData**,**
string **outData)*;

Description

Parameters

hConnect (I)
Handle returned by ARCAConnect.

inData (I)
JSON input data structure:
{
“TargetToinitialize “ : “xxxx” ,
“code “ : “xxxx”
}

Accepted values for :
TargetToinitialize : Denomination to initialize (Es: EUCA) or Cassette to initialize (Es: AAAA)
code : Cassette key-code

lloutData (I)
Specifies the size of the *outData* parameter.

OutData(O)
JSON output data structure:
{ "message": xxxx, "reply": { "replyCode": "xxxxx", "replyCodeDescription": "xxxx" } }

Return value :
Message : Message(1 dec.-ASCII)
0 = Ok, **1,3,5** = reserved, **2**= cassette not present
4= wrong code, **6**= denomination not empty

Return Value
AR_OKAY
AR_UNIT_ALREADY_RESERVED
AR_UNIT_BUSY
AR_KO
Refer to chapter Reply codes of ArcadevInt for the full list and description of return codes.

Comments

ARCAexeCassetteAssing

#include “ARCADevsvc.h”

Result API ARCAexeCassetteAssign (**int** *hConnect,*
string ** inData,*
int lloutData**,**
string **outData)*;

Description

Parameters

hConnect (I)
Handle returned by ARCAConnect.

inData (I)
No input data, set to NULL.

lloutData (I)
Specifies the size of the *outData* parameter.

OutData(O)
JSON output data structure:
{
content : {"message":"xx"}
reply : {"replyCode":"0","replyCodeDescription":"OK"}
}

Return value :
message*:* 0 = OK
1÷16 = cassette A÷”num_cas” not empty
17÷33 = cassette A÷”num_cas” hardware problem , check the hardware and retry

Return Value
AR_OKAY
AR_UNIT_ALREADY_RESERVED
AR_UNIT_BUSY
AR_KO
Refer to chapter Reply codes of ArcadevInt for the full list and description of return codes.

Comments

ARCAexeDeviceErrorLog

#include “ARCADevsvc.h”

Result API ARCAexeDeviceErrorLog (**int** *hConnect,*
string ** inData,*
int lloutData**,**
string **outData)*;

Description

Parameters

hConnect (I)

Handle returned by ARCAConnect.

inData (I)

JSON input data structure:

{

“operationType“ : “xxxx” ,

}

Accepted values for operationType : :

Init = This command is used to erase all data stored

lloutData (I)

Specifies the size of the outData parameter.

OutData(O)

reply: {
"replyCode": "xxxx" ,
"replyCodeDescription": "xxxx"
}

Return value :

Return Value

AR_OKAY
AR_UNIT_ALREADY_RESERVED
AR_UNIT_BUSY
AR_KO
Refer to chapter Reply codes of ArcadevInt for the full list and description of return codes.

ARCAsetDeviceLAN

#include “ARCADevsvc.h”

Result API ARCAsetDeviceLAN (**int** *hConnect,*
string * *inData,*
int lloutData**,**
string **outData)*;

Description

Parameters

hConnect (I)

Handle returned by ARCAConnect.

inData (I)

JSON input data structure:

{

*“*lanEncryption *“ : “xxxx”*

}

Accepted values for lanEncryption*:*

“0” for Simplified
“1” for SSL/TLS
“2” for IPSEC

lloutData (I)

Specifies the size of the outData parameter.

OutData(O)

reply: {
"replyCode": "xxxx" ,
"replyCodeDescription": "xxxx"
}

Return value :

Return Value

AR_OKAY
AR_UNIT_ALREADY_RESERVED
AR_UNIT_BUSY
AR_KO
Refer to chapter Reply codes of ArcadevInt for the full list and description of return codes.

ARCAgetDeviceLAN

#include “ARCADevsvc.h”

Result API ARCAgetDeviceLAN (**int** *hConnect,*
string * *inData,*
int lloutData**,**
string **outData)*;

Description

Parameters

hConnect (I)

Handle returned by ARCAConnect.

{

*“*configType*“ : “xxxx” ,*

}

Accepted values for configType*:* “lanEncryption”

lanEncryption = get the type of LAN communication protocol

lloutData (I)

Specifies the size of the outData parameter.

OutData(O)

{
reply: {
"replyCode": "xxxx" ,
"replyCodeDescription": "xxxx"
}
"content": {
“lanEncryption”: “xxx”
}
}

lanCommunicationProtocol = “0” -> Simplified
“1” -> SSL/TLS
“2” -> IPSEC
“4” -> 802.1x
“5” -> SSL/TLS+802.1x

Return Value

AR_OKAY
AR_UNIT_ALREADY_RESERVED
AR_UNIT_BUSY
Refer to chapter Reply codes of ArcadevInt for the full list and description of return codes.

ARCAexeRecoverySuspend

#include “ARCADevsvc.h”

Result API ARCAexeRecoverySuspend (**int** *hConnect,*
string ** inData,*
int lloutData**,**
string **outData)*;

Description

Parameters

hConnect (I)
Handle returned by ARCAConnect.
inData (I)
No input data, set to NULL.functions
lloutData (I)
Specifies the size of the outData parameter.

OutData(O)

reply: {
"replyCode": "xxxx" ,
"replyCodeDescription": "xxxx"
}

Return value :

Return Value

AR_OKAY
AR_UNIT_ALREADY_RESERVED
AR_UNIT_BUSY
AR_KO
Refer to chapter Reply codes of ArcadevInt for the full list and description of return codes.

ARCAexeRecoveryContinue

#include “ARCADevsvc.h”

Result API ARCAexeRecoveryContinue (**int** *hConnect,*
string * *inData,*
int lloutData**,**
string **outData)*;

Description

Parameters

hConnect (I)
Handle returned by ARCAConnect.
inData (I)
No input data, set to NULL.functions
lloutData (I)
Specifies the size of the outData parameter.

OutData(O)

reply: {
"replyCode": "xxxx" ,
"replyCodeDescription": "xxxx"
}

.

Return value :

Return Value

AR_OKAY
AR_UNIT_ALREADY_RESERVED
AR_UNIT_BUSY
AR_KO
Refer to chapter Reply codes of ArcadevInt for the full list and description of return codes.

ARCAexeJournalInit

#include “ARCADevsvc.h”

Result API ARCAexeJournalInit (**int** *hConnect,*
string * *inData,*
int lloutData**,**
string **outData)*;

Description

Parameters

hConnect (I)
Handle returned by ARCAConnect.
inData (I)
No input data, set to NULL.functions
lloutData (I)
Specifies the size of the outData parameter.

OutData(O)

reply: {
"replyCode": "xxxx" ,
"replyCodeDescription": "xxxx"
}

Return value :

Return Value

AR_OKAY
AR_UNIT_ALREADY_RESERVED
AR_UNIT_BUSY
AR_KO
Refer to chapter Reply codes of ArcadevInt for the full list and description of return codes.

ARCAgetDevicePhoto

#include “ARCADevsvc.h”

Result API ARCAgetDevicePhoto (**int** *hConnect,*
string ** inData,*
int lloutData**,**
string **outData)*;

Description

Parameters

hConnect (I)

Handle returned by ARCAConnect.

inData (I)

No input data, set to NULL.functions

lloutData (I)

Specifies the size of the outData parameter.

OutData(O)

reply: {
"replyCode": "xxxx" ,
"replyCodeDescription": "xxxx"
}
"content":
{

{
"ph_c1": "xxx",
"ph_c3": "xxx",
"ph_c4a": "xxx",
"ph_c4b": "xxx",
"ph_cashleft": "xxx",
"ph_cashright": "xxx",
"ph_count": "xxx",
"ph_feed": "xxx",
"ph_in_box": "xxx",
"ph_incenter": "xxx",
"ph_inleft": "xxx",
"ph_inq": "xxx",
"ph_out": "xxx",
"ph_rej": "xxx",
"ph_shift": "xxx”
} .

Return value :

Return Value

AR_OKAY
AR_UNIT_ALREADY_RESERVED
AR_UNIT_BUSY
AR_KO
Refer to chapter Reply codes of ArcadevInt for the full list and description of return

codes.

ARCAsetDevicePhoto

#include “ARCADevsvc.h”

Result API ARCAsetDevicePhoto (**int** *hConnect,*
string ** inData,*
int lloutData**,**
string **outData)*;

Description

Parameters

hConnect (I)

Handle returned by ARCAConnect.

inData (I)

{
“ph_id”: “xxxx” ,
}

“ph_all” = all photo sensor
“ph_upper” = only photo sensor upper part
“ph_lower” = only photo sensor lower part
"ph_incenter"
"ph_inleft"
"ph_feed"
"ph_c1"
"ph_shift"
"ph_inq"
"ph_count"
"ph_out"
"ph_c3"
"ph_c4a"
"ph_c4b"
"ph_rej"
"ph_in_box"
"ph_cashleft"
"ph_cashright"
"ph_hmax"

lloutData (I)

Specifies the size of the outData parameter.

OutData(O)

{
reply : {"replyCode":"xxxx",
replyCodeDescription":"xxxx"}
}

Return value :

Return Value

AR_OKAY
AR_UNIT_ALREADY_RESERVED
AR_UNIT_BUSY

Refer to chapter Reply codes of ArcadevInt for the full list and description of return codes.

ARCAexeFileTransfer

#include “ARCADevsvc.h”

Result API ARCAexeFileTransfer(**int** *hConnect,*
string * *inData,*
int lloutData**,**
string **outData)*;

Description

Parameters

hConnect (I)
Handle returned by ARCAConnect.
inData (I)
JSON input data structure:
{
“transferType“ : “xxxx” ,
“transferMode” : “xxxx” ,
“transferFile” : “xxxx”
}
Accepted values for transferType: :
Download
Upload
Accepted values for transferMode:
Init
Transfer
End
Abort
Service
Accepted values for transferFile
Log
Suite
Module:

*In case of Log you can specify “*ZipfileName”

(get all LOG and service configuration)

lloutData (I)
Specifies the size of the outData parameter.

OutData(O)

```
reply: {
"replyCode": "xxxx" ,
"replyCodeDescription": "xxxx"
}
```

.

Return value :

Return Value

AR_OKAY
AR_UNIT_ALREADY_RESERVED
AR_UNIT_BUSY
Refer to chapter Reply codes of ArcadevInt for the full list and description of return codes.

ARCAgetPocketOutput

#include “ARCADevsvc.h”

Result API ARCAgetPocketOutput (**int** *hConnect,*
string ** inData,*
int lloutData**,**
string **outData)*;

Description

Parameters

hConnect (I)

Handle returned by ARCAConnect.

inData (I)

JSON input data structure:

{

*“*configType*” : “xxxx” ,*

}

Accepted values for configType*:*

bundleSize-> set the maximum number of banknotes in output slot during the operation of withdrawal

lloutData (I)

Specifies the size of the outData parameter.

OutData(O)

*In case of “*BundleSize”

{

reply: {
"replyCode": "xxxx" ,
"replyCodeDescription": "xxxx"
}
"content": {
“bundleSize”: “xxx”
}

Return value :

Return Value

AR_OKAY
AR_UNIT_ALREADY_RESERVED
AR_UNIT_BUSY
Refer to chapter Reply codes of ArcadevInt for the full list and description of return codes.

ARCAsetPocketOutput

#include “ARCADevsvc.h”

Result API ARCAsetPocketOutput (**int** *hConnect,*
string ** inData,*
int lloutData**,**
string **outData)*;

Description

Parameters

hConnect (I)

Handle returned by ARCAConnect.

inData (I)

JSON input data structure:

{

*“*configType*” : “xxxx” ,*

*“*numnotes” : “xxx”

}

Accepted values for configType*:*

withdrawalBundleSize -> set the maximum number of banknotes in output slot during the operation of withdrawal

lloutData (I)

Specifies the size of the outData parameter.

OutData(O)

reply: {
"replyCode": "xxxx" ,
"replyCodeDescription": "xxxx"
}

Return value :

Return Value

AR_OKAY
AR_UNIT_ALREADY_RESERVED
AR_UNIT_BUSY
AR_KO
Refer to chapter Reply codes of ArcadevInt for the full list and description of return codes.

ARCAgetDispenseSecurityLimit

#include “ARCADevsvc.h”

Result API ARCAgetDispenseSecurityLimit (**int** *hConnect,*
string * *inData,*
int lloutData**,**
string **outData)*;

Description

Parameters

hConnect (I)
Handle returned by ARCAConnect.
inData (I)
No input data, set to NULL.functions
lloutData (I)
Specifies the size of the outData parameter.

OutData(O)

reply: {
"replyCode": "xxxx" ,
"replyCodeDescription": "xxxx"
}

Return value :

Return Value
AR_OKAY
AR_UNIT_ALREADY_RESERVED
AR_UNIT_BUSY
AR_KO
Refer to chapter Reply codes of ArcadevInt for the full list and description of return codes.

ARCAsetDelays

#include “ARCADevsvc.h”

Result API ARCAsetDelays (**int** *hConnect,*
string * *inData,*
int lloutData**,**
string **outData)*;

Description

Parameters

hConnect (I)

Handle returned by ARCAConnect.

I

InData (I)

```
{
        “content”: [
                { “amount”: “xxx”, “delay”: “xxxx” },
                { “amount”: “xxx”, “delay”: “xxxx” },
                { “amount”: “xxx”, “delay”: “xxxx” },
                { “amount”: “xxx”, “delay”: “xxxx” },
                { “amount”: “xxx”, “delay”: “xxxx” },
                { “amount”: “xxx”, “delay”: “xxxx” },
                { “amount”: “xxx”, “delay”: “xxxx” },
                { “amount”: “xxx”, “delay”: “xxxx” },
                { “amount”: “xxx”, “delay”: “xxxx” },
                { “amount”: “xxx”, “delay”: “xxxx” },
            ]
}
```

- amount= The amount is in about a hundred unit (example: if amount = 1 the real value is 1 * 100 = 100)
- delay= Delay in seconds for this class (0-65535)

lloutData (I)

Specifies the size of the outData parameter.

OutData(O)

```
        reply: {
"replyCode": "xxxx" ,
"replyCodeDescription": "xxxx"
}
```

Return value :

Return Value

AR_OKAY
AR_UNIT_ALREADY_RESERVED
AR_UNIT_BUSY
AR_KO
Refer to chapter Reply codes of ArcadevInt for the full list and description of return

codes.

ARCACassette

#include “ARCADevsvc.h”

Result API ARCACassette (**int** *hConnect,*
string ** inData,*
int lloutData**,**
string **outData)*;

Description

Parameters

hConnect (I)

Handle returned by ARCAConnect.

I

InData (I)

{

“cassette”: [

{ “Num_cas”: “xxx”, “Enable”: “xxxx” },
{ “Num_cas”: “xxx”, “Enable”: “xxxx” },
{ “Num_cas”: “xxx”, “Enable”: “xxxx” },

]

}

num_cas = target cassette A…”
Enable = 0 = switch OFF , 1 = switch ON

lloutData (I)

Specifies the size of the outData parameter.

OutData(O)

No output data, set to NULL.functions

Return value :

Return Value

AR_OKAY
AR_UNIT_ALREADY_RESERVED
AR_UNIT_BUSY
AR_KO
Refer to chapter Reply codes of ArcadevInt for the full list and description of return codes.

ARCAgetCommunicationLAN

#include “ARCADevsvc.h”

Result API ARCAgetCommunicationLAN (**int** *hConnect,*
string ** inData,*
int lloutData**,**
string **outData)*;

Description

Parameters

hConnect (I)

Handle returned by ARCAConnect.

inData (I)

{
“lanParam” :”xxxx”
Or
“lanPort” : “xxxx”
}

lanParam value accepted :
“1”=DHCP
“2”=IP address
“3”=Subnet mask
“4”=Gateway
“5”=Device name
“6”=Device description
“7”=Primary DNS
“8”=Secondary DNS
“9”=Primary WINS
“10”=Secondary WINS
“11”= Use NetBios name
“12”= Username 802.1x
“13”= Password 802.1x
Or
“whitelist” = get the addresses list authorized to connect to the device

lanPort value accepted :
1 = LAN 1
2 = LAN 2
3 = LAN 3
4 = LAN 4
5 = LAN 5
6 = LAN 6
7 = LAN 7
8 = LAN 8
9 = LAN 9
10 = LAN 10
1 1= LAN Service

lloutData (I)

Specifies the size of the outData parameter.

OutData(O)

OutData (I)

reply: {
"replyCode": "xxxx" ,
"replyCodeDescription": "xxxx"
}
"content":
{
“lanParamValue” :”xxxx”

}

Or

{"content":{"lanPortStatus":"enable/disable","lanPortValue":"8xxx"},"reply":{"replyCode":"0","replyCodeDescription":"OK"}}}

Return Value

AR_OKAY
AR_UNIT_ALREADY_RESERVED
AR_UNIT_BUSY
AR_KO
Refer to chapter Reply codes of ArcadevInt for the full list and description of return codes.

ARCAsetCommunicationLAN

#include “ARCADevsvc.h”

Result API ARCAsetCommunicationLAN (**int** *hConnect,*
string ** inData,*
int lloutData**,**
string **outData)*;

Description

Parameters

hConnect (I)

Handle returned by ARCAConnect.

inData (I)

{
“lanParam” :”xxxx”
“lanParamValue” : “xxxx”

Or

“lanPort” : “xxxx” ,
“lanPortStatus” : “xxxx” ,
“lanPortValue” : “xxxx”
}

lanParam value :
“1” =DHCP
“2” =IP address (0.0.0.0 max 15 char)
“3”.=Subnet mask (0.0.0.0 max 15 char)
“4” =Gateway (0.0.0.0 max 15 char)
“5” =Device name (max 15 char)
“6” =Device description (max 50 char)
“7” =Primary DNS (0.0.0.0 max 15 char)
“8” =Secondary DNS (0.0.0.0 max 15 char)
“9” =Primary WINS (0.0.0.0 max 15 char)
“ 10”=Secondary WINS (0.0.0.0 max 15 char)
“11”= Use NetBios name
“12”= Username 802.1x (max 32 char)
“13”= Password 802.1x (max 32 char)

or
“whitelist” : This command is used to fill the authorized addresses list
{
“opType”: “xxxx” ,
“addressType” :”xxxx”
“address“ : “xxxx”
}

opType:
1=insert an address
2=delete an address
3=delete all addresses (all IP or all MAC)
addressType:
1=IP address

2=MAC address
address :
Address to insert or to delete. If op_type=3, this parameter is not required.
The IP address form is dot decimal (i.e. 172.19.11.76) while MAC address form is six group of two hex digit separated by hypens(-) (i.e. 00-13-8F-AD-11-BE)

Or
"lanPort" : It identifies the LAN number
1 = LAN 1
2 = LAN 2
3 = LAN 3
4 = LAN 4
5 = LAN 5
6 = LAN 6
7 = LAN 7
8 = LAN 8
9 = LAN 9
10 = LAN 10
1 1= LAN Service
"lanPortStatus" : "enable/disable"
"lanPortValue" : "es 8000"

lloutData (I)
Specifies the size of the outData parameter.

OutData(O)
OutData (I)

```
reply: {
"replyCode": "xxxx" ,
"replyCodeDescription": "xxxx"
}
```

Return value :

Return Value

AR_OKAY
AR_UNIT_ALREADY_RESERVED
AR_UNIT_BUSY
AR_KO
Refer to chapter Reply codes of ArcadevInt for the full list and description of return codes.

ARCAsetCassette

#include “ARCADevsvc.h”

Result API ARCAsetCassette(**int** *hConnect,*
string * *inData,*
int lloutData**,**
string **outData)*;

Description

Parameters

hConnect (I)

Handle returned by ARCAConnect.

inData (I)

JSON input data structure:

{

“configType *“ : “xxxx”*

“cassetteNumber” : “xxx”

}

Accepted values for configType*:*

“**cassetteNumber**” = With this command it is possible to get the number of the configured cassettes of the device.

“**protocolCassetteNumber**” = With this command it is possible to set the number of the cassettes used by communication protocol.

“**serviceProtocolCassetteNumber**”= With this command it is possible to set the number of the cassettes used by service communication protocol

lloutData (I)

Specifies the size of the outData parameter.

OutData(O)

reply: {
"replyCode": "xxxx" ,
"replyCodeDescription": "xxxx"
}

Return Value

AR_OKAY
AR_UNIT_ALREADY_RESERVED
AR_UNIT_BUSY
Refer to chapter Reply codes of ArcadevInt for the full list and description of return codes.

Comments

ARCAsetCassetteChangheKey

#include “ARCADevsvc.h”

Result API ARCAsetCassetteChangeKey(**int** *hConnect,*
string * *inData,*
int lloutData**,**
string **outData)*;

Description

Parameters

hConnect (I)

Handle returned by ARCAConnect.

inData (I)

JSON input data structure:

{

"cassette" : “xxxx”
"oldCode" : “xxxx” ,
newCode": “xxxx” ,

}

target-cassette = A÷”num_cas”
old-code = old key-code (6 ASCII-chars 0x20-0x7f)
new-code = new key-code (6 ASCII-chars 0x20-0x7f)

lloutData (I)

Specifies the size of the outData parameter.

OutData(O)

reply: {
"replyCode": "xxxx" ,
"replyCodeDescription": "xxxx"
}

Return Value

AR_OKAY
AR_UNIT_ALREADY_RESERVED
AR_UNIT_BUSY
Refer to chapter Reply codes of ArcadevInt for the full list and description of return codes.

Comments

ARCAsetLogServiceRecord

Result API ARCAsetLogServiceRecord(**int** *hConnect,*
string ** inData,*
int lloutData**,**
string **outData)*;

Description

Parameters

hConnect (I)

Handle returned by ARCAConnect.

inData (I)

JSON input data structure:

{

“nn1” : “xxxx” ,
“nn2” : “xxxx” ,
“nn3” : “xxxx” ,
“nn4” : “xxxx” ,
“nn5” : “xxxx” ,
“nn6” : “xxxx” ,
“nn7” : “xxxx” ,
“nn8” : “xxxx” ,
“nn9” : “xxxx” ,
“nna” : “xxxx” ,
“nnb” : “xxxx” ,
“nnc” : “xxxx” ,
“nnd” : “xxxx” ,
“nne” : “xxxx” ,
“nnf” : “xxxx” ,
“nng” : “xxxx” ,
“nnh” : “xxxx” ,
“nni” : “xxxx” ,
“nnj” : “xxxx” ,
“nnk” : “xxxx”

}

- Nn1-nnk = Hexadecimal data. (two Hex Ascii)
- CM18 /CM18E: nn1-nnb
- CM20E: nn1-nne
- CM18T: nn1-nnk

lloutData (I)

Specifies the size of the outData parameter.

OutData(O)

reply: {
"replyCode": "xxxx" ,
"replyCodeDescription": "xxxx"
}

Return Value

AR_OKAY
AR_UNIT_ALREADY_RESERVED
AR_UNIT_BUSY
Refer to chapter Reply codes of ArcadevInt for the full list and description of return codes.

Comments

ARCAsetCassetteDenomination

#include “ARCADevsvc.h”

Result API ARCAsetCassetteDenomination(**int** *hConnect,*
string ** inData,*
int lloutData**,**
string **outData)*;

Description

Parameters

hConnect (I)

Handle returned by ARCAConnect.

inData (I)

{
“cas_id”: Cassette id ‘A’- ‘num_cas' ,
“NrDenominationElements” : “xxx”,
“NrDenomination”: [
{ “denominationID”: “xxxx},
{ “denominationID”: “xxxx” },
{ “denominationID”: “xxxx”, },
….
}

cas_id= (4 ASCII-chars)
denominationID : Denomination (ex: EUCA) – Max 128

lloutData (I)

Specifies the size of the outData parameter.

OutData(O)

reply: {
"replyCode": "xxxx" ,
"replyCodeDescription": "xxxx"
}

Return value :

Return Value

AR_OKAY
AR_UNIT_ALREADY_RESERVED

AR_UNIT_BUSY
AR_KO
Refer to chapter Reply codes of ArcadevInt for the full list and description of return codes.

ARCAsetReaderSettings

#include “ARCADevsvc.h”

Result API ARCAsetReaderSettings(**int** *hConnect,*
string ** inData,*
int lloutData**,**
string **outData)*;

Description

Parameters

hConnect (I)

Handle returned by ARCAConnect.

inData (I)

{

“type”= “xxxx”

“bank_num” = “xxxx”
or
“*bank_to_act” = “xxxx”*
or
*“*enable_ref1” = “xxxx” ,
*“*enable_ref2” = “xxxx” ,
*“*enable_ref3” = “xxxx” ,
*“*enable_ref4” = “xxxx” ,
or
“slot” = “xxxx” ,
“bankId” , “xxxx”

}

Possible value for type : numBanks , activeBanks

numBanks = This command is used to select the bank of note identifier with which you want to work
parameter : “bank_num” = “Number of bank (0 or 15)

activeBanks = This command is used to select the number of active banks of note identifier that will work concurrently (if you want to work in SINGLE CURRENCY bank_to_act must be equal to zero (0) or more than 4 and if you want to work in MULTICURRENCY bank_to_act must be from 1 to 4).
Parameter : *“bank_to_act “ = Number of bank that you want to activate*

references = This command is used to temporary enable/disable references
parameter :
enable_ref1 = Reference n° 1 1: enabled / 0: disabled
enable_ref1 = Reference n° 2 1: enabled / 0: disabled
enable_ref1 = Reference n° 3 1: enabled / 0: disabled
enable_ref1 = Reference n° 4 1: enabled / 0: disabled

slot = This command is used to select the references that will be stored on the reader
parameter :
slot : destination of reader memory (0-3)
bankId = Reference bank number (0-16)

lloutData (I)
Specifies the size of the outData parameter.

OutData(O)

reply: {
"replyCode": "xxxx" ,
"replyCodeDescription": "xxxx"
}

Return value :

Return Value

AR_OKAY
AR_UNIT_ALREADY_RESERVED
AR_UNIT_BUSY
AR_KO
Refer to chapter Reply codes of ArcadevInt for the full list and description of return codes.

ARCAsetDeviceIdentification

#include “ARCADevsvc.h”

Result API ARCAsetDeviceIdentification(**int** *hConnect,*
string ** inData,*
int lloutData**,**
string **outData)*;

Description

Parameters

hConnect (I)

Handle returned by ARCAConnect.

inData (I)

{

*“*CMxxx” : “xxxx”

}

Possible values are:

- CM20
- CM18
- CM18T
- CM18E
- CM20E

lloutData (I)

Specifies the size of the outData parameter.

OutData(O)

reply: {
"replyCode": "xxxx" ,
"replyCodeDescription": "xxxx"
}

Return value :

Return Value

AR_OKAY
AR_UNIT_ALREADY_RESERVED
AR_UNIT_BUSY
Refer to chapter Reply codes of ArcadevInt for the full list and description of return codes.

ARCAsetDeviceSettings

#include “ARCADevsvc.h”

Result API ARCAsetDeviceSettings (**int** *hConnect,*
string ** inData,*
int lloutData**,**
string **outData)*;

Description

With this command it is possible to set some functionality parameters
Before settings the parameters it is necessary to read the configuration with ARCAgetDeviceSettings (ARCADevInt) and pass the same structure with the values changed

Parameters

hConnect (I)

Handle returned by ARCAConnect.

inData (I)

```
{
 "content": {
        "Config": {
        "viewDateTimeOnDisplay": "true/false",
        "balancedCassetteHandling": "true/false",
        "alarm1Handling": "true/false",
         "delayClassDispensing": "true/false",
         "viewDateTimeOnDisplayInFormatAMandPM": "true/false",
         "useUnfitinSafe": "true/false",
         "enableJournallog": "true/false"
         },
         "OptionConfig": {
         "specialCleanWithoutControl": "true/false",
         "specialAlarmMode": "true/false",
        "simplifiedProtocol": "true/false",
         "executeCloseCommandAlsoInJam": "true/false"
        },
         "OptionOneConfig": {
         "forceRecoveryWithTestCommand": "true/false",
         "donotremovecassettejamifspecialcleanON": "true/false",
        "lanTimeout": "true/false",
        "timeControlDispenseamount": "true/false",
         "enableBookingExternalButton": "true/false"
         },
         "OptionTwoConfig": {
         "safeCen40Bit": "true/false",
         "bvuSynchronousHandling": "true/false",
         "faceOrientationHandling": "true/false",
         "specialCleanUsingDisplay": "true/false",
         "cat2BoxHandling": "true/false",
        "evoLedHandling": "true/false",
         "separateCat2andCat3": "true/false",
         "feedBanknoteswithInputBinFree": "true/false",
         "differentCenterAUDbn": "true/false",
        "disableMessageonDisplay": "true/false",
         "alarm2OutputHandling": "true/false",
```

```
                    "remapFeederJamtoMissfeeding": "true/false",
                    "virtualDestkopEnvironment": "true/false",
                   "handlingNewLedSide": "true/false",
                    "disableCM18evoLedPulse": "true/false"
                    }
        }
}
```

lloutData (I)

Specifies the size of the outData parameter.

OutData(O)

```
                                reply: {
                   "replyCode": "xxxx" ,
                   "replyCodeDescription": "xxxx"
                   }
```

Return value :

Return Value

AR_OKAY
AR_UNIT_ALREADY_RESERVED
AR_UNIT_BUSY
Refer to chapter Reply codes of ArcadevInt for the full list and description of return codes.

ARCAgetShiftCenterSettings

#include “ARCADevsvc.h”

Result API ARCAgetShiftCenterSettings(**int** *hConnect,*
string * inData,*
int lloutData**,**
string **outData)*;

Description

With this command it is possible to get the centering value of the bankonote on output slot

Parameters

hConnect (I)

Handle returned by ARCAConnect.

inData (I)

no input data

lloutData (I)

Specifies the size of the outData parameter.

OutData(O)

{
reply: {
"replyCode": "xxxx" ,
"replyCodeDescription": "xxxx"
}
"content": {
“*centeringValue*”: “xxx”
}
}

Return value :

Return Value

AR_OKAY
AR_UNIT_ALREADY_RESERVED
AR_UNIT_BUSY
Refer to chapter Reply codes of ArcadevInt for the full list and description of return codes.

ARCAsetShiftCenterSettings

#include “ARCADevsvc.h”

Result API ARCAsetShiftCenterSettings(**int** *hConnect,*
string ** inData,*
int lloutData**,**
string **outData)*;

Description

With this command it is possible to get the centering value of the bankonote on output slot

Parameters

hConnect (I)

Handle returned by ARCAConnect.

inData (I)

{
“*centeringValue*”: “xxx”
}

centeringValue =centering value between the range 55 -78 (default 65)

lloutData (I)

Specifies the size of the outData parameter.

OutData(O)

{
reply: {
"replyCode": "xxxx" ,
"replyCodeDescription": "xxxx"
}
}
}

Return value :

Return Value

AR_OKAY
AR_UNIT_ALREADY_RESERVED
AR_UNIT_BUSY
Refer to chapter Reply codes of ArcadevInt for the full list and description of return codes

ARCAsetDeviceProtocolType

#include “ARCADevsvc.h”

Result API ARCAsetDeviceProtocolType(**int** *hConnect,*
string ** inData,*
int lloutData**,**
string **outData)*;

Description

With this command it is possible to get the centering value of the bankonote on output slot

Parameters

hConnect (I)

Handle returned by ARCAConnect.

inData (I)

{
" “protocolSet" : "xxxx"
}

protocolSet accetped value : STANDARD / SIMPLIFIED

lloutData (I)

Specifies the size of the outData parameter.

OutData(O)

reply: {
"replyCode": "xxxx" ,
"replyCodeDescription": "xxxx"
}

Return value :

Return Value

AR_OKAY
AR_UNIT_ALREADY_RESERVED
AR_UNIT_BUSY
Refer to chapter Reply codes of ArcadevInt for the full list and description of return codes.

ARCAgetInputSetting

#include “ARCADevsvc.h”

Result API ARCAgetInputSetting (**int** *hConnect,*
string * *inData,*
int lloutData**,**
string **outData)*;

Description

With this command it is possible to get the number banknote on output slot during the operation of counting

Parameters

hConnect (I)

Handle returned by ARCAConnect.

{

*“*configType*“ : “xxxx” ,*

}

Accepted values for configType*:*

“BundleSize”

lloutData (I)

Specifies the size of the outData parameter.

OutData(O)

{

reply: {

"replyCode": "xxxx" ,

"replyCodeDescription": "xxxx"

}

"content": {

“bundleSize”: “xxx”

}

}

Return Value

AR_OKAY

AR_UNIT_ALREADY_RESERVED

AR_UNIT_BUSY

Refer to chapter Reply codes of ArcadevInt for the full list and description of return codes.

ARCAsetInputSetting

#include “ARCADevsvc.h”

Result API `ARCAsetInputSetting` (**int** *hConnect,*
string * *inData,*
int lloutData**,**
string **outData)*;

Description

With this command it is possible to set the number of banknotes in output slot during a counting operation (the default is 200)

Parameters

hConnect (I)

Handle returned by ARCAConnect.

{

*“*configType*” : “*countingBundleSize*” ,*

*“*numnotes” : “xxx”

}

lloutData (I)

Specifies the size of the outData parameter.

OutData(O)

{

reply: {

"replyCode": "xxxx" ,

"replyCodeDescription": "xxxx"

}

}

}

Return Value

AR_OKAY

AR_UNIT_ALREADY_RESERVED

AR_UNIT_BUSY

Refer to chapter Reply codes of ArcadevInt for the full list and description of return codes.

ARCAsetDeviceSerialNumber

#include “ARCADevsvc.h”

Result API `ARCAsetDeviceSerialNumber` (**int** *hConnect,*
string ** inData,*
int lloutData**,**
string **outData)*;

Description

This command is used to fill the serial number to the machine stored in controller

Parameters

hConnect (I)

Handle returned by ARCAConnect.

{

*“*serialNumber *” : “*xxxx*” ,*

}

lloutData (I)

Specifies the size of the outData parameter.

OutData(O)

{
reply: {
"replyCode": "xxxx" ,
"replyCodeDescription": "xxxx"
}
}
}

Return Value

AR_OKAY
AR_UNIT_ALREADY_RESERVED
AR_UNIT_BUSY
Refer to chapter Reply codes of ArcadevInt for the full list and description of return codes.

ARCAsetAudioSettings

#include “ARCADevsvc.h”

Result API ARCAsetAudioSettings(**int** *hConnect,*
string ** inData,*
int lloutData**,**
string **outData)*;

Description

This command is used to fill the audio configuration parameters

Parameters

hConnect (I)

Handle returned by ARCAConnect.

inData (I)

JSON input data structure:

{

*“*audioValue *” : “xxxx”*

}

audioValue (0-65535)

lloutData (I)

Specifies the size of the outData parameter.

OutData(O)

reply: {
"replyCode": "xxxx" ,
"replyCodeDescription": "xxxx"
}

Return value :

Return Value

AR_OKAY
AR_UNIT_ALREADY_RESERVED
AR_UNIT_BUSY
AR_KO
Refer to chapter Reply codes of ArcadevInt for the full list and description of return codes.

ARCAgetOperatingHours

#include “ARCADevsvc.h”

Result API `ARCAgetOperatingHours` (**int** *hConnect,*
string ** inData,*
int lloutData**,**
string **outData)*;

Description

With this command is possible to get the Periodic operating hour filled

Parameters

hConnect (I)

Handle returned by ARCAConnect.

{

“operatingHoursType” = “xxxx” ,

“weekDay *“ : “xxxx” ,*

Or
“day : "xxx"
“month” : “xxxx” ,
“year” : “xxxx”

}

operatingHoursType = **periodic** , **aperiodic**

in case of **periodic** :
weekDay = Week day setted, (Monday, Tuesday, …).

*in case of **aperiodic** :*
day = Day of month (1-31)
month = (1-12)
year = es: 2003 == 03

lloutData (I)

Specifies the size of the outData parameter.

OutData(O)

{
In case of Periodic
{
content :
{"day":"XX","lunchBreakOff":"xx:xx","lunchBreakOn":"xx:xx","switchOff":"xx:xx","switchOn":"xx:xx"}
reply : {"replyCode":"0","replyCodeDescription":"OK"}
}
In case of Aperiodic
{
content :
{"day":"xx","lunchBreakOff":"xx:xx","lunchBreakOn":"xx:xx","month":"xx","swit

chOff":"xx:xx","switchOn":"xx:xx","year":"xx"}
reply : {"replyCode":"0","replyCodeDescription":"OK"}
}

}

Return Value

AR_OKAY
AR_UNIT_ALREADY_RESERVED
AR_UNIT_BUSY
Refer to chapter Reply codes of ArcadevInt for the full list and description of return codes.

ARCAsetOperatingHours

#include “ARCADevsvc.h”

Result API `ARCAsetOperatingHours` (**int** *hConnect,*
string ** inData,*
int lloutData**,**
string **outData)*;

Description

With this command is possible to get the Periodic operating hour filled

Parameters

hConnect (I)

Handle returned by ARCAConnect.

{

{

In case of ***periodic***

`weekDay` *: "xx" ,*
lunchBreakOff : "xx:xx" ,
lunchBreakOn : "xx:xx" ,
operatingHoursType : "periodic" ,
switchOff : "xx:xx" ,
switchOn : "xx:xx"

in case of ***aperiodic***

day : "xx"
lunchBreakOff : "xx:xx",
lunchBreakOn : "xx:x"
month : "xx"
operatingHoursType : "aperiodic"
switchOff : "xx:xx"
switchOn : "xx:xx"
year : "xx"

}

}

in case of periodic :

weekDay = Week day setted, (Monday, Tuesday, …).

in case of aperiodic :
day = Day of month (1-31)
month = (1-12)
year = es: 2003 == 03

lloutData (I)

Specifies the size of the outData parameter.

OutData(O)

{
content :
reply : {"replyCode":"0","replyCodeDescription":"OK"}}

Return Value

AR_OKAY
AR_UNIT_ALREADY_RESERVED
AR_UNIT_BUSY
Refer to chapter Reply codes of ArcadevInt for the full list and description of return codes.

ARCAsetReaderThreshold

#include “ARCADevsvc.h”

Result API `ARCAsetReaderThreshold` (**int** *hConnect,*
string ** inData,*
int lloutData**,**
string **outData)*;

Description

Parameters

hConnect (I)

Handle returned by ARCAConnect.

{

*“*configType *“ : “xxxx” ,*

*“*bankId” : “xxx”

*“*fitFlag” : “xxxx”

“fitThresholdFitness” : “xxxx”

}

*“*bankId” = Reference bank number (0-15)

configType accetpted parameter : **fitConfiguration** , **fitThreshold**

in case of fitConfiguration the parameter **fitFlag** is Fit Handling Flag (0= Fitness Enabled , 1= Always FIT)

in case of fitThreshold the parameter **fitThresholdFitness** is the Threshold Fitness ID (0-2)

lloutData (I)

Specifies the size of the outData parameter.

OutData(O)

{
reply: {
"replyCode": "xxxx" ,
"replyCodeDescription": "xxxx"
}
}

}

Return Value

AR_OKAY
AR_UNIT_ALREADY_RESERVED
AR_UNIT_BUSY
Refer to chapter Reply codes of ArcadevInt for the full list and description of return codes.

ARCAgetTimeZone

#include “ARCADevsvc.h”

Result API ARCAgetTimeZone (**int** *hConnect,*
string ** inData,*
int lloutData**,**
string **outData)*;

Description

With this command it is possible to get the Time Zone Time configuration parameters

Parameters

hConnect (I)

Handle returned by ARCAConnect.

inData (I)

NO imput data , set to NULL

lloutData (I)

Specifies the size of the outData parameter.

OutData(O)

content : {"timeZoneIndex":"xxx"}

reply : {"replyCode":"xxxx","replyCodeDescription":"xxx"}

timeZoneIndex = refer to file arca_timezone.json to get the value

Return value :

Return Value

AR_OKAY
AR_UNIT_ALREADY_RESERVED
AR_UNIT_BUSY
Refer to chapter Reply codes of ArcadevInt for the full list and description of return codes.

ARCAsetTimeZone

#include “ARCADevsvc.h”

Result API ARCAsetTimeZone (**int** *hConnect,*
string * *inData,*
int lloutData**,**
string **outData)*;

Description

This command is used to fill the Time Zone Time parameters

Parameters

hConnect (I)

Handle returned by ARCAConnect.

inData (I)

{
"timeZoneIndex": "14"
}

timeZoneIndex = refer to file arca_timezone.json to get the value

lloutData (I)

Specifies the size of the outData parameter.

OutData(O)

reply : {"replyCode":"xxxx","replyCodeDescription":"xxx"}

Return value :

Return Value

AR_OKAY
AR_UNIT_ALREADY_RESERVED
AR_UNIT_BUSY
Refer to chapter Reply codes of ArcadevInt for the full list and description of return codes.

ARCAsetCommunicationsUsb

#include “ARCADevsvc.h”

Result API ARCAsetCommunicationsUsb (**int** *hConnect,*
string * *inData,*
int lloutData**,**
string **outData)*;

Description

With this command is possible to enable/disable the USB ports.

Parameters

hConnect (I)

Handle returned by ARCAConnect.

inData (I)

{
portUsb : "xxx"
statusUsb : "enable/disable"
}

portUsb = It identifies the port USB number 1 = USB Host 1 2 = USB Host 2 3 = USB Host 3 (Service) Possible value are : 1 - CM18Solo 1 or 2 - C6060 1,2 or 3 - Others unit type

lloutData (I)

Specifies the size of the outData parameter.

OutData(O)

reply : {"replyCode":"xxxx","replyCodeDescription":"xxx"}

Return value :

Return Value

AR_OKAY
AR_UNIT_ALREADY_RESERVED
AR_UNIT_BUSY
Refer to chapter Reply codes of ArcadevInt for the full list and description of return codes.

ARCAgetCommunicationsUsb

#include “ARCADevsvc.h”

Result API ARCAgetCommunicationsUsb (**int** *hConnect,*
string * *inData,*
int lloutData**,**
string **outData)*;

Description

: With this command it is possible to get the USB status (enable or disable)

Parameters

hConnect (I)

Handle returned by ARCAConnect.

inData (I)

{
portUsb : "xxx"
}

portUsb = It identifies the port USB number 1 = USB Host 1 2 = USB Host 2 3 = USB Host 3 (Service) Possible value are : 1 - CM18Solo 1 or 2 - C6060 1,2 or 3 - Others unit type

lloutData (I)

Specifies the size of the outData parameter.

OutData(O)

{
{"content":{"statusUsb":"xxxx"},"reply":{"replyCode":"xxxx","replyCodeDescription":"xxxx"}}}

Return value :

Return Value

AR_OKAY
AR_UNIT_ALREADY_RESERVED
AR_UNIT_BUSY
Refer to chapter Reply codes of ArcadevInt for the full list and description of return codes.

ARCAsetCommunicationsSerial

#include “ARCADevsvc.h”

Result API ARCAsetCommunicationsSerial (**int** *hConnect,*
string * *inData,*
int lloutData**,**
string **outData)*;

Description

Parameters

hConnect (I)

Handle returned by ARCAConnect.

inData (I)

{

portSerial: "xxx"

statusSerial: "enable/disable"

}

portSerial : Possible values:

- *A – Serial port A*
  B – Serial port B

statusSerial : Possible values:

“off” , “peripheral” , “host”

lloutData (I)

Specifies the size of the outData parameter.

OutData(O)

reply : {"replyCode":"xxxx","replyCodeDescription":"xxx"}

Return value :

Return Value

AR_OKAY
AR_UNIT_ALREADY_RESERVED
AR_UNIT_BUSY

Refer to chapter Reply codes of ArcadevInt for the full list and description of return codes

ARCAgetDevicePhotoNovus

#include “ARCADevsvc.h”

Result API ARCAgetDevicePhotoNovus (**int** *hConnect,*
string ** inData,*
int lloutData**,**
string **outData)*;

Description

Parameters

hConnect (I)

Handle returned by ARCAConnect.

{
“targetModule “ : “xxxx” ,
“phId” : “xxx”
}

targetModule parameter **:** all , …
“
phId” in case of all

- “upper” for upper part sensor , no bins
- **“**lower” for lower part sensor
- “bins” for all bins sensor

lloutData (I)

Specifies the size of the outData parameter.

OutData(O)

{
content : {"0":
{"agc":"X","current":"xxx",
"phId":"namePhoto(es syncTrvL)” ,
,"resultCode":"xxx",
"resultDescription":"xxx",
"threshold":"xxx"}
, *"xx":{"agc":"0"*
,"current":"xxx",
"phId":"namePhoto",
"resultCode":"xxx",
"resultDescription":"xxx"
, *"threshold":"xxx"}*
reply : {"replyCode":"xxx",
"replyCodeDescription":"xxx"}
}

Return Value

AR_OKAY
AR_UNIT_ALREADY_RESERVED
AR_UNIT_BUSY
Refer to chapter Reply codes of ArcadevInt for the full list and description of return codes

Coin Section

ARCAgetCoinCashData

#include “ARCADevsvc.h”

Result API ARCAgetCoinCashData(**int** *hConnect,*
string * inData,*
int lloutData**,**
string *outData)*;

Description

Parameters

hConnect (I)

Handle returned by ARCAConnect.

{

*“*operationType *“ : “xxxx”*

}

operationTypeaccetpted parameter : **dispensedAmount**, **availableAmount**

lloutData (I)

Specifies the size of the outData parameter.

OutData(O)

{
content : {"availableAmount":"xxx"}
reply : {"replyCode":"xxx","replyCodeDescription":"xxx"}
}
Or
{
content : {"dispensedAmount":""}
reply : {"replyCode":"xxx","replyCodeDescription":"xxx"}
}

Return Value

AR_OKAY
AR_UNIT_ALREADY_RESERVED
AR_UNIT_BUSY
Refer to chapter Reply codes of ArcadevInt for the full list and description of return codes.

ARCACoinInventory

#include “ARCADevsvc.h”

Result API ARCACoinInventory (**int** *hConnect,*
string * *inData,*
int lloutData**,**
string **outData)*;

Description

Parameters

hConnect (I)

Handle returned by ARCAConnect.

{

*“*operationType *“ : “xxxx”*

amount : "xxx"

}

operationTypeaccetpted parameter : **load**, **clear**

clear : With this command it is possible to reset the total amount of the Coin Dispenser stored on the device. The same command resets the counters of the amount exempted for each side (or operator).

Load : With this command it is possible to store the amount loaded in the Coin Dispenser in the device.
amount : "xxx" = Amount deposited. The sum should be specified without a decimal point. ".". The last two digits will be treated as decimals. Example: 123 means 1 dollar and 23 cents; 12,300 means $ 123.

lloutData (I)

Specifies the size of the outData parameter.

OutData(O)

{

reply : {"replyCode":"xxx","replyCodeDescription":"xxx"}

}

Return Value

AR_OKAY
AR_UNIT_ALREADY_RESERVED
AR_UNIT_BUSY

Refer to chapter Reply codes of ArcadevInt for the full list and description of return codes

ARCACoinDispense

#include “ARCADevsvc.h”

Result API ARCACoinDispense (**int** *hConnect,*
string ** inData,*
int lloutData**,**
string **outData)*;

Description

Parameters

hConnect (I)

Handle returned by ARCAConnect.

{

*“*operationType *“ : “xxxx”*

amount : "xxx"
or
{
coinToDispense :
[{"denominationID":"xxx","value":xxx"}
,{"denominationID":"xxx","value":"xxxx ,
…..

denominationID":"xxx","value":"xxxx"}]
}

}

operationTypeaccetpted parameter **: amount**, ***denomination***

***amount*:** With this command it is possible to obtain dispence by amount

denomination = Every de nomination that belong to **den_list** is composed from a couple of numbers. Therefore, it can take values from **00** to **99**. If the command contains only a name consisting of more than two digits, this is not executed. The same applies if one or more names are expressed with less than 2 digits. Each name is separated by a comma ",".
The names are sorted in descending order

lloutData (I)

Specifies the size of the outData parameter.

OutData(O)

{
reply : {"replyCode":"xxx","replyCodeDescription":"xxx"}
}

Return Value

AR_OKAY
AR_UNIT_ALREADY_RESERVED
AR_UNIT_BUSY
Refer to chapter Reply codes of ArcadevInt for the full list and description of return codes

ARCAgetCoinConfiguration

#include “ARCADevsvc.h”

Result API ARCAgetCoinConfiguration (**int** *hConnect,*
string * inData,*
int lloutData**,**
string *outData)*;

Description

Parameters

hConnect (I)

Handle returned by ARCAConnect.

{

*“*coinParamId *“ : “xxxx”*

}

coinParamId :

“0”: Coin denomination for hopper 0

……...

“7”: Coin denomination for hopper 7

“d”: Value of the notes below (in cents)

“a”: List of all parameters + dispense below + type canister

“t”: Type canister (USA, Canada, etc…)

lloutData (I)

Specifies the size of the outData parameter.

OutData(O)

In case 0 to 7 or d

{

content : {"coinParamValue":"xxx"}

reply : {"replyCode":"xxx","replyCodeDescription":"xxx"}

}

In case of a

{

content :

{"den0":"xxx",

"den1":"xxx"

"den2""xxx",

"den3":"xxx",

"den4":"xxx",

"den5":"xxx",

"den6":"xxx"

,"den7 ":"xxx"}

reply : {"replyCode":"xxx","replyCodeDescription":"xxx"}

}

Return Value

AR_OKAY
AR_UNIT_ALREADY_RESERVED
AR_UNIT_BUSY
Refer to chapter Reply codes of ArcadevInt for the full list and description of return codes