## DTC U0422:68 [INSTRUMENT CLUSTER]

id0902e8950800

System malfunction location	Error signal received from front body control module (FBCM)		
Detection	• The instrument cluster receives error signals from the front body control module (FBCM) for <b>5 s or</b>		
condition	more with the ignition switched ON (engine off or on).		
Fail-safe	_		
Possible cause	DTCs are stored in the front body control module (FBCM).		
Possible cause	Instrument cluster malfunction		
System wiring	<u>_</u>		
diagram	_		

**Diagnostic Procedure** 

Diagnostic Procedure					
Step	Inspection		Action		
1	VERIFY INSTRUMENT CLUSTER DTCs	Yes	Repair the malfunctioning part according to the applicable		
	• Perform the DTC inspection for the instrument		DTC troubleshooting.		
	cluster using the M-MDS.		(See DTC TABLE [INSTRUMENT CLUSTER].)		
	(See DTC INSPECTION [INSTRUMENT	No	Go to the next step.		
	CLUSTER].)				
	Is the DTC displayed?				
2	VERIFY FRONT BODY CONTROL MODULE	Yes	Repair the malfunctioning part according to the applicable		
	(FBCM) DTCs		DTC troubleshooting.		
	Perform the DTC inspection for the front body		(See DTC TABLE [FRONT BODY CONTROL MODULE		
	control module (FBCM) using the M-MDS.		(FBCM)].)		
	(See DTC INSPECTION [FRONT BODY	No	Go to the next step.		
	CONTROL MODULE (FBCM)].)				
	Is the DTC displayed?				
3	VERIFY THAT REPAIRS HAVE BEEN	Yes	Replace the instrument cluster, then go to the next step.		
	COMPLETED		(See INSTRUMENT CLUSTER REMOVAL/		
	Clear DTC for the instrument cluster using the		INSTALLATION.)		
	M-MDS.	No	Go to the next step.		
	(See CLEARING DTC [INSTRUMENT				
	CLUSTER].)				
	Switch the ignition ON (engine off or on) and				
	wait for 20 s or more.				
	Perform the DTC inspection for the instrument				
	cluster using the M-MDS.				
	(See DTC INSPECTION [INSTRUMENT				
	CLUSTER].)				
4	• Is the DTC U0422:68 displayed?	\/	Description and the condition of the condition to the condition to		
4	VERIFY IF OTHER DTCs DISPLAYED	Yes	Repair the malfunctioning part according to the applicable		
	Are any other DTCs displayed?		DTC troubleshooting.		
		NI-	(See DTC TABLE [INSTRUMENT CLUSTER].)		
		No	DTC troubleshooting completed.		