## i-stop OFF SWITCH REMOVAL/INSTALLATION [SKYACTIV-G 2.0, SKYACTIV-G 2.5]

id0140g2888800

## Note

- The i-stop OFF switch is integrated with the cluster switch.
  For the cluster switch removal/installation, refer to "SWITCH PANEL REMOVAL/INSTALLATION" because the cluster switch is installed to the switch panel. (See SWITCH PANEL REMOVAL/INSTALLATION.)