DTC U2101:00 [FORWARD SENSING CAMERA (FSC)]

id0902p9030700

System malfunction location	Forward sensing camera (FSC) configuration error		
Detection condition	Detects that forward sensing camera (FSC) has unsupported configuration data.		
Fail-safe	Fail-safe • Inhibits the lane departure warning system (LDWS). • Inhibits the high beam control system (HBC).		
Possible cause	Forward sensing camera (FSC) configuration error		
System wiring diagram	_		

Diagnostic Procedure				
Step	Inspection		Action	
1	PERFORM FORWARD SENSING CAMERA (FSC) CONFIGURATION (USING AS-BUILT DATA) • Using the M-MDS, perform the forward sensing camera (FSC) configuration with the As-Built data. (See FORWARD SENSING CAMERA (FSC) CONFIGURATION (USING AS-BUILT DATA).) • Clear the forward sensing camera (FSC) DTCs using the M-MDS. (See CLEARING DTC [FORWARD SENSING CAMERA (FSC)].) • Perform the DTC inspection for the forward sensing camera (FSC) using the M-MDS. (See DTC INSPECTION [FORWARD SENSING CAMERA (FSC)].) • Is DTC U2101:00 displayed?	Yes	Perform the configuration of the forward sensing camera (FSC) using the As-Built data again, then go to the next step. (See FORWARD SENSING CAMERA (FSC) CONFIGURATION (USING AS-BUILT DATA).)	
		No	Go to Step 3.	
2	VERIFY THAT REPAIRS HAVE BEEN COMPLETED • Clear the forward sensing camera (FSC) DTCs using the M-MDS. (See CLEARING DTC [FORWARD SENSING CAMERA (FSC)].) • Perform the DTC inspection for the forward sensing camera (FSC) using the M-MDS. (See DTC INSPECTION [FORWARD SENSING CAMERA (FSC)].) • Is DTC U2101:00 displayed?	Yes	Replace the forward sensing camera (FSC), then go to the next step. (See FORWARD SENSING CAMERA (FSC) REMOVAL/INSTALLATION.)	
		No	Go to the next step.	
3	• Are any other DTCs displayed?	Yes	Repair the malfunctioning part according to the applicable DTC troubleshooting. (See DTC TABLE [FORWARD SENSING CAMERA (FSC)].) DTC troubleshooting completed.	
		1,10	15 to desiconoung completed.	