## DTC P0615:00 [SKYACTIV-D 2.2]

id0102s4061500

DTC P0615:00	Starter relay circuit problem		
DETECTION CONDITION	<ul> <li>The PCM records DTCs when the number of times the engine has been started reaches the warrantied performance frequency for the starter or starter relay.</li> <li>Diagnostic support note</li> <li>This is a continuous monitor (other).</li> <li>The check engine light does not illuminate.</li> <li>FREEZE FRAME DATA (Mode 2)/Snapshot data is not available.</li> <li>DTC is stored in the PCM memory.</li> </ul>		
FAIL-SAFE FUNCTION	Not applicable		
POSSIBLE CAUSE	relay (180 000 times)		
SYSTEM WIRING DIAGRAM	Not applicable		

**Diagnostic Procedure** 

STEP	INSPECTION		ACTION
1	VERIFY RELATED SERVICE INFORMATION	Yes	Perform repair or diagnosis according to the available
	AVAILABILITY		Service Information.
	<ul> <li>Verify related Service Information availability.</li> </ul>		If the vehicle is not repaired, go to the next step.
	Is any related Service Information available?	No	Go to the next step.
2	REPLACE STARTER AND STARTER RELAY	_	Go to the next step.
	Switch the ignition off.		
	Replace the starter and starter relay.		
	(See STARTER REMOVAL/INSTALLATION		
	[SKYACTIV-D 2.2].)		
3	VERIFY DTC TROUBLESHOOTING	Yes	Replace the PCM, then go to the next step.
	COMPLETED		(See PCM REMOVAL/INSTALLATION [SKYACTIV-D 2.2].)
	Clear the DTC from the PCM memory using the	No	Go to the next step.
	M-MDS.		
	(See AFTER REPAIR PROCEDURE		
	[SKYACTIV-D 2.2].)		
	Start the engine and warm it up completely.		
	Perform the DTC Reading Procedure.		
	(See ON-BOARD DIAGNOSTIC TEST		
	[SKYACTIV-D 2.2].)		
	Is the same DTC present?		0 4 4 5 5 6
4	VERIFY AFTER REPAIR PROCEDURE	Yes	Go to the applicable DTC inspection.
	Perform the "AFTER REPAIR PROCEDURE".		(See DTC TABLE [SKYACTIV-D 2.2].)
	(See AFTER REPAIR PROCEDURE	No	DTC troubleshooting completed.
	[SKYACTIV-D 2.2].)		
1	<ul><li>Are any DTCs present?</li></ul>		