i-stop OFF SWITCH REMOVAL/INSTALLATION [SKYACTIV-D 2.2]

id0140z7888800

Note

- The i-stop OFF switch is integrated with the cluster switch.
 For the cluster switch removal/installation, refer to "SWITCH PANEL REMOVAL/INSTALLATION" because the cluster switch is installed to the switch panel. (See SWITCH PANEL REMOVAL/INSTALLATION.)