## DTC B10A5:49 [REAR BODY CONTROL MODULE (RBCM)]

id0902p4013400

| System<br>malfunction<br>location | Theft-deterrent siren internal malfunction  |  |
|-----------------------------------|---|--|
| Detection condition               | • Rear body control module (RBCM) detects theft-deterrent siren internal malfunction for <b>1.5 s or more</b> . |  |
| Fail-safe                         | _   |  |
| Possible cause                    | Theft-deterrent siren malfunction     Rear body control module (RBCM) malfunction                               |  |
| System wiring diagram             | _   |  |

| Step | tic Procedure Inspection  | Action |   |
|------|---|--------|---|
| 1    | VERIFY REAR BODY CONTROL MODULE                                   | Yes    | Go to the next step.  |
|      | (RBCM) DTCs AGAIN   | No     | Go to Step 4.   |
|      | Clear rear body control module (RBCM) DTCs                        |        |   |
|      | using the M-MDS.  |        |   |
|      | (See CLEARING DTC [REAR BODY                                      |        |   |
|      | CONTROL MODULE (RBCM)].)  |        |   |
|      | Switch the ignition ON (engine on) and wait for                   |        |   |
|      | 3 s or more.  |        |   |
|      | Perform the DTC inspection for the rear body                      |        |   |
|      | control module (RBCM) using the M-MDS.                            |        |   |
|      | (See DTC INSPECTION [REAR BODY                                    |        |   |
|      | CONTROL MODULE (RBCM)].)  |        |   |
|      | • Is DTC B10A5:49 displayed?                                      | \/ ·   | 0.1.1   |
| 2    | INSPECT THEFT-DETERRENT SIREN                                     | Yes    | Go to the next step.  |
|      | Inspect the theft-deterrent siren.     (See THEFT-DETERRENT SIREN | No     | Replace the theft-deterrent siren, then go to the next step |
|      | INSPECTION.)  |        | (See THEFT-DETERRENT SIREN REMOVAL/<br>INSTALLATION.)       |
|      | • Is the theft-deterrent siren normal?                            |        | INSTALLATION.)  |
| 3    | VERIFY THAT REPAIRS HAVE BEEN                                     | Yes    | Replace the rear body control module (RBCM), then go to     |
| Ü    | COMPLETED   | . 00   | the next step.  |
|      | Clear rear body control module (RBCM) DTCs                        |        | (See REAR BODY CONTROL MODULE (RBCM)                        |
|      | using the M-MDS.  |        | REMOVAL/INSTALLATION.)                                      |
|      | (See CLEARING DTC [REAR BODY                                      | No     | Go to the next step.  |
|      | CONTROL MODULE (RBCM)].)  |        | '   |
|      | Switch the ignition ON (engine on) and wait for                   |        |   |
|      | 3 s or more.  |        |   |
|      | <ul> <li>Perform the DTC inspection for the rear body</li> </ul>  |        |   |
|      | control module (RBCM) using the M-MDS.                            |        |   |
|      | (See DTC INSPECTION [REAR BODY                                    |        |   |
|      | CONTROL MODULE (RBCM)].)  |        |   |
|      | Is DTC B10A5:49 displayed?  |        |   |
| 4    | VERIFY IF OTHER DTCs DISPLAYED                                    | Yes    | Repair the malfunctioning part according to the applicable  |
|      | <ul> <li>Are any other DTCs displayed?</li> </ul>                 |        | DTC troubleshooting.  |
|      |   |        | (See DTC TABLE [REAR BODY CONTROL MODULE                    |
|      |   |        | (RBCM)].)   |
|      |   | No     | DTC troubleshooting completed.                              |