
CHARGE AIR COOLER REMOVAL/INSTALLATION [SKYACTIV-D 2.2]

id0113z7705900

- 1. Disconnect the negative battery cable. (See NEGATIVE BATTERY CABLE DISCONNECTION/CONNECTION [SKYACTIV-D 2.2].)
- Remove the front bumper. (See FRONT BUMPER REMOVAL/INSTALLATION.)
- 3. Remove in the order shown in the figure.
- 4. Install in the reverse order of removal.




1	Charge air cooler outlet pipe
2	Charge air cooler inlet nine

2 | Charge air cooler inlet pipe

Charge air cooler (See Charge Air Cooler Installation Note.)

Charge Air Cooler Installation Note

1. Temporarily install the bolts and nuts shown in the diagram.



Tighten the charge air cooler in the order shown in the figure.

