## QUICK DIAGNOSIS CHART [FW6A-EL, FW6AX-EL]

id050317100400

																							15031	1710	
																						X: /	APF	PLI	EΓ
VEHICLE DOES NOT MOVE IN D. M OR R POSITION	Т										Π				Х	Х	Х						П		_
VEHICLE MOVES IN P POSITION, OR																									
PARKING GEAR DOES NOT DISENGAGE																Х									
WHEN P IS DISENGAGED																									
EXCESSIVE CREEP				Χ																					
NO CREEP AT ALL				Χ											Х										
LOW MAXIMUM SPEED AND POOR ACCELERATION		Х	Х		Χ							Х										П			
NO SHIFTING		Х	Х					Х	Х	Х	Х	Х	Х									Т	П		_
DOES NOT SHIFT TO 5GR OR 6GR	$\top$	_	Х					Х	Х	Х	Х	_										$\vdash$	П		_
ABNORMAL SHIFTING	X	_	Х					-	Х	Х	Х	_	x												_
FREQUENT SHIFTING	+							, ·			X	_										_			_
SHIFT POINT IS HIGH OR LOW	X							~	Х	Х	X	_	Х									$\vdash$	H		_
	<u> </u>							^	^	^	_	_	^									$\vdash$	H		_
NO KICKDOWN ENGINE FLARES UP OR SLIPS	-											Х										$\vdash$			_
WHEN UPSHIFTING OR DOWNSHIFTING			X									Х													Х
JUDDER UPON TORQUE CONVERTER			Н																			$\vdash$	$\vdash$		
CLUTCH (TCC) OPERATION		Χ										Х			Х										
EXCESSIVE SHIFT SHOCK FROM N TO D OR				_																		Т			_
N TO R POSITION				Χ								Х								X					Х
EXCESSIVE SHIFT SHOCK IS FELT												Х													Х
WHEN UPSHIFTING AND DOWNSHIFTING												^													_
EXCESSIVE SHIFT SHOCK ON												Х			Х										Х
TORQUE CONVERTER CLUTCH (TCC) NOISE OCCURS AT IDLE	-																					$\vdash$			_
WHEN VEHICLE IS STOPPED					х									х	Х										
IN ALL POSITIONS					^									^	^										
NOISE OCCURS AT IDLE																						Т			_
WHEN VEHICLE IS STOPPED					Χ										Χ										
IN D, M OR R POSITION																									
TRANSAXLE OVERHEATS	X	Х										Х	Х								Х	Х	Х		
ENGINE STALLS				Х											Х									Х	
WHEN SHIFTED TO D, M OR R POSITION	+					.,																$\vdash$	$\vdash$		_
STARTER DOES NOT WORK	_				Χ	Х																$\sqcup$			_
GEAR POSITION INDICATOR							Х														Х				
DOES NOT ILLUMINATE IN M POSITION GEAR POSITION INDICATOR	-																					$\vdash$			_
ILLUMINATES IN P, R, N AND D POSITIONS							Х																		
M POSITION INDICATOR LIGHT																						$\vdash$			_
DOES NOT ILLUMINATE IN M POSITION/							Х																		
M POSITION INDICATOR LIGHT ILLUMINATES IN D POSITION																									
ATF SEEPING FROM AUTOMATIC TRANSAXLE																		Х	Χ						_
ITEM /	+			z	_											_		-				$\vdash$	z		_
				710	ō	(E	S			J Q	Z					Ó		AGI					읟		
				CĀ	CT	Ž	Ĕ			¥.						C		AM		Ö			2		
SYMPTOM	_	_	_	ЗFI	Ę	ĭĂŢ	Ĭ	Z		声型	12	_	S			3		) D	느				اجًا		C
	6	Ó	Ó	эE(	1AL	ᇣᇰ	ビ	l≌	Z	ST A		6	Ě		z	느		뷝	z	8 8		Z	AF.	Z	Ξ
	E	CI	5	SF	Σ	바음	MA	2	l≌	₹ ¥		E	N N	S	은	M		Ž	9			ΙĔ	Ì	$\exists$	'n
	ECT SENSOR MALFUNCTION	CKP SENSOR MALFUNCTION	MAF SENSOR MALFUNCTION	NOT WITHIN IDLE SPEED SPECIFICATION	ENGINE CONTROL SYSTEM MALFUNCTION	IMMOBILIZER SYSTEM OPERATING OR SYSTEM MALFUNCTION	INSTRUMENT CLUSTER MALFUNCTION	BARO SENSOR MALFUNCTION	IAT SENSOR MALFUNCTION	TIRE MALFUNCTION (DIAMETER, PRESSURE OTHER THAN STANDARD)	LOW-G (XY) SENSOR MALFUNCTION	APP SENSOR MALFUNCTION	BRAKE SWITCH MALFUNCTION	OIL PUMP MALFUNCTION	TORQUE CONVERTER OPERATING MALFUNCTION	PARKING MECHANISM MALFUNCTION	MANUAL SHAFT STUCK	SEALING DETERIORATION AND DAMAGE	INCORRECT INSTALLATION OF ATX EXTERNAL PART	POOR INSTALLATION OR WORN OF ENGINE MOUNT, SUSPENSION		OIL COOLER MALFUNCTION	CONTROL VALVE BODY MALFUNCTION	TCC PISTON MALFUNCTION	<u>1</u>
	Œ	Ë	빌	SPE	SYS	STI	ST	1AL	J.	6 #	Ö	I-FI	MAI	N	품글	E S	STL	JR/	AR.	S [S	Z	교	BC	$\mathbb{F}$	Σ
	Ι¥	MA	MA	Ë	7	S√ F	Ü	2	<b>J</b> AL	E	N.	MA	I	님	Æ	ΑĦ	ŀ	R	SS'	4 5	I	<b> </b>	묏	1AL	Ĭ
	Ä	2	띩	ID	TR	∺ ⋛	1	Š	~	<u> </u>	S	Ä	12	IAL	N	EC	₹	삠	É₹	ΙΞΣ	12		AL	2	Ę
CAUSE OF TROUBLE	185	SS	8	Z	Š		JEN	N.	Š	드분		SC	NS.	Ы	ŏΣ	Σ	ŝ	E		IST MC	E	삗	<u></u>	Ō	4
	戶	点	넰	ΙL		B S	Ş	SE	N.	MA	ري	河	Щ	N	Ä F	N	Ή	S S	문 누	불빛	<u>¥</u>	8	원	<u>S</u>	ij
	E	F)	Į.	ν <u>τ</u>	S	MO S S	3TR	8	SE	문입	<u>~</u>	9	Ä	۵	TORQUE CONVERTER OPERATING MALFUNC	X	Ŋ	ALI	INCORRECT INSTALL ATX EXTERNAL PART		ATF MALFUNCTION	Ō	Ž	Ö	ENING I FEIGIFNT TOM I FABRING
	10	14	ı 🔍 l	$\circ$	ラ	$= \square$	100	-	-	· 4	-		. ~		$\sim$ L	-	Ø	mil	$\simeq$ $\sim$	いつフ		I = I	ıΟl	()	9,

ac5wzw00006249