## **EXHAUST SYSTEM INSPECTION [SKYACTIV-D 2.2]**

id0115z7800100

- Start the engine and inspect each exhaust system component for exhaust gas leakage.
  If there is leakage, repair or replace the appropriate component. (See EXHAUST SYSTEM REMOVAL/INSTALLATION [SKYACTIV-D 2.2].)