
HEADLIGHT LEVELING ACTUATOR INSPECTION

id091800809700

Note

- The headlight leveling actuator is integrated in the front combination light.
- For the actuator inspection of the headlight auto leveling system, perform the headlight leveling actuator operation check mode. (See HEADLIGHT LEVELING ACTUATOR OPERATION CHECK MODE [ADAPTIVE FRONT LIGHTING SYSTEM (AFS)].)
- 1. Verify that the voltages of each of the terminals are as indicated in the terminal voltage table.
 - If the voltage is not as indicated in the table, inspect the parts under Inspection item(s).
 - If the system does not work normally even though the parts or related wiring harnesses do not have any malfunction, replace the front combination light. (See FRONT COMBINATION LIGHT REMOVAL/ INSTALLATION.)

Terminal Voltage List (Reference)



ac5wzw00000045

| Terminal | Signal | Connection | Test | condition | Voltage (V) | Inspection item (s) |
|----------|--|---|---|---|-----------------|--|
| F | Headlight leveling actuator signal | | Light switch at HEAD position | Headlight leveling switch position 0 | Approx. 10.1 | Headlight leveling switch (See HEADLIGHT LEVELING SWITCH INSPECTION.) Related wiring harness |
| | | | | Headlight leveling switch position - | Approx. 9.4 | |
| | | | | Headlight leveling switch position 1 | Approx. 8.7 | |
| | | | | Headlight leveling switch position - | Approx. 7.9 | |
| | | | | Headlight leveling switch position 2 | Approx. 7.2 | |
| | | | | Headlight leveling switch position - | Approx. 6.5 | |
| | | | | Headlight leveling switch position 3 | Approx. 5.8 | |
| | | | | Headlight leveling switch position - | Approx. 5.1 | |
| | | | | Headlight leveling switch position 4 | Approx. 4.4 | |
| | | | | Headlight leveling switch position - | Approx. 3.6 | |
| | | | | Headlight leveling switch position 5 | Approx. 2.9 | |
| ı | Headlight leveling actuator power supply | Headlight relay (LO) | Light switch at HEAD position Light switch at OFF | | B+ | Headlight relay (LO) (See RELAY INSPECTION.) Related wiring harness |
| L | Ground | Headlight leveling switch Body ground | Under any condition | | 1.0 or less | Headlight leveling switch (See HEADLIGHT LEVELING SWITCH INSPECTION.) Related wiring harness |