MANIFOLD ABSOLUTE PRESSURE (MAP) SENSOR INSPECTION [SKYACTIV-G 2.0]

id0140f4800900

Voltage Inspection

- 1. Connect the M-MDS to the DLC-2.
- 2. Switch the ignition ON (engine off or on).
- 3. Verify that the MAP sensor output voltage (PID: MAP) is within the specification. (See ON-BOARD DIAGNOSTIC
 - TEST [SKYACTIV-G 2.0].) (See PCM INSPECTION [SKYACTIV-G 2.0].)

 If not as specified, replace the MAP sensor/IAT sensor No.2. (See MANIFOLD ABSOLUTE PRESSURE (MAP) SENSOR/INTAKE AIR TEMPERATURE (IAT) SENSOR NO.2 REMOVAL/INSTALLATION [SKYÁCTIV-G 2.0].)

Specification

