BRAKE FLUID PRESSURE SENSOR

id041500105200

Purpose/Function

• The brake fluid pressure sensor detects the fluid pressure from the master cylinder and transmits it to the DSC HU/CM.

Construction

• The brake fluid pressure sensor is built into the DSC HU/CM. Therefore if there is any malfunction of the brake fluid pressure sensor, replace the DSC HU/CM.

Fail-safe

DTC No.	Fail-safe function
C0044:01	 Illuminates the TCS/DSC indicator light. Illuminates the master warning light.(Not illuminated depending on malfunction content.)*1 Tire pressure monitoring system warning light illuminates after flashes. (Not illuminated/flashed depending on malfunction content.) Inhibits the TCS*2, DSC*2, roll over mitigation (ROM)*2, brake assist control*2, hill launch assist (HLA)*2, TPMS*2, smart city brake support (SCBS)*1*2, and secondary collision reduction (SCR)*2 controls.
C0044:28	Illuminates the TCS/DSC indicator light.
C0044:54	 Illuminates the master warning light.(Not illuminated depending on malfunction content.)*1 Tire pressure monitoring system warning light illuminates after flashes. Inhibits the TCS, DSC, roll over mitigation (ROM), brake assist control, hill launch assist (HLA), TPMS, smart city brake support (SCBS), and secondary collision reduction (SCR) controls.

^{*1 :} Vehicle with smart city brake support (SCBS).

DTC No.	Fail-safe function
DIC NO.	
C0044:64	 Illuminates the TCS/DSC indicator light. Illuminates the master warning light.(Not illuminated depending on malfunction content.)*1 Tire pressure monitoring system warning light illuminates after flashes. (Not illuminated/flashed depending on malfunction content.) Inhibits the TCS*2, DSC*2, roll over mitigation (ROM)*2, brake assist control*2, hill launch assist (HLA)*2, TPMS*2, smart city brake support (SCBS)*1*2, and secondary collision reduction (SCR)*2 controls.

^{*2 :} Enabled depending on malfunction content.