DTC B109F:49 [REAR BODY CONTROL MODULE (RBCM)]

id0902p4013100

System malfunction location	Intruder sensor internal malfunction	
Detection condition	Rear body control module (RBCM) detects intruder sensor internal malfunction for 1.5 s or more.	
Fail-safe	_	
Possible cause	• Intruder sensor malfunction • Rear body control module (RBCM) malfunction	
System wiring diagram	_	

Diagnostic Procedure

Step	p Inspection Action			
	Inspection VERIFY REAR BODY CONTROL MODULE Yes			
1	(RBCM) DTCs AGAIN	Yes	Go to the next step.	
	Clear rear body control module (RBCM) DTCs	No	Go to Step 4.	
	using the M-MDS.			
	(See CLEARING DTC [REAR BODY			
	CONTROL MODULE (RBCM)].)			
	Lock the door to go on theft-deterrent system			
	standby.			
	Unlock the door to cancel theft-deterrent			
	standby.			
	Perform the DTC inspection for the rear body			
	control module (RBCM) using the M-MDS.			
	(See DTC INSPECTION [REAR BODY			
	CONTROL MODULE (RBCM)].)			
	Is DTC B109F:49 displayed?			
2	INSPECT INTRUDER SENSOR	Yes	Go to the next step.	
	Inspect the intruder sensor.	No	Replace the intruder sensor, then go to the next step.	
	(See INTRUDER SENSOR INSPECTION.)		(See INTRUDER SENSOR REMOVAL/INSTALLATION.)	
	• Is the intruder sensor normal?		Della di la contra della (DDOM) di contra	
3	VERIFY THAT REPAIRS HAVE BEEN COMPLETED	Yes	Replace the rear body control module (RBCM), then go to	
	Clear rear body control module (RBCM) DTCs		the next step. (See REAR BODY CONTROL MODULE (RBCM)	
	using the M-MDS.		REMOVAL/INSTALLATION.)	
	(See CLEARING DTC [REAR BODY	No	Go to the next step.	
	CONTROL MODULE (RBCM)].)	110	Co to the next step.	
	Lock the door to go on theft-deterrent system			
	standby.			
	Unlock the door to cancel theft-deterrent			
	standby.			
	Perform the DTC inspection for the rear body			
	control module (RBCM) using the M-MDS.			
	(See DTC INSPECTION [REAR BODY			
	CONTROL MODULE (RBCM)].)			
	• Is DTC B109F:49 displayed?			
4	VERIFY IF OTHER DTCs DISPLAYED	Yes	Repair the malfunctioning part according to the applicable	
	Are any other DTCs displayed?		DTC troubleshooting.	
			(See DTC TABLE [REAR BODY CONTROL MODULE	
		No	(RBCM)].)	
		No	DTC troubleshooting completed.	