BLOWER MOTOR INSPECTION [FULL-AUTO AIR CONDITIONER]

- Connect battery positive voltage to blower motor terminal B, connect terminal A to ground, and then verify its operation.
 - If there is any malfunction, replace the blower

