## ON-BOARD DIAGNOSTIC SYSTEM MALFUNCTION DISPLAY FUNCTION [SKYACTIV-G 2.0, SKYACTIV-G 2.5]

## **Outline**

- Illuminates the check engine light to notify the driver of a malfunction occurring in the engine control system.
- The check engine light is in the instrument cluster. (See CHECK ENGINE LIGHT [SKYACTIV-G 2.0, SKYACTIV-G 2.5].)

## **Function**

- The check engine light illuminates when a malfunction occurs in the engine control system, and it illuminates at the same time a DTC is recorded in the PCM.
- The illumination/non-illumination conditions of the check engine light are determined by the number of drive cycles. (See ON-BOARD DIAGNOSTIC SYSTEM TEST MODE [SKYACTIV-G 2.0, SKYACTIV-G 2.5].)