REARVIEW MIRROR REMOVAL/INSTALLATION

- 1. Remove the screw.
- 2. Pull the rearview mirror in the direction of the arrow (1) shown in the figure
- 3. Install in the reverse order of removal.

id091200009200

