
#### WASTEGATE SOLENOID VALVE REMOVAL/INSTALLATION [SKYACTIV-D 2.2]

id0113z7266100


#### Caution

- If the vacuum hose is installed incorrectly, it could cause a vehicle malfunction. To prevent this, refer to "VACUUM HOSE STRUCTURAL VIEW" and install the vacuum hose correctly. (See Vacuum hose structural view.)
- 1. Disconnect the negative battery cable. (See NEGATIVE BATTERY CABLE DISCONNECTION/CONNECTION [SKYACTIV-D 2.2].)
- 2. Remove the battery and the battery tray. (See BATTERY REMOVAL/INSTALLATION [SKYACTIV-D 2.2].)
- 3. Remove in the order shown in the figure.

#### **ATX**



#### MTX



ac5wzw00004692


1	Vacuum pipe bracket
2	Vacuum hose No.1
	(See Vacuum Hose No.1 Installation Note.)
3	Vacuum hose No.2
	(See Vacuum Hose No.2 Installation Note.)
4	Vacuum hose No.3
	(See Vacuum Hose No.3 Installation Note.)
5	Wastegate solenoid valve

4. Install in the reverse order of removal.


#### **Vacuum Hose No.3 Installation Note**

1. Install vacuum hose No.3 as shown in the figure.

### Wastegate solenoid valve side



#### Vacuum pipe bracket side




#### ac5wzw00004694


#### **Vacuum Hose No.2 Installation Note**

1. Install vacuum hose No.2 as shown in the figure.

## Wastegate solenoid valve side




### Wastegate valve actuator side




#### **Vacuum Hose No.1 Installation Note**

1. Install vacuum hose No.1 as shown in the figure. Wastegate solenoid valve side




### Vacuum pipe bracket side




#### ac5wzw00004698

### Vacuum hose structural view


1. Verify that the vacuum hose is installed correctly as shown in the figure. Whole figure (ATX)




# Whole figure (MTX)




# Wastegate solenoid valve side (ATX)



## Wastegate solenoid valve side (MTX)



#### Vacuum pipe bracket side (ATX)



#### Vacuum pipe bracket side (MTX)

