## DTC U053B:00 [INSTRUMENT CLUSTER]

id0902e8016500

System malfunction location	Error signal received from forward sensing camera (FSC)		
Detection condition	• The instrument cluster receives error signals from the forward sensing camera (FSC) for <b>1 s or more</b> with the ignition switched ON (engine off or on).		
Fail-safe	— —		
Possible cause	<ul> <li>DTCs are stored in the forward sensing camera (FSC).</li> <li>Instrument cluster malfunction</li> </ul>		
System wiring diagram	_		

**Diagnostic Procedure** 

Diagnostic Procedure					
Step	Inspection		Action		
1	VERIFY INSTRUMENT CLUSTER DTCs	Yes	Repair the malfunctioning part according to the applicable		
	Perform the DTC inspection for the instrument		DTC troubleshooting.		
	cluster using the M-MDS.		(See DTC TABLE [INSTRUMENT CLUSTER].)		
	(See DTC INSPECTION [INSTRUMENT	No	Go to the next step.		
	CLUSTER].)				
	Is the DTC displayed?				
2	VERIFY FORWARD SENSING CAMERA (FSC)	Yes	Repair the malfunctioning part according to the applicable		
	DTCs		DTC troubleshooting.		
	Perform the DTC inspection for the forward		(See DTC TABLE [FORWARD SENSING CAMERA		
	sensing camera (FSC) using the M-MDS.		(FSC)].)		
	(See DTC INSPECTION [FORWARD	No	Go to the next step.		
	SENSING CAMERA (FSC)].)				
	• Is the DTC displayed?	.,			
3	VERIFY THAT REPAIRS HAVE BEEN	Yes	Replace the instrument cluster, then go to the next step.		
	COMPLETED		(See INSTRUMENT CLUSTER REMOVAL/		
	Clear DTC for the instrument cluster using the M-MDS.	NI-	INSTALLATION.)		
	(See CLEARING DTC [INSTRUMENT	No	Go to the next step.		
	CLUSTERI.)				
	Switch the ignition ON (engine off or on) and				
	wait for <b>20 s or more</b> .				
	Perform the DTC inspection for the instrument				
	cluster using the M-MDS.				
	(See DTC INSPECTION [INSTRUMENT				
	CLUSTER].)				
	• Is DTC U053B:00 displayed?				
4	VERIFY IF OTHER DTCs DISPLAYED	Yes	Repair the malfunctioning part according to the applicable		
	Are any other DTCs displayed?		DTC troubleshooting.		
			(See DTC TABLE [INSTRUMENT CLUSTER].)		
		No	DTC troubleshooting completed.		
	I		<u>,                                      </u>		