## POWER BRAKE UNIT VACUUM SENSOR INSPECTION [SKYACTIV-G 2.0]

id0140f4889400

## **Voltage Inspection**

- 1. Connect the M-MDS to the DLC-2.
- 2. Switch the ignition ON (engine off or on).
- Verify that the power brake unit vacuum sensor output voltage (PID: BBP) is within the specification. (See ON-BOARD DIAGNOSTIC TEST [SKYACTIV-G 2.0].) (See PCM INSPECTION [SKYACTIV-G 2.0].)
  If not as specified, replace the power brake unit vacuum sensor. (See POWER BRAKE UNIT VACUUM
  - SENSOR REMOVAL/INSTALLATION.)

## **Specification**

