CANNOT TUNE (SEEK DOES NOT STOP) [RADIO]

id0903e3016200

Possible DTC	Cannot tune (seek does not stop)		
	Using the M-MDS U3000:16, U3000:04		
	Without using M-MDS (On- board diagnostic test mode)	09:Er20, 09:Er22	
Possible cause	 Audio panel malfunction Electronic jamming from outside, or inferior condition of broadcasting station radio wave Antenna plug poor connection Antenna feeder malfunction Audio unit malfunction 		

Diagnostic procedure					
STEP	INSPECTION		ACTION		
1	Inspect if feel of SEEK switch is normal when	Yes	Go to the next step.		
	switch is pushed and released.	No	Perform confirmation step 1: audio panel switch confirmation.		
	• Is it okay?		Replace audio panel if necessary.		
2	Inspect indication of LCD.	Yes	Go to the next step.		
	Is frequency indication increased or decreased	No	Perform confirmation step 1: audio panel switch confirmation.		
	when SEEK switch is pushed?		Replace audio panel if necessary.		
3	Manually tune to local broadcasting station and	Yes	Go to Step 6.		
	check reception condition. • Is reception okay?		Go to the next step.		
4	Inspect antenna plug connection condition.	Yes	Go to the next step.		
	Is connection okay?		Insert antenna plug securely.		
5	Switch the ignition off (LOCK).		Replace antenna feeder.		
	Measure continuity between antenna feeder	No	Go to the next step.		
	axis and ground.				
	Is there any continuity?				
6	Check if number of broadcasting stations	Yes	The system is normal. (Explain to customer that SEEK		
	changes depending on time and place.		sometimes does not stop depending on signal reception		
	Does it change?		condition.)		
			Note		
			Signals tend to reach longer distances in the night. It is noticeable in AM signals, several audio functions may		
			1		
			stop due to foreign broadcasting station or noise. Though the audio system restrains sensitivity of SEEK		
			and SCAN functions in the night, the audio system may		
			select other than desired broadcasting station when		
			signals are considerably strong. This function is linked		
			to the parking light. When the parking light or headlight		
			is turned on, SEEK and SCAN may not function for weak		
			signals.		
		No	Replace audio unit.		
		INU	(See AUDIO UNIT REMOVAL/INSTALLATION.)		
			(OGE AUDIO DIVIT REIVIOVAL/IIVOTALLATION.)		