## **EMISSION SYSTEM [SKYACTIV-D 2.2]**


id0116e1110100

## **Outline**

• Diesel particulate elimination equipment (Diesel Particulate Filter (DPF) has been adopted which eliminates PM from the exhaust gas.


#### **Structural View**

**Engine compartment side** 




ac5wzn00002250


#### **Exhaust system side** 2WD



## 4WD




# Fuel tank side 2WD





ac5wzn00002253

## 4WD



ac5wzn00002254





## **Structure**

• The emission system consists of the following parts:

Part/System name		Reference
Exhaust gas purification system (See EXHAUST GAS PURIFICATION SYSTEM [SKYACTIV-D 2.2].)	Catalytic converter	(See CATALYTIC CONVERTER [SKYACTIV-D 2.2].)
Exhaust gas recirculation system (See EXHAUST GAS RECIRCULATION SYSTEM [SKYACTIV-D 2.2].)	EGR valve	(See EGR VALVE [SKYACTIV-D 2.2].)
	EGR cooler	(See EGR COOLER [SKYACTIV-D 2.2].)
	EGR cooler bypass	(See EGR COOLER BYPASS VALVE [SKYACTIV-D
	valve	2.2].)
Fuel-filler cap		(See FUEL-FILLER CAP [SKYACTIV-D 2.2].)
Rollover valve		(See ROLLOVER VALVE [SKYACTIV-D 2.2].)
Check valve		(See CHECK VALVE [SKYACTIV-D 2.2].)
Diesel particulate filter (DPF)		(See DIESEL PARTICULATE FILTER [SKYACTIV-D
		2.2].)
Intake shutter valve		(See INTAKE SHUTTER VALVE [SKYACTIV-D 2.2].)