## TROUBLESHOOTING INDEX [EMERGENCY STOP SIGNAL SYSTEM (ESS)]

id0903j7010500

| No. | Troubleshooting item       | Description                                                               |
|-----|----------------------------|---------------------------------------------------------------------------|
| 1   | ESS (EMERGENCY STOP SIGNAL | Hazard warning lights do not flash even though the vehicle decelerates    |
|     | SYSTEM) DOES NOT OPERATE   | suddenly *1.                                                              |
|     | [EMERGENCY STOP SIGNAL     | Hazard warning lights end flashing before vehicle stops (vehicle speed at |
|     | SYSTEM (ESS)]              | approx. 10 km/h {6.2 mph}) while the system operates.                     |
| 2   | ESS (EMERGENCY STOP SIGNAL |                                                                           |
|     | SYSTEM) OPERATES WHILE NOT | Hazard warning lights flash while driving.                                |
|     | UNDER OPERATION CONDITIONS | Hazard warning lights flash even though deceleration is done without      |
|     | [EMERGENCY STOP SIGNAL     | decelerating*1 rapidly.                                                   |
|     | SYSTEM (ESS)]              |                                                                           |

 $<sup>^{*1}</sup>$ : Deceleration of vehicle speed at 30 km/h {19 mph} or more for 1 s while vehicle speed is 60—70 km/h {38—43 mph} or more.