DTC U2300:56 [INSTRUMENT CLUSTER]

id0902e8016900

System malfunction location	Instrument cluster configuration error		
Detection condition	Instrument cluster configuration error (incorrect value write) detected.		
Fail-safe	_		
Possible cause	Instrument cluster configuration error Instrument cluster malfunction		
System wiring diagram	_		

Diagnostic Procedure

Diagnost	nostic Procedure				
Step	Inspection		Action		
1	PERFORM INSTRUMENT CLUSTER CONFIGURATION (USING AS-BUILT DATA) • Using the M-MDS, perform the instrument cluster configuration with the As-Built data. (See INSTRUMENT CLUSTER CONFIGURATION (USING AS-BUILT DATA).) • Clear DTC for the instrument cluster using the M-MDS. (See CLEARING DTC [INSTRUMENT CLUSTER].) • Perform the DTC inspection for the instrument cluster using the M-MDS. (See DTC INSPECTION [INSTRUMENT CLUSTER].) • Is the DTC U2300:56 displayed?	Yes	Using the M-MDS, re-perform the instrument cluster configuration using the As-Built data, then go to the next step. (See INSTRUMENT CLUSTER CONFIGURATION (USING AS-BUILT DATA).)		
		No	Go to Step 3.		
2	VERIFY THAT REPAIRS HAVE BEEN COMPLETED • Clear DTC for the instrument cluster using the M-MDS. (See CLEARING DTC [INSTRUMENT CLUSTER].) • Perform the DTC inspection for the instrument cluster using the M-MDS. (See DTC INSPECTION [INSTRUMENT CLUSTER].) • Is the DTC U2300:56 displayed?	Yes	Replace the instrument cluster, then go to the next step. (See INSTRUMENT CLUSTER REMOVAL/ INSTALLATION.)		
		No	Go to the next step.		
3	• Are any other DTCs displayed?	Yes	Repair the malfunctioning part according to the applicable DTC troubleshooting. (See DTC TABLE [INSTRUMENT CLUSTER].) DTC troubleshooting completed.		
		INU	DIO troubleshooting completed.		