DTC B115E:54 [FORWARD SENSING CAMERA (FSC)]

id0902p9029500

System malfunction location	Forward sensing camera (FSC) aiming not completed		
Detection condition	Forward sensing camera (FSC) aiming not completed is detected.		
Fail-safe	• Inhibits the lane departure warning system (LDWS). • Inhibits the high beam control system (HBC).		
Possible cause	Forward sensing camera (FSC) aiming not performed. Forward sensing camera (FSC) malfunction		
System wiring diagram	_		

Diagnostic Procedure				
Step	Inspection		Action	
1	PERFORM FORWARD SENSING CAMERA	Yes	Perform the forward sensing camera (FSC) aiming again,	
	(FSC) AIMING		then go to the next step.	
	Perform the forward sensing camera (FSC)		(See FORWARD SENSING CAMERA (FSC) AIMING.)	
	aiming. (See FORWARD SENSING CAMERA (FSC) AIMING.) • Clear the forward sensing camera (FSC) DTCs using the M-MDS. (See CLEARING DTC [FORWARD SENSING CAMERA (FSC)].) • Perform the DTC inspection for the forward sensing camera (FSC) using the M-MDS. (See DTC INSPECTION [FORWARD SENSING CAMERA (FSC)].)	No	Go to Step 3.	
2	• Is DTC B115E:54 displayed? VERIFY THAT REPAIRS HAVE BEEN	Yes	Replace the forward sensing camera (FSC), then go to the	
	COMPLETED Clear the forward sensing camera (FSC) DTCs using the M-MDS. (See CLEARING DTC [FORWARD SENSING CAMERA (FSC)].) Perform the DTC inspection for the forward sensing camera (FSC) using the M-MDS. (See DTC INSPECTION [FORWARD SENSING CAMERA (FSC)].) Is DTC B115E:54 displayed?		next step. (See FORWARD SENSING CAMERA (FSC) REMOVAL/ INSTALLATION.)	
		No	Go to the next step.	
3	• Are any other DTCs displayed?	Yes	Repair the malfunctioning part according to the applicable DTC troubleshooting. (See DTC TABLE [FORWARD SENSING CAMERA (FSC)].)	
		No	DTC troubleshooting completed.	