

# iTE Control Board

外部輸出入架構說明文件



#### 修訂記錄

| 修訂日期       | 修訂說明   | 頁次 |
|------------|--------|----|
| 2016/11/17 | 初建版本   |    |
| 2016/12/7  | 更新程式範例 |    |
|            |        |    |
|            |        |    |
|            |        |    |
|            |        |    |
|            |        |    |
|            |        |    |
|            |        |    |
|            |        |    |
|            |        |    |
|            |        |    |



#### 目錄

| 1. | 亰   | 前言                          | . 1 |
|----|-----|-----------------------------|-----|
|    | , , |                             |     |
|    |     | 適用範圍                        |     |
|    |     | 適用人員                        |     |
|    |     | /                           |     |
|    |     |                             |     |
|    | 2.1 | ITE CONTROL BOARD 外部輸出入架構介紹 | 3   |
|    | 2.2 | 外部輸入架構流程介紹                  | 3   |
|    | 2.3 | 外部輸出架構流程介紹                  | е   |
|    |     | 知自完 <del>業</del>            | 5   |



## 1. 前言

#### **1.1** 编寫目的

介紹iTE Control board 外部輸出入架構說明。

## 1.2 適用範圍

使用於iTE Control board相關產品。

#### 1.3 適用人員

適用於使用iTE FAE or 客戶RD開發人員。






## 2. 外部輸出入架構介紹

#### 2.1 iTE Control board 外部輸出入架構介紹

● 透過外部輸出入架構,從週邊讀取訊息,再傳遞到畫面,和透過畫面輸入,再傳遞到週邊,有統一的寫法,不至於讓畫面阻塞住。

## 2.2 外部輸入架構流程介紹



● 程式在ExternalInTask執行緒中不斷的讀取週邊的訊息,然後將訊息寫入extInQueue的訊息佇列中。 程式碼檔案在external.c,範例代碼如下:

```
static void* ExternalInTask(void* arg)
{
    while (!extQuit)
        ExternalEvent ev;
          char readbuf[4];
#if defined(CFG_UARTO_ENABLE) && !defined(CFG_DBG_UARTO)
        if (read(ITP_DEVICE_UARTO, readbuf, 4))
            switch (readbuf[0])
            case '0':
                ev.type = EXTERNAL_TESTO;
                break;
            case '1':
                ev.type = EXTERNAL_TEST1;
                ev.arg1 = readbuf[1];
                break:
            case '2':
                ev.type = EXTERNAL_TEST2;
                ev.arg1 = readbuf[1];
                ev.arg2 = readbuf[2];
                break:
            case '3':
                ev.type = EXTERNAL_TEST3;
                ev.arg1 = readbuf[1];
                ev.arg2 = readbuf[2];
```



```
ev.arg3 = readbuf[3];
                break:
            case '4':
                ev.type = EXTERNAL_TEST4;
                ev.arg1 = readbuf[1];
                break:
            case '5':
                ev.type = EXTERNAL_TEST5;
                ev.arg1 = readbuf[1];
                break;
            default:
                ev.type = EXTERNAL_SHOW_MSG;
                memset(ev.buf1, 0 , EXTERNAL_BUFFER_SIZE);
                memcpy(ev.buf1, readbuf, 4);
                break;
            }
            mq_send(extInQueue, (const char*)&ev, sizeof (ExternalEvent), 0);
        }
#endif
        usleep(10000);
    }
    mq_close(extInQueue);
    extInQueue = -1;
    return NULL;
}
```

新的讀取週邊訊息程式碼需要在此加入。

● 在主執行緒中不斷檢查extInQueue之中是不是有新的訊息。若有, 則會讀出新訊息,交給 ExternalProcessEvent() 處理,相關程式碼在scene.c,如下:

```
static void CheckExternal(void)
{
    ExternalEvent ev;
    int ret = ExternalReceive(&ev);

    if (ret)
    {
        ScreenSaverRefresh();
        ExternalProcessEvent(&ev);
    }
}
```



● 在ExternalProcessEvent()中依訊息型別做不同的處理,再更新畫面。程式碼在external\_process.c。 範例如下:

```
static void ExternalProcessUart(ExternalEvent* ev)
    if (!ituWidgetIsVisible(buttonLayer))
        ituLayerGoto(buttonLayer); // goto button layer
    ituCoverFlowGoto(buttonCoverFlow, 2); // goto #3 page
    ituSceneSendEvent(&theScene, EVENT_CUSTOM_UART, ev->buf1); // send received UART data to UI
}
void ExternalProcessEvent(ExternalEvent* ev)
   char buf[64];
    assert(ev);
   switch (ev->type)
   case EXTERNAL_SHOW_MSG:
       printf("EXTERNAL_SHOW_MSG\n");
       ExternalProcessUart(ev);
       break;
   case EXTERNAL TESTO:
       printf("EXTERNAL_TESTO\n");
       ituSceneSendEvent(&theScene, EVENT_CUSTOM_KEYO, NULL);
       break:
   case EXTERNAL_TEST1:
       printf("EXTERNAL_TEST1: %d\n", ev->arg1);
       ituSceneSendEvent(&theScene, EVENT_CUSTOM_KEY1, NULL);
       break;
   case EXTERNAL_TEST2:
       printf("EXTERNAL_TEST2: %d %d\n", ev->arg1, ev->arg2);
       sprintf(buf, "%d %d", ev->arg1, ev->arg2);
       ituSceneSendEvent(&theScene, EVENT_CUSTOM_KEY2, buf);
       break;
   case EXTERNAL_TEST3:
       printf("EXTERNAL_TEST3: %d %d %d\n", ev->arg1, ev->arg2, ev->arg3);
       sprintf(buf, "%d %d %d", ev->argl, ev->arg2, ev->arg3);
       ituSceneSendEvent(&theScene, EVENT_CUSTOM_KEY1, buf);
       break;
   case EXTERNAL TEST4:
       printf("EXTERNAL_TEST4: %d\n", ev->arg1);
       break:
```



```
case EXTERNAL_TEST5:
    printf("EXTERNAL_TEST5: %d\n", ev->argl);
    break;
}
```

#### 2.3 外部輸出架構流程介紹



● 從畫面取得輸出訊息後,呼叫ExternalSend()將訊息寫入extQutQueue的訊息佇列中。範例程式碼如下:

```
// called when user press send button
bool ButtonUartSendButtonOnPress(ITUWidget* widget, char* param)
{
    ExternalEvent ev;

    // fill in data
    ev.type = EXTERNAL_SHOW_MSG;
    strcpy(ev.bufl, "test");

    // send to output message queue
    ExternalSend(&ev);

    return true;
}
```

程式在ExternalOutTask執行緒中不斷的讀取extQutQueue訊息佇列中的訊息,然後將訊息輸出到對應的週邊。程式碼檔案在external.c,範例代碼如下:



{

```
case EXTERNAL_TESTO:
                writebuf[0] = '0';
               write(ITP_DEVICE_UARTO, writebuf, 4);
                break;
            case EXTERNAL_TEST1:
                writebuf[0] = '1';
                writebuf[1] = (char)ev.argl;
               write(ITP_DEVICE_UARTO, writebuf, 4);
                break;
            case EXTERNAL_TEST2:
                writebuf[2] = '2';
                writebuf[1] = (char)ev.argl;
                writebuf[2] = (char)ev.arg2;
               write(ITP_DEVICE_UARTO, writebuf, 4);
                break;
            case EXTERNAL_TEST3:
                writebuf[0] = '3';
                writebuf[1] = (char)ev.argl;
                writebuf[2] = (char)ev.arg2;
                writebuf[3] = (char)ev.arg3;
               write(ITP_DEVICE_UARTO, writebuf, 4);
                break:
            case EXTERNAL_TEST4:
                writebuf[0] = '4';
                writebuf[1] = (char)ev.argl;
               write(ITP_DEVICE_UARTO, writebuf, 4);
                break;
            case EXTERNAL_TEST5:
                writebuf[0] = '5';
                writebuf[1] = (char)ev.argl;
               write(ITP_DEVICE_UARTO, writebuf, 4);
                break:
            case EXTERNAL_SHOW_MSG:
               write(ITP_DEVICE_UARTO, ev.buf1, 4);
               break;
            }
#endif
       }
    mq_close(extOutQueue);
    extOutQueue = -1;
    return NULL;
```



## 2.4 訊息定義

● 訊息型別定義在ctrlboard.h。範例程式碼如下:

```
typedef enum
{
    EXTERNAL_SHOW_MSG, ///< UART
    EXTERNAL_TESTO, ///< Test #0
    EXTERNAL_TEST1, ///< Test #1
    EXTERNAL_TEST2, ///< Test #2
    EXTERNAL_TEST3, ///< Test #3
    EXTERNAL_TEST4, ///< Test #4
    EXTERNAL_TEST5 ///< Test #5
} ExternalEventType;</pre>
```

使用者需要在此添加新的型別。

● 訊息結構也定義在ctrlboard.h。範例程式碼如下:

```
#define EXTERNAL_BUFFER_SIZE 64 ///< External buffer size

typedef struct
{
    ExternalEventType type;
    int arg1;
    int arg2;
    int arg3;
    uint8_t buf1[EXTERNAL_BUFFER_SIZE];
} ExternalEvent;</pre>
```

使用者可修改此結構以符合實際訊息的結構。