inspur	Туре	Instruction s	Doc.	Department	No.	xx/xxxx/xx	
,	Version	1.0			Release Date	20170220	
Inspur Electronic Information Industry Co. Ltd							

## DOSFlash User Guide

## Purpose

This document provides information to use the DOSFlash.

**Application Scope** 

Inspur Grantley platform server.

Instructions for DOSFlash

- 1. Put DOSFlash package and BIOS image file to DOS startup disk and boot into DOS.
- 2. Change directory to DOSFlash, as shown in Figure 1. BIOS.bin is 16M image file to be updated. Flash.bat is script to update 8M BIOS part. MEflash.bat is script to update 16M BIOS and ME part.

```
C:\>cd dosflash
C:\DOSFLASH>dir
Volume in drive C is ZHENGYUAN
Volume Serial Number is 485D-783E
Directory of C:\DOSFLASH
                <DIR>
                              12-19-14 10:06a
                <DIR>
                              12-19-14 10:06a
AFUDOS
         EXE
                    169,120
                              02-02-15
                              11-15-13
ANALYZE
                     13,525
BMC
                          16
                              12-12-13
                                         1:51p
FLASH
         BAT
                        332
                              12-19-14
                                         9:53a
IPMITOOL EXE
                     47,852
                              11-15-13
MEFLASH
                      1,050
README
                        982
SLEEP
                      9,927
         EXE
                              11-15-13 10:45a
BIOS
                 16,777,216
                              12-19-14
         9 file(s)
                        17,010,340 bytes
         2 dir(s)
                     2,090,102,784 bytes free
```

Figure 1

3. Without updating ME part, the command below update the BIOS part. The upgrade process is shown in figure 2. Reboot is suggested after the update is complete.

flash BIOS.bin

inspur	Туре	Instruction s	Doc.	Department	No.	xx/xxxx/xx	
	Version	1.0			Release Date	20170220	
Inspur Flectronic Information Industry Co. Ltd							

C:\DOSFLASH>flash BIOS.bin BIOS reflashing now ..... AMI Firmware Update Utility v5.07.01 Copyright (C)2014 American Megatrends Inc. All Rights Reserved. Reading flash ..... done - ME Data Size checking . ok Secure Flash enabled, recalculate ROM size with signature... - FFS checksums ..... ok Loading capsule to secure memory buffer ... done Erasing Boot Block ..... done Updating Boot Block ..... done Verifying Boot Block ..... done Erasing Main Block ..... done Updating Main Block ..... done Verifying Main Block ..... done Erasing NVRAM Block ..... done Updating NVRAM Block ..... done Verifying NVRAM Block ..... done Erasing NCB Block ..... done Updating NCB Block ..... done Verifying NCB Block ..... done Erasing RomHole Block ..... done Updating RomHole Block ..... done Verifying RomHole Block ..... done BIOS reflash finished!

Figure 2

4. When ME part changed, the command below update the BIOS and ME part. The upgrade process is shown in figure 3.

meflash BIOS.bin

inspur	Туре	Instruction s	Doc.	Department	No.	xx/xxxx/xx	
	Version	1.0			Release Date	20170220	
Income Floring in Information Industry, Co. Ital							

Inspur Electronic Information Industry Co.,Ltd.

```
C:\DOSFLASH>meflash BIOS.bin
ME reflash Begin.....
20 ec 32 00 02
Waiting for ME to reflash now,please wait a moment.....
C:\DOSFLASH>
ME reflashing now .....
     ************
                       AMI Firmware Update Utility v5.07.01
        Copyright (C)2014 American Megatrends Inc. All Rights Reserved.
Reading flash ...... done
- ME Data Size checking . ok
Secure Flash enabled, recalculate ROM size with signature...
- FFS checksuns . . . . . ok
Loading capsule to secure memory buffer . . . done
Erasing Boot Block . . . . . . done
Updating Boot Block . . . . . . done
Verifying Boot Block ..... done
Erasing Main Block ..... done
Updating Main Block ..... done
Verifying Main Block ..... done
Erasing NVRAM Block ..... done
Updating NVRAM Block ..... done
Verifying NVRAM Block ..... done
Erasing NCB Block ..... done
Updating NCB Block ..... done
Verifying NCB Block ...... done
Erasing RomHole Block ..... done
Updating RomHole Block ..... done
Verifying RomHole Block .... done
- Update success for /FDT!!
   Successful Update Recovery Loader to OPRx!!
Successful Update FPT, MFSB, FTPR and MFS!!
   ME Entire Image update success !!
WARNING: System must power-off to have the changes take effect!
20 ec 32 00 00
Please wait a moment.....
1E reflash finished!
system must power off to have the changes take effect!
```

Figure 3

Note: After the update is complete, system must power-off. Please make sure motherboard has no residual electricity before power on and boot.

UID light can be used to detect whether motherboard has residual electricity. Press UID light button. If the light is off, this shows that motherboard has no residual electricity. Otherwise motherboard has residual electricity.