


SERVICE

Manual



8-3. Flow Chart of Troubleshooting







Oscilloscope


Digital Multimeter





Power Supply

+ driver, ESD Safe Tweezer






8960 & Spectrum Analyzer

Soldering iron


MT Pro

8-4-1. Power On



MT Pro


8-4-2. Initial






8-4-3. No Service





8-4-4. SIM Part








8-4-5. LCD Part








MT Pro


8-4-6. SPK Part








8-4-7 MIC





MT Pro


8-4-8. RCV





MT Pro


8-4-9. Key Input





MT Pro


8-4-10. Vibration Motor






MT Pro

8-4-11.Main CAMERA




MT Pro

8-4-12.SUB CAMERA



MT Pro


8-4-13. Touch Screen



MT Pro


8-4-14. Sensor

8-4-14-1. Proxi Sensor



MT Pro


8-4-14-2. Accel Sensor








8-4-15. GSM 850,900,1800,1900 WCDMA 1,2,5,8 RX






8-4-16. GSM 850,900,1800,1900 WCDMA 1,2,5,8 TX




MT Pro

8-4-17. RF Section(WLAN / BT/FM)

- WLAN RX




- WLAN TX




MT Pro

- BT



- FM



MT Pro

8-4-18. RF Section(GPS)

