3 BASIC OPERATION

Setting the frequency (Continued)

♦ Entering a Band Edge

When "ON (User)" or "ON (User) & TX Limit" is selected on the "Band Edge Beep" screen, you can enter a total of 30 band edge frequencies.

- ① Initially, all band edges are entered. Therefore, you must first edit or delete them to enter a new band edge.
- ① You cannot enter an overlapped frequency or a frequency that is out of the preset transmit frequency.
- Open the "Band Edge Beep" screen.
 MENU » SET > Function > Band Edge Beep
- 2. Select "ON (User)" or "ON (User) & TX Limit."

 ①If you select "ON (User) & TX Limit," you can limit transmission to within the entered frequency range.



"Band Edge Beep" screen

3. Select "User Band Edge."



FUNCTION set screen

· Opens the "User Band Edge" screen.

Editing a Band Edge

You can edit a band edge entered as a default or when entering a new band edge.

- On the FUNCTION set screen, select "User Band Edge."
- 2. Touch the band edge you want to edit for 1 second.

(Example: 5: 14.000.000 - 14.350.000 MHz)



"User Band Edge" screen

3. Edit the lower band edge frequency. (Example: 14.1)



Entry examples

• 14.025 MHz: [1], [4], [•], [0], [2], [5], [ENT] • 18.0725 MHz: [1], [8], [•], [0], [7], [2], [5], [ENT]

• 730 kHz: [0], [•], [7], [3], [ENT] • 5.100 MHz: [5], [•], [1], [ENT] • 7.000 MHz: [7], [ENT]

• Changing from 21.280 MHz to 21.245 MHz: [•], [2], [4], [5], [ENT]

 Touch [ENT] to save the edited lower band edge frequency.



 Edit the upper band edge frequency. (Example: 14.25)



- 6. Touch [ENT] to save the edited upper band edge frequency.
 - The edited band edge is saved and returns to the previous screen.



TIP:

Rotate

- You can also edit the frequency by rotating (MAIN DIAL) or (MULTI).
- Each band edge must be higher in frequency than the ones above it. If you try to enter a lower frequency than the edges above, the lower frequency edge will be cleared when you push [ENT].