### 13 OTHER FUNCTIONS

# Displaying my call sign

You can display your own call sign at power ON.

[Example: Displaying the call sign JA3YUA]

- Open the MY CALL screen.
  - MENU » SET > Display > My Call
- Enter your call sign of up to 10 characters.
  See "Keyboard entering and editing" (p. 1-8) for details.
- 3. Touch [ENT] to save the entered call sign.






- The MY CALL screen closes and returns to the DISPLAY screen.
- · The entered name is displayed.
- The entered call sign is displayed at power ON.

## **Screen Capture function**

You can capture the transceiver display onto an SD card. Most of the screens used in this manual are captured using this function. However, some displays cannot be captured.

#### ♦ Capturing a screen

1. Open the "Screen Capture [POWER] SW" screen.



- 2. Select "ON" by rotating and pushing MULT).
- 3. Select the desired screen to capture.
- 4. Push **POWER** to capture the screen.
  - The captured screen is saved onto the SD card.

### Viewing the captured screen

• The capture list is displayed.

- Open the SCREEN CAPTURE VIEW screen.
  MENU » SET > SD Card > Screen Capture View
  - SET > 3D Cald > Screen Capture
  - The latest screen capture is at the top of the list.
- 2. Select the desired screen capture to be displayed by rotating and pushing (MULT).
  - The selected screen capture is displayed.



While a screen capture is displayed, you can scroll through all the screen captures by rotating (MULTI).

#### Other options in the capture list

1. While the capture list is displayed, push **QUICK** to display the QUICK MENU.



- 2. Select the desired option.
  - **File Information:** Displays the name, size, and date of the selected screen capture.
  - **Delete:** The confirmation dialog is displayed before deleting the file. Select [YES] to delete or select [NO] to cancel.
  - Delete All: The confirmation dialog is displayed before deleting all the files on the list. Select [YES] to delete or select [NO] to cancel.