


Male connector 1:
Connected to an USB-to-TTL device.



Male connector 2:
1. Connect to a filter
or 2. Use a jumper



Male connector 3:
Connected to an external filter circuit to denoise the anemometer whose behaviour is a switch's.

Anemometer 3:
Anemometer 4:
J7
Conn\_01x03\_Male

