

DroidLink_BodyPCA Command List

This reference shows commands exactly as they must be sent to the DroidLink Master.

- BodyPCA shortcut commands use :BS followed directly by two digits, such as :BS32.
- All other BodyPCA commands use the :BS, routing prefix, such as :BS,BZ,D,FWD.
- Do not add spaces before or inside a command unless the saved preset name itself contains a space.

The Master recognizes the :BS prefix, routes the complete command to the configured device with the Body role, and preserves all commas and command arguments.

BodyPCA shortcuts

Command to send	Action
:BS00-:BS31	Run an assigned user-created servo or mixed preset
:BS32	Open all drawers
:BS33	Close all drawers
:BS34	Run drawer wave
:BS35	Run drawer flutter
:BS36	Open all large doors
:BS37	Close all large doors
:BS38	Open front doors
:BS39	Close front doors
:BS40	Open rear doors
:BS41	Close rear doors
:BS42	Open both utility arms
:BS43	Close both utility arms
:BS44	Run utility-arm wave
:BS45	Run upper utility-arm wave
:BS46	Run lower utility-arm wave
:BS47	Run front-left arm show
:BS48	Run front-right arm show
:BS49	Run back-left arm show
:BS50	Run back-right arm show
:BS51	Run front arm show

Command to send	Action
:BS52	Run rear arm show
:BS53	Run all service-arm show
:BS54	Run service-arm wave
:BS55	Deploy all service arms
:BS56	Stow all service arms
:BS57	Deploy front service arms
:BS58	Stow front service arms
:BS59	Deploy rear service arms
:BS60	Stow rear service arms
:BS61	Run service-arm peek
:BS62	Run confused service-arm animation
:BS63	Run excited service-arm animation
:BS64	Run panic service-arm animation
:BS65	Run full body show
:BS66	Run body wave
:BS67	Close all body mechanisms
:BS68	Run excited personality animation
:BS69	Run short-circuit animation
:BS70	Run overload animation
:BS71	Run scream animation
:BS72	Run shiver animation
:BS73	Run scared animation
:BS74	Run complete buzzsaw sequence
:BS75	Dispense a trading card
:BS76	Run trading-card cartridge eject
:BS77	Start LED rainbow
:BS78	Start blue LED scanner
:BS79	Start red LED alert strobe
:BS80	Start blue-white LED sparkle
:BS81	Stop and clear body LEDs
:BS82-:BS89	Reserved
:BS90-:BS99	Run an assigned user-created LED-only preset

Simple body commands

The final letter selects the action: O opens, C closes, and F flutters.

Target	Open	Close	Flutter
All drawers	:BS,AD0	:BS,ADC	:BS,ADF
All large doors	:BS,ALO	:BS,ALC	:BS,ALF
All service doors	:BS,AS0	:BS,ASC	:BS,ASF
Both utility arms	:BS,AU0	:BS,AUC	:BS,AUF
Both front arm bays	:BS,AF0	:BS,AFC	:BS,AFF
Both rear arm bays	:BS,AR0	:BS,ARC	:BS,ARF
All four arm bays	:BS,AX0	:BS,AXC	:BS,AXF
Accessories X1-X3	:BS,AY0	:BS,AYC	:BS,AYF
All calibrated standard body mechanisms	:BS,AA0	:BS,AAC	:BS,AAF

Individual mechanisms use the same format:

```
:BS,D10  
:BS,FLC  
:BS,UAF  
:BS,FLL0  
:BS,FRAC  
:BS,BRLF  
:BS,X10  
:BS,X2C  
:BS,X3F
```

Open and close may include a movement time in milliseconds:

```
:BS,AD0,1500  
:BS,FLC,800
```

Flutter may include a step time and cycle count:

```
:BS,D1F,250,3  
:BS,ADF,300
```

Servo and safety commands

Command to send	Action
:BS,BT,index,percent,ms	Move one zero-based servo index
:BS,BG,mask,percent,ms	Move a configured servo group

Command to send	Action
:BS,BA,percent,ms	Move every configured standard body servo
:BS,BD,index	Stop and disable one servo output
:BS,BX	Emergency stop playback, motion, flutter, LEDs, and PCA outputs
:BS,BL	List calibration and current positions
:BS,CL	List all saved calibration values
:BS,SC,index,closed,full,enabled[,omitted]	Save servo calibration and installed state
:BS,CR,index	Restore one servo's factory calibration
:BS,CR,ALL	Restore all factory calibration values

Preset commands

Command to send	Action
:BS,PR,name	Run a saved or factory named preset
:BS,PL	List presets and their BodyPCA shortcut assignments
:BS,PD,name	Delete one user-created preset
:BS,PX	Stop named-preset playback

LED commands

Use a saved segment name or ALL as the target.

Command to send	Action
:BS,LC,target,R,G,B[,W]	Set a solid LED color
:BS,LE,target,effect,R,G,B,W,speed,level,rainbow	Start an LED effect
:BS,LO,target	Turn one LED target off
:BS,LB,brightness	Set and save global brightness from 0-255
:BS,LL	List LED strip and segment configuration
:BS,LX	Stop effects and turn the complete body strip off

Examples:

```
:BS,LC,ALL,0,0,255
:BS,LE, LONG_DATA_PORT,2,0,0,255,0,5,9,0
:BS,LO,COIN_SLOTS
:BS,LX
```

Buzzsaw commands

Command to send	Action
:BS,BZ,D,FWD	Drive the buzzsaw deploy servo forward
:BS,BZ,D,REV	Drive the buzzsaw deploy servo in reverse
:BS,BZ,D,STOP	Stop the buzzsaw deploy servo
:BS,BZ,M,ON	Turn the buzzsaw motor signal on
:BS,BZ,M,OFF	Turn the buzzsaw motor signal off

Trading-card commands

Command to send	Action
:BS,TC,M,ON	Turn the trading-card dispenser motor on
:BS,TC,M,OFF	Turn the trading-card dispenser motor off
:BS,TC,E,EJECT	Move the cartridge-eject servo to eject
:BS,TC,E,HOME	Return the cartridge-eject servo home
:BS,TC,E,STOP	Stop the cartridge-eject servo

Web Config and help

Command to send	Action
:BS,WEB,ON	Start the BodyPCA configuration access point
:BS,WEB,OFF	Exit Web Config and reboot into normal mode
:BS,WEB,STATUS	Print Web Config status and address
:BS,BH	Print command help

The Watch Display Device ID button may also start BodyPCA Web Config using :SCFG,<ID>. Users normally select the device on the Watch Display rather than entering that system command manually.