

DroidLink Complete Command Reference

This searchable reference lists the user-facing commands supported by the DroidLink projects in this workspace. Enter these commands in a Watch Display button, RC mapping, Master Sequence, or another DroidLink command field unless marked **USB Console only**.

Current firmware source is the authority. Internal transport and developer-only messages are intentionally omitted.

Quick prefix index

Prefix	Device or purpose	Example
:AS	Master DFPlayer audio	:AS025
:CM	Master system control	:CM03
:DC	Master dome movement	:DC, LEFT
:DM / :DP	Drive/dome tuning	:DM, MAX, 0.30
:MS	Master Sequence	:MS05
:RCP	RC button profile	:RCP2
:SM	Sentry Mode	:SMON
:SCFG	Device setup	:SCFG, 5
:BS , :B1S ...	Body/Body Maestro	:BS07
:DS , :D1S ...	Dome/AstroPixels Maestro	:D1S07
:LS , :L1S ...	Lifter/Lifter Maestro	:LS07
:US , :U1S ...	Universal-role DroidLink Slave/Maestro	:US07
:LE	Slave LED strip	:LE5, 1, 20, 80
:MP	MagicPanel	:MPT57
:PS	Periscope	:PSQ4

Master system

Command	Result
:CM02	Toggle dome enabled/disabled.
:CM03	Toggle drive motors enabled/disabled. Blocked during runtime Web Config.
:CM04	Select Slow drive mode.
:CM05	Select Normal drive mode.
:CM06	Select Turbo drive mode.
:CM07	Select Calibration drive mode.
:CM09	Start runtime Web Config; drive output is disabled.
:CM0B	Stop runtime Web Config.

RC profiles (V2.1.0)

Command	Result
:RCP1 - :RCP4	Select RC Profile 1-4.
:RCPNEXT	Select next profile, wrapping from 4 to 1.
:RCPPREV	Select previous profile, wrapping from 1 to 4.
:RCPQ	Request active profile state for the Watch Display.

The Master always boots into Profile 1. Optional profile feedback is configured in the Master Web UI.

Dome movement

Command	Result
:DC, LEFT	Move dome left.
:DC, RIGHT	Move dome right.
:DC, STOP	Stop dome movement.

Display movement is momentary. In a Master Sequence, movement continues until :DC, STOP .

Drive and dome tuning

These are normally sent by Watch Display tuning screens.

Command	Result
:DMQ	Request active drive-profile values.
:DM,MAX,value	Set maximum drive speed for active mode.
:DM,ACC,value	Set drive acceleration.
:DM,DEC,value	Set drive deceleration.
:DM,SPIN,value	Set drive spin value.
:DPQ	Request dome-profile values.
:DP,MAX,value	Set maximum dome speed.
:DP,ACC,value	Set dome acceleration.
:DP,DEC,value	Set dome deceleration.

Master Sequences, delays, and Sentry

Command	Result
:MS00 - :MS31	Run saved Master Sequence 00-31.
:Wmilliseconds	Delay a chained command, such as :W1000 .
:SMON	Start Sentry using saved settings.
:SMOFF	Stop Sentry and apply saved shutdown behavior.
:SM:min:max:sound:domeMs	Legacy configure/start with fixed dome duration.
:SM:min:max:sound:domeMin:domeMax	Legacy configure/start with random dome duration.

Up to three sequence IDs may follow a legacy Sentry command: :SM:2:4:SAD:300:700,MS00,MS01,MS02 .

Example chain: :BS01:W1000:DS02 . A delay begins when reached; it does not wait for the previous action or audio track to finish. The Master accepts up to six chunks in a temporary chain.

Device setup

Command	Result
:SCFG,nodeID	Reboot the configured device with that ID into setup/config mode. Example: :SCFG,5 .

Master audio / DFPlayer

Command	Result
:AS001 - :AS255	Play numbered MP3-folder track.
:AS000 or :AS00	Stop playback.
:ASPAUSE	Pause.
:ASRES	Resume.
:ASNEXT / :ASPREV	Next/previous track.
:ASV+ / :ASV-	Raise/lower volume by 3.
:ASV00 - :ASV30	Set and save exact volume.
:ASGEN	Random General track.
:ASCHAT	Random Chat track.
:ASHAP	Random Happy track.
:ASPROC	Random Processing track.
:ASSAD	Random Sad track.
:ASSENT	Random Sentimental track.
:ASWHIS	Random whistle-category track.
:ASHUM	Random Hum track.
:ASSCRE	Random Scream track.
:ASOOH	Random Ooh track.
:ASALARM	Random Alarm track.
:ASRAZZ	Random Razz track.
:ASWHIST	Random Whist track.
:ASMUS	Random Music track.
:ASRND	Random category and track.

Slave and Maestro routing

`nn` is a Maestro script number from `00` through `99` .

Command family	Result
:BSnn	Run script on all Body Maestro positions.
:B1Snn , :B2Snn , :B3Snn	Run script on one Body Maestro position.
:DSnn	Run script on all Dome/AstroPixels Maestro positions.
:D1Snn , :D2Snn	Run script on one Dome/AstroPixels Maestro position.
:LSnn	Run script on all Lifter Maestro positions.
:L1Snn , :L2Snn ...	Run script on one Lifter Maestro position.
:USnn	Run script on all Universal Maestro positions.
:U1Snn , :U2Snn ...	Run script on one Universal Maestro position.

Examples: :BS00 , :B2S07 , :DS15 , :D1S03 .

Slave LED strip

Format: :LEeffect,color,speed,brightness

Effect	Name	Effect	Name
0	Off	9	Sparkle
1	Rainbow	10	Twinkle
2	Breathe	11	Color wipe
3	Cylon	12	Comet
4	Confetti	13	Strobe
5	Solid	14	Police
6	Fire	15	Converge
7	Wave	16	End flash
8	Scanner		

Colors: 0 White, 1 Red, 2 Green, 3 Blue, 4 Yellow, 5 Purple, 6 Cyan, 7 Aqua, 8 Orange, 9 Pink.
Speed is 1 - 255 ; brightness is 0 - 255 . Example: :LE5,1,20,80 .

Periscope

Periscope commands use :PS plus the native command. A sequence command selects the sequence. When lights are off, send :PS0N to display it.

Command	Result
:PS0N	Turn lights on and display selected sequence.
:PS0FF	Turn lights off.
:PSX	Emergency off.
:PS?	Status/help through USB Console routing.
:PSQ0	Classic R2 Startup
:PSQ1	Party Mode
:PSQ2	Bright Pulse
:PSQ3	Communication Mode
:PSQ4	Police Lights
:PSQ5	Red Alert
:PSQ6	Knight Rider
:PSQ7	Searchlight
:PSQ8	Stealth Mode
:PSQ9	Diving
:PSQ10	Surfacing
:PSQ11	Calm Blue
:PSQ12	System Boot
:PSQ13	Fire Mode
:PSQ14	Celebration
:PSQ15	Charging
:PSQ16	Hyperdrive
:PSQ17	Malfunction
:PSQ18	Scan Complete
:PSQ19	Sonar Ping
:PSQ20	Auto Demo Mode

Custom format: :PS[group][effect][color][speed] . Group is M Main, T Top, or A All. Examples:
:PSM185 (Main white pulse), :PST647 (Top blue chase), :PSA199 (All pink fast).

USB Console only: NEWMAC repeats Master-MAC setup. Direct USB commands omit :PS , such as Q4 , OFF , or M185 .

Patterns

Command	Result
<code>:MPTpattern</code>	Run pattern.
<code>:MPTpattern,seconds</code>	Run for 1-3600 seconds.
<code>:MPTpattern,Ccolor</code>	Run using preset color 0-9.
<code>:MPTpattern,seconds,Ccolor</code>	Supply duration and color.
<code>:MPSPattern</code>	Alternate pattern form.

Examples: `:MPT56` , `:MPT56,10` , `:MPT56,C2` , `:MPT62,30,C5` , `:MPS57` .

Control, settings, and text

Command	Result
:MPA / :MPON	All LEDs on.
:MPD / :MPOFF	All LEDs off.
:MP!	Cancel and clear panel.
:MPDEMO	Smart Demo.
:MPP0 / :MPP1	Timed/always-on mode.
:MPC0 - :MPC9	Preset color; 9 is rainbow.
:MPCr,g,b	Custom RGB, each 0-255.
:MPB0 - :MPB255	Brightness.
:MPV1 - :MPV100	Speed.
:MPSP1 - :MPSP100	Alternate speed command.
:MPTRANSITION0 / :MPTRANSITION1	Smooth transitions off/on.
:MPSAVE / :MPLOAD	Save/reload settings.
:MPAUTOSAVE0 / :MPAUTOSAVE1	Automatic saving off/on.
:MPSTARTpattern	Save startup pattern; :MPSTART0 clears it.
:MPSTATUS	Print settings to USB Console.
:MPHELP / :MPHELP FULL	Print quick/full help.
:MPLIST	Print pattern list.
:MPTEXT:your text	Scroll text, including spaces.
:MPTEXT_BOUNCE:your text	Bounce text.
:MPTEXTSAVE0:your text	Save text in slot 0; slots 0-9.
:MPTEXTLOAD0	Load and scroll saved text slot.
:MPFONT0 / :MPFONT1	Standard/Aurebesh font.
:MPPLAYLIST_RUN:57,62,109	Run temporary pattern list.
:MPNEWMAC	Repeat Master-MAC setup.
:MPNEWPROFILE	Repeat Matrix profile selection.

Pattern ranges

IDs	Contents
0 - 7	Off/on, timed-on, toggle, alerts
8 - 15	Directional trace fill/line
16 - 19	Expand/compress fill/ring
20 - 30	Cross, Cylon, eye scan, fades, flashes, loops
31 - 47	Tests, logos, quadrants, random pixel, countdowns, faces, heart, checkerboard
48 - 51	Compress-in/explode-out
52 - 55	VU meter directions
56 - 68	Heartbeat, rainbow, fire, twinkle, plasma, Life, Matrix, cube, kaleidoscope, rain, drip, Pac-Man, Invaders
80	Bouncing text
97 - 98	Scrolling text variants
99	Test all
100 - 119	PSI colors/motion and R2 communication/thinking/alert
200	Smart Demo

See [MagicPanel Command Reference](#) for individual pattern names.

DroidLink_AP

DroidLink_AP displays the commands appropriate for its selected Maestro, PCA9685, or Marcdino controller mode on the **Commands** page inside Web Config. See [Installing and setting up DroidLink_AP](#) for installation, wiring, templates, and Web Config access.

The current development source also provides the following upcoming commands; they are not included in the current V1.1.0 Installer release:

Command	Action
:DS<n>O	Move positional-servo output <n> to Full, or turn an on/off output on.
:DS<n>C	Move positional-servo output <n> to Closed, or turn an on/off output off.
:DS<n>T	Toggle positional-servo output <n> between Closed and Full.
:DS<n>F	Run 360-degree servo output <n> forward.
:DS<n>R	Run 360-degree servo output <n> in reverse.
:DS<n>S	Stop 360-degree servo output <n> at its saved Stop pulse.

<n> is the zero-based output number displayed in DroidLink_AP Web Config. Custom output names do not alter these command numbers.

DroidLink Slave

DroidLink Slave uses BS, DS, LS, or US according to its configured Body, Dome, Lifter, or Universal role. Saved controller sequences use shortcuts 00 through 59; 60 restores startup lighting, 61 turns configured lighting off, and LED-only sequences use 62 through 91.

Use the [DroidLink Slave Command Reference](#) for direct output, sequence, lighting, Web Config, stop, and return-home commands. Output calibration and sequence creation are performed in the Slave Web Config interface.

External prefixes and console setup

Mixed chains recognize :, *, @, \$, !, %, #, &. Native DroidLink commands start with :; other prefixes are forwarded only when their adapter is configured. Example: :BS01:W500@APLE51000.

USB Console command	Device	Result
NEWMAC	Periscope, MagicPanel, supported nodes	Repeat Master-MAC setup.
NEWPROFILE	MagicPanel	Repeat Matrix profile setup.
HELP / HELP FULL	MagicPanel	Print help.
LIST	MagicPanel	Print patterns.
STATUS	MagicPanel	Print settings.

Safety

- Test drive and dome operation with the droid safely supported and clear of people.
- :CM03 is not a substitute for a physical power disconnect.
- End sequence-driven dome movement with :DC,STOP.
- Use unique device IDs and correct saved MAC addresses.

Last source audit: 2026-08-28.