

DroidLink MagicPanel Command Reference

Document revision 1 — Reviewed September 26, 2026

MagicPanel commands begin with `:MP`. Send them from a Watch Display button, RC mapping, Master Sequence, or another supported DroidLink command source.

Pattern format

```
:MPT<pattern>
:MPT<pattern>,<seconds>
:MPT<pattern>,C<color>
:MPT<pattern>,<seconds>,C<color>
```

Examples:

Command	Result
<code>:MPT56</code>	Run Animated Heart.
<code>:MPT56,10</code>	Run Animated Heart for 10 seconds.
<code>:MPT56,C2</code>	Run Animated Heart in blue.
<code>:MPT56,10,C2</code>	Run Animated Heart for 10 seconds in blue.
<code>:MPT62,30,C5</code>	Run Matrix Rain for 30 seconds in cyan.
<code>:MPDEMO</code>	Run Smart Demo.
<code>:MP!</code>	Stop the current animation and clear the panel.

S is also accepted as an alternate pattern prefix, such as `:MPS57`.

Timed and always-on modes

Command	Result
<code>:MPP0</code>	Timed mode; supplied durations are honored.
<code>:MPP1</code>	Always-on mode; continuous patterns remain active.

Select timed mode before relying on a duration:

```
:MPP0
:MPT56,10,C2
```

Duration must be from 1 through 3600 seconds.

Power and basic control

DroidLink MagicPanel Command Reference - Document Revision 1 - September 26, 2026

Command	Result
:MPA or :MPON	Turn all LEDs on.
:MPD or :MPOFF	Turn all LEDs off.
:MP!	Cancel the current animation and clear the panel.

Colors

Command	Result
:MPC<n>	Select preset color 0–8; 9 selects rainbow.
:MPC<r>,<g>,	Select a custom RGB color using values 0–255.

Examples:

```
:MPC2
:MPC25,100,255
```

Brightness, speed, and transitions

Command	Result
:MPB<n>	Brightness from 0 through 255.
:MPV<n>	Animation speed from 1 through 100.
:MPSP<n>	Alternate speed command from 1 through 100.
:MPTRANSITION0	Disable smooth transitions.
:MPTRANSITION1	Enable smooth transitions.

Text

Command	Result
:MPTEXT:HELLO THERE	Scroll the supplied text.
:MPTEXT_BOUNCE:R2-D2	Display bouncing text.
:MPTEXTSAVE0:HELLO	Save text in slot 0.
:MPTEXTLOAD0	Load and scroll text from slot 0.
:MPFONT0	Use the standard font.
:MPFONT1	Use the Aurebesh font.

Persistent settings

DroidLink MagicPanel Command Reference - Document Revision 1 - September 26, 2026

Command	Result
:MPSAVE	Save current panel settings.
:MPLOAD	Reload saved panel settings.
:MPAUTOSAVE0	Disable automatic saving.
:MPAUTOSAVE1	Enable automatic saving and save current settings.
:MPSTART<n>	Save pattern n as the fixed startup pattern.
:MPSTART0	Clear the fixed startup pattern.
:MPSTATUS	Print current settings to the USB Console.

Example setup:

```
:MPC5
:MPB100
:MPV50
:MPTRANSITION1
:MPT57
:MPSAVE
```

Help and pattern list

Command	Result
:MPHELP	Print quick help to the USB Console.
:MPHELP FULL	Print extended help.
:MPLIST	Print the complete supported pattern list.

The complete pattern-number table and additional examples are included below.

Recovery

Command	Result
NEWMAC	Enter through the USB Console to clear the Master MAC and reboot into setup.
NEWPROFILE	Enter through the USB Console to clear the Matrix profile and reboot into selection.

These are local USB Console recovery commands and are not routed through the DroidLink Master. After **NEWMAC**, DroidLink control cannot resume until the Master MAC is entered again through the MagicPanel setup Console.

Temporary playlist

```
:MPPLAYLIST_RUN:57,62,109
```

This runs the listed patterns in sequence. Playlist save/load is not currently implemented.

Troubleshooting commands

- Confirm the command begins with `:MP`.
- Do not place spaces inside pattern commands.
- Separate pattern, duration, and color with commas.
- Confirm the pattern supports the selected matrix profile.
- Confirm MagicPanel is connected to the correct Master.
- Confirm the same unique Device ID and MagicPanel MAC are saved in Master Config.