

DroidLink Master Command Reference

Document revision 1 — Reviewed September 26, 2026

This reference was checked against the released Master V2.0.1 source and the Master V2.1.0 locked-testing source on September 26, 2026. It contains only commands owned or interpreted by the Master. Commands belonging to DroidLink Slave, DroidLink_AP, MagicPanel, Periscope, and external serial devices remain in their own guides or Web Config interfaces.

Master V2.0.1 commands

Dome and drive state

These commands change physical-motion state. Test with the droid safely supported and keep an accessible physical power disconnect available.

Availability	Command	Action	Important behavior
Public	:CM02	Toggle dome output enabled or disabled	This is a toggle, not an explicit ON command. The Master reports the resulting state to the Watch Display.
Public	:CM03	Toggle drive motors enabled or disabled	This is a toggle. Drive enabling is blocked while normal Runtime Web Config is active.
Public	:CM04	Select Slow drive mode	Uses the saved Slow-mode limits.
Public	:CM05	Select Normal drive mode	Uses the saved Normal-mode limits.
Public	:CM06	Select Turbo drive mode	Uses the saved Turbo-mode limits.
Public	:DC, LEFT	Rotate the dome left	A Watch Display command is momentary. In a Master Sequence it remains active until :DC, STOP or the sequence ends.
Public	:DC, RIGHT	Rotate the dome right	A Watch Display command is momentary. In a Master Sequence it remains active until :DC, STOP or the sequence ends.
Public	:DC, STOP	Stop dome rotation	Use after every intentional sequence-driven dome movement.

CM02 and CM03 deliberately toggle the current state. Do not use them when an automation must guarantee a particular starting state without first knowing the current state.

Master Runtime Web Config

Availability	Command	Action	Important behavior
Public	:CM09	Start Master Runtime Web Config	Stops Sentry, Master Sequences, dome motion, audio, and drive output during the transition. Drive output remains locked while normal Runtime Web Config is active.
Public	:CM0B	Exit Master Runtime Web Config	Stops active actions during the transition. Closing Web Config does not automatically enable drive motors.

Master Sequences

Availability	Command	Action	Important behavior
Public	:MS00 through :MS31	Run the saved Master Sequence in that slot	An undefined slot does nothing. A second Master Sequence does not start while one is already running.

Create, edit, run, and cancel Master Sequences in Master Runtime Web Config. Canceling a sequence prevents unsent steps but cannot undo a command already received by another device.

Sentry Mode

Availability	Command	Action	Important behavior
Public	:SMON	Start Sentry Mode using the saved Web Config settings	Sentry always starts off after a Master reboot. Optional saved behavior may enable the dome.
Public	:SMOFF	Stop Sentry scheduling and apply the saved shutdown behavior	Depending on saved settings, a Sentry-started Master Sequence may finish or be canceled. Dome and audio shutdown follow the saved Sentry options.

Configure Sentry behavior in Master Runtime Web Config.

Device Web Config

Availability	Command	Action	Important behavior
Public	:SCFG, <device ID>	Ask the configured device with that DroidLink Device ID to restart in Web Config mode	Valid user-device IDs are 2 through 13. The Watch Display DEVICE ID buttons create this command automatically. Device ID 0 is the Master and is intentionally rejected by this route.

Master DFPlayer audio

These commands require the optional Master DFPlayer hardware and correctly named files in the DFPlayer /MP3 folder.

Availability	Command	Action
Public	:AS001 through :AS255	Play that numbered MP3-folder track
Public	:AS00 or :AS000	Stop playback
Public	:ASPAUSE	Pause playback
Public	:ASRES	Resume playback
Public	:ASNEXT	Play the next numbered track, wrapping after 255
Public	:ASPREV	Play the previous numbered track, wrapping before 1
Public	:ASV+ / :ASV-	Raise or lower volume by 3
Public	:ASV00 through :ASV30	Set and save an exact volume
Public	:ASGEN	Play a random General-category track
Public	:ASCHAT	Play a random Chat-category track
Public	:ASHAP	Play a random Happy-category track
Public	:ASPROC	Play a random Processing-category track
Public	:ASSAD	Play a random Sad-category track
Public	:ASSENT	Play a random Sentimental-category track
Public	:ASWHIS	Play a random Whistle-category track
Public	:ASHUM	Play a random Hum-category track
Public	:ASSCRE	Play a random Scream-category track
Public	:ASOOH	Play a random Ooh-category track
Public	:ASALARM	Play a random Alarm-category track
Public	:ASRAZZ	Play a random Razz-category track
Public	:ASWHIST	Play a random Whist-category track
Public	:ASMUS	Play a random Music-category track
Public	:ASRND	Choose a random configured category and track

The similarly named `:ASWHIS` and `:ASWHIST` commands are both implemented and select different track ranges.

Display command chains and delays

Availability	Command or format	Action	Important behavior
Public	:W<milliseconds>	Delay the next item in a temporary command chain	This is meaningful inside a chain received from the Display. It does not wait for audio or another device action to finish.
Public	Up to six prefixed command chunks in one chain	Run the chunks in order	Supported chunk-prefix characters are <code>:</code> , <code>*</code> , <code>@</code> , <code>\$</code> , <code>!</code> , <code>%</code> , <code>#</code> , and <code>&</code> . Non- <code>:</code> commands depend on configured external hardware.

Example:

:DC,RIGHT:W500:DC,STOP

DroidLink Master Command Reference · Document Revision 1 · September 26, 2026

This begins rightward dome movement, waits 500 milliseconds, and sends the stop command. Sequence-driven dome movement must always end with a stop command.

Master V2.1.0 locked-testing commands

These commands are not available in normal Master V2.0.1. They require a license authorized for Master V2.1.0 locked testing and a compatible Watch Display.

Availability	Command	Action	Important behavior
Testing only	:RCP1 through :RCP4	Select RC button Profile 1 through 4	The Master boots into Profile 1.
Testing only	:RCPNEXT	Select the next RC profile, wrapping after Profile 4	Profile switching is blocked while guarded Web Drive Tuning is armed.
Testing only	:RCPPREV	Select the previous RC profile, wrapping before Profile 1	Profile switching is blocked while guarded Web Drive Tuning is armed.
Testing only	:RCPQ	Request the active RC profile state	Intended for compatible Display synchronization and normally sent automatically.