

DroidLink Complete Command Reference

Document revision 2 — Revised September 26, 2026

This searchable reference lists the user-facing commands supported by the DroidLink projects in this workspace. Enter these commands in a Watch Display button, RC mapping, Master Sequence, or another DroidLink command field unless marked **USB Console only**.

Current firmware source is the authority. Internal transport and developer-only messages are intentionally omitted.

Quick prefix index

Prefix	Device or purpose	Example
:AS	Master DFPlayer audio	:AS025
:CM	Master system control	:CM03
:DC	Master dome movement	:DC, LEFT
:DM / :DP	Drive/dome tuning	:DM, MAX, 0.30
:MS	Master Sequence	:MS05
:RCP	RC button profile	:RCP2
:SM	Sentry Mode	:SMON
:SCFG	Device setup	:SCFG, 5
:BS , :B1S ...	Body/Body Maestro	:BS07
:DS , :D1S ...	Dome/AstroPixels Maestro	:D1S07
:LS , :L1S ...	Lifter/Lifter Maestro	:LS07
:US , :U1S ...	Universal-role DroidLink Slave/Maestro	:US07
:LE	Slave LED strip	:LE5, 1, 20, 80
:MP	MagicPanel	:MPT57
:PS	Periscope	:PSQ4

Master system

DroidLink Complete Command Reference • Document Revision 2 • September 26, 2026

Command	Result
:CM02	Toggle dome enabled/disabled.
:CM03	Toggle drive motors enabled/disabled. Blocked during runtime Web Config.
:CM04	Select Slow drive mode.
:CM05	Select Normal drive mode.
:CM06	Select Turbo drive mode.
:CM07	Select Calibration drive mode.
:CM09	Start runtime Web Config; drive output is disabled.
:CM0B	Stop runtime Web Config.

RC profiles (V2.1.0)

Command	Result
:RCP1 - :RCP4	Select RC Profile 1-4.
:RCPNEXT	Select next profile, wrapping from 4 to 1.
:RCPPREV	Select previous profile, wrapping from 1 to 4.
:RCPQ	Request active profile state for the Watch Display.

The Master always boots into Profile 1. Optional profile feedback is configured in the Master Web UI.

Dome movement

Command	Result
:DC, LEFT	Move dome left.
:DC, RIGHT	Move dome right.
:DC, STOP	Stop dome movement.

Display movement is momentary. In a Master Sequence, movement continues until :DC,STOP .

Drive and dome tuning

These are normally sent by Watch Display tuning screens.

Command	Result
:DMQ	Request active drive profile values.
:DM,MAX,value	Set maximum drive speed for active mode.
:DM,ACC,value	Set drive acceleration.
:DM,DEC,value	Set drive deceleration.
:DM,SPIN,value	Set drive spin value.
:DPQ	Request dome-profile values.
:DP,MAX,value	Set maximum dome speed.
:DP,ACC,value	Set dome acceleration.
:DP,DEC,value	Set dome deceleration.

Master Sequences, delays, and Sentry

Command	Result
:MS00 - :MS31	Run saved Master Sequence 00-31.
:Wmilliseconds	Delay a chained command, such as :W1000 .
:SMON	Start Sentry using saved settings.
:SMOFF	Stop Sentry and apply saved shutdown behavior.
:SM:min:max:sound:domeMs	Legacy configure/start with fixed dome duration.
:SM:min:max:sound:domeMin:domeMax	Legacy configure/start with random dome duration.

Up to three sequence IDs may follow a legacy Sentry command: :SM:2:4:SAD:300:700,MS00,MS01,MS02 .

Example chain: :BS01:W1000:DS02 . A delay begins when reached; it does not wait for the previous action or audio track to finish. The Master accepts up to six chunks in a temporary chain.

Device setup

Command	Result
:SCFG,nodeID	Reboot the configured device with that ID into setup/config mode. Example: :SCFG,5 .

Master audio / DFPlayer

DroidLink Complete Command Reference - Document Revision 2 - September 26, 2026

Command	Result
:AS001 - :AS255	Play numbered MP3-folder track.
:AS000 or :AS00	Stop playback.
:ASPAUSE	Pause.
:ASRES	Resume.
:ASNEXT / :ASPREV	Next/previous track.
:ASV+ / :ASV-	Raise/lower volume by 3.
:ASV00 - :ASV30	Set and save exact volume.
:ASGEN	Random General track.
:ASCHAT	Random Chat track.
:ASHAP	Random Happy track.
:ASPROC	Random Processing track.
:ASSAD	Random Sad track.
:ASSENT	Random Sentimental track.
:ASWHIS	Random whistle-category track.
:ASHUM	Random Hum track.
:ASSCRE	Random Scream track.
:AS00H	Random Ooh track.
:ASALARM	Random Alarm track.
:ASRAZZ	Random Razz track.
:ASWHIST	Random Whist track.
:ASMUS	Random Music track.
:ASRND	Random category and track.

Slave and Maestro routing

nn is a Maestro script number from 00 through 99.

Command family	Result
:BSnn DroidLink Complete Commands Reference Body Maestro Revision 2 September 26, 2026	Run script on all Body Maestro positions.
:B1Snn , :B2Snn , :B3Snn	Run script on one Body Maestro position.
:DSnn	Run script on all Dome/AstroPixels Maestro positions.
:D1Snn , :D2Snn	Run script on one Dome/AstroPixels Maestro position.
:LSnn	Run script on all Lifter Maestro positions.
:L1Snn , :L2Snn ...	Run script on one Lifter Maestro position.
:USnn	Run script on all Universal Maestro positions.
:U1Snn , :U2Snn ...	Run script on one Universal Maestro position.

Examples: :BS00 , :B2S07 , :DS15 , :D1S03 .

Slave LED strip

Format: :LEeffect,color,speed,brightness

Effect	Name	Effect	Name
0	Off	9	Sparkle
1	Rainbow	10	Twinkle
2	Breathe	11	Color wipe
3	Cylon	12	Comet
4	Confetti	13	Strobe
5	Solid	14	Police
6	Fire	15	Converge
7	Wave	16	End flash
8	Scanner		

Colors: 0 White, 1 Red, 2 Green, 3 Blue, 4 Yellow, 5 Purple, 6 Cyan, 7 Aqua, 8 Orange, 9 Pink. Speed is 1 - 255 ; brightness is 0 - 255 . Example: :LE5,1,20,80 .

Periscope

Periscope commands use :PS plus the native command. A sequence command selects the sequence. When lights are off, send :PS0N to display it.

Command	Result
:PSON	Turn lights on and display selected sequence.
:PSOFF	Turn lights off.
:PSX	Emergency off.
:PS?	Status/help through USB Console routing.
:PSQ0	Classic R2 Startup
:PSQ1	Party Mode
:PSQ2	Bright Pulse
:PSQ3	Communication Mode
:PSQ4	Police Lights
:PSQ5	Red Alert
:PSQ6	Knight Rider
:PSQ7	Searchlight
:PSQ8	Stealth Mode
:PSQ9	Diving
:PSQ10	Surfacing
:PSQ11	Calm Blue
:PSQ12	System Boot
:PSQ13	Fire Mode
:PSQ14	Celebration
:PSQ15	Charging
:PSQ16	Hyperdrive
:PSQ17	Malfunction
:PSQ18	Scan Complete
:PSQ19	Sonar Ping
:PSQ20	Auto Demo Mode

Custom format: :PS[group][effect][color][speed] . Group is **M** Main, **T** Top, or **A** All. Examples: :PSM185 (Main white pulse), :PST647 (Top blue chase), :PSA199 (All pink fast).

USB Console only: **NEWMAC** repeats Master-MAC setup. Direct USB commands omit :PS , such as Q4 , OFF , or M185 .

Patterns

Command	Result
:MPTpattern	Run pattern.
:MPTpattern,seconds	Run for 1-3600 seconds.
:MPTpattern,Ccolor	Run using preset color 0-9.
:MPTpattern,seconds,Ccolor	Supply duration and color.
:MPSpattern	Alternate pattern form.

Examples: :MPT56 , :MPT56,10 , :MPT56,C2 , :MPT62,30,C5 , :MPS57 .

Control, settings, and text

Command	Result
:MPA / :MPON	All LEDs on.
:MPD / :MPOFF	All LEDs off.
:MP!	Cancel and clear panel.
:MPDEMO	Smart Demo.
:MPP0 / :MPP1	Timed/always-on mode.
:MPC0 - :MPC9	Preset color; 9 is rainbow.
:MPCr,g,b	Custom RGB, each 0-255.
:MPB0 - :MPB255	Brightness.
:MPV1 - :MPV100	Speed.
:MPSP1 - :MPSP100	Alternate speed command.
:MPTRANSITION0 / :MPTRANSITION1	Smooth transitions off/on.
:MPSAVE / :MPLoad	Save/reload settings.
:MPAUTOSAVE0 / :MPAUTOSAVE1	Automatic saving off/on.
:MPSTARTpattern	Save startup pattern; :MPSTART0 clears it.
:MPSTATUS	Print settings to USB Console.
:MPHELP / :MPHELP FULL	Print quick/full help.
:MPLIST	Print pattern list.
:MPTEXT:your text	Scroll text, including spaces.
:MPTEXT_BOUNCE:your text	Bounce text.
:MPTEXTSAVE0:your text	Save text in slot 0; slots 0-9.
:MPTEXTLOAD0	Load and scroll saved text slot.
:MPFONT0 / :MPFONT1	Standard/Aurebesh font.
:MPPLAYLIST_RUN:57,62,109	Run temporary pattern list.
:MPNEWMAC	Repeat Master-MAC setup.
:MPNEWPROFILE	Repeat Matrix profile selection.

Pattern ranges

IDs	Contents
0 - 7	Off/on, timed-on, toggle, alerts
8 - 15	Directional trace fill/line
16 - 19	Expand/compress fill/ring
20 - 30	Cross, Cylon, eye scan, fades, flashes, loops
31 - 47	Tests, logos, quadrants, random pixel, countdowns, faces, heart, checkerboard
48 - 51	Compress-in/explode-out
52 - 55	VU meter directions
56 - 68	Heartbeat, rainbow, fire, twinkle, plasma, Life, Matrix, cube, kaleidoscope, rain, drip, Pac-Man, Invaders
80	Bouncing text
97 - 98	Scrolling text variants
99	Test all
100 - 119	PSI colors/motion and R2 communication/thinking/alert
200	Smart Demo

See [MagicPanel Command Reference](#) for individual pattern names.

DroidLink_AP

DroidLink_AP displays the commands appropriate for its selected Maestro, PCA9685, or Marcdino controller mode on the **Commands** page inside Web Config. See the [DroidLink_AP Complete Guide](#) for installation, wiring, templates, and Web Config access.

The current development source also provides the following upcoming commands; they are not included in the current V1.1.0 Installer release:

Command	Action
:DS<n>O	Move positional-servo output <n> to Full, or turn an on/off output on.
:DS<n>C	Move positional-servo output <n> to Closed, or turn an on/off output off.
:DS<n>T	Toggle positional-servo output <n> between Closed and Full.
:DS<n>F	Run 360-degree servo output <n> forward.
:DS<n>R	Run 360-degree servo output <n> in reverse.
:DS<n>S	Stop 360-degree servo output <n> at its saved Stop pulse.

<n> is the zero-based output number displayed in DroidLink_AP Web Config. Custom output names do not alter these command numbers.

DroidLink Slave

DroidLink Slave uses `BS`, `DS`, `LS`, or `US` according to its configured Body, Dome, Lifter, or Universal role. Saved controller sequences use shortcuts `00` through `59`; `60` restores startup lighting, `61` turns configured lighting off, and LED-only sequences use `62` through `91`.

The **Commands** tab in Slave Web Config is the authoritative command reference because it displays the correct role prefix and Device ID for that controller. The [DroidLink Slave Complete Guide](#) contains the same user command list. Output calibration, sequence creation, and shortcut assignment are performed in Web Config.

External prefixes and console setup

Mixed chains recognize `:`, `*`, `@`, `$`, `!`, `%`, `#`, &. Native DroidLink commands start with `:`; other prefixes are forwarded only when their adapter is configured. Example: `:BS01:W500@APLE51000`.

USB Console command	Device	Result
NEWMAC	Periscope, MagicPanel, supported nodes	Repeat Master-MAC setup.
NEWPROFILE	MagicPanel	Repeat Matrix profile setup.
HELP / HELP FULL	MagicPanel	Print help.
LIST	MagicPanel	Print patterns.
STATUS	MagicPanel	Print settings.

Safety

- Test drive and dome operation with the droid safely supported and clear of people.
- `:CM03` is not a substitute for a physical power disconnect.
- End sequence-driven dome movement with `:DC,STOP`.
- Use unique device IDs and correct saved MAC addresses.

Last source audit: 2026-08-28.