

FLAME_WAKEUP

About :

Pluto drone is equipped with a flame sensor to takeoff automatically, when fire is detected. It is an application to automate takeoff, incase of any fire.

Add-On used :

A flame sensor module is basically just a IR reciver module, which detects the fire by using the IR waves emitting from it.



Components and Connection:

Pluto drone, flame_sensor module and connecting wires.

Connect the Sound sensor on the RC port of Primus V5/X2 board

Primus V5/X2 pin	Peripherals
VCC on RC port	VCC on flame_module
GND on RC port	GND on flame_module
Signal on RC port	D0 on flame_module

How does it work?

Flame sensor module is basically an instrument to detect IR waves emitting from hot objects:

- Normal reading → 1 = no takeoff
- Fire detected → 0 = take-off

PlutoBlocks



Working:

Initially, we set receiver mode as ESP .

When loop begins, we constantly evaluate whether the flame sensor detects any flame. We then evaluate to land it or take off, depending on the reading of flame sensor.



Fig: Flame sensor with Pluto

Moving further

Try adding more features to help make firefighting operations more efficient.

Try making a flame follower drone.