

How to open the signature function

1. Precautions

Please note that during the development and debugging phase, do not enable the signature function. After the development and debugging are completed, enable the signature function again. After the signature function is turned on, it only supports updating the signed firmware.

2. Generate signature certificate

Please note that the certificate in the engineering demo is the default certificate for the DSPREAD prototype.

Please contact technical support personnel to obtain the certificate.

The certificate includes boot certificate and APP certificate.

3. Update certificate

Please replace the existing engineering certificate with the new APP certificate obtained. The directory is as follows:

App certs : DS10\demo\ql-cross-tool\sign\

Please replace the existing engineering certificate with the new BOOT certificate obtained. The directory is as follows.

Boot certs : DS10\demo\ql-config\quec-project\aboot\config\security\key\

4. Open the signature function

1. Run "secboot.bat"

```
=====
1、Close SecBoot
2、OPEN SecBoot
0、quit
Please select item number, then click enter button:
```

2. Select 2 option to open signature function

Functional Configuration

```
=====
1、Close SecBoot
2、OPEN SecBoot
0、quit
Please select item number, then click enter button:2
复制 1 个文件。
复制 1 个文件。
复制 1 个文件。
复制 1 个文件。
\git\DS10\demo\ql-config\quec-project\aboot\config\template\CRANELRH_QUEC_TEMPLATE_
复制 1 个文件。
\git\DS10\demo\ql-config\quec-project\aboot\config\partition\CRANELRH_QUEC_FLASH_LA
复制 1 个文件。
复制 1 个文件。
-----Sign Open Success-----
Press Any Key to exit
```