How to use the XML Updater

Step1:

You can see here are six files in the tool folder. Delete the last two bin files first.

emv_app.bin	2018/8/9 18:32	BIN 文件	9 KB
emv_capk.bin	2018/8/9 18:32	BIN 文件	17 KB
emv_profile_tlv	2018/8/10 9:48	XML 文件	73 KB
■ old_emv_profile_to_bin	2018/8/7 14:10	应用程序	60 KB
ucrtbased.dll	2018/8/7 14:10	应用程序扩展	1,609 KB
vcruntime140d.dll	2018/8/7 14:10	应用程序扩展	111 KB

## Step2:

Put your XML file, which you already changed, in this folder and replace the emv\_profile\_tlv. Please make sure your new XML file name is also emv\_profile\_tlv.

emv_profile_tlv	2018/8/10 9:48	XML 文件	73 KB
old_emv_profile_to_bin	2018/8/7 14:10	应用程序	60 KB
ucrtbased.dll	2018/8/7 14:10	应用程序扩展	1,609 KB
vcruntime140d.dll	2018/8/7 14:10	应用程序扩展	111 KB

## Step3:

Click the old\_emv\_profile\_to\_bin file to get the new two bin files – emv\_app.bin and emv\_capk.bin.

## Step4:

Open the Demo and use the new two bin files to replace the old one in the assets. Then, run the code.

