# Ship Air Watch Console

A practical guide to the Marine and Air listening interface




### RADIO OPERATOR #2




*Numbered faceplate reference; controls can vary slightly by display mode.*

## 1 DISPLAY AND MAP

- **POWER** blacks out LCD, local audio, and panel indicators. Receiver services keep running.
- **DIM** cycles three brightness levels. **DISPLAY** switches waveform/waterfall.
- **MENU** opens Settings; press again to return to Marine. **SETUP** opens History.
- **PHONES** mutes/restores local headphone audio.
- Tabs select Marine, AIS, Weather, Ports, or Settings.
- Map controls choose Marine/Air; **EXPAND** opens the larger map.

## 2 RECEIVE AND LISTEN

- **BAND** selects Air, Marine, Ham, or Local FRS/GMRS.
- **VOLUME** dial or +/–; buttons change volume by 5%.
- **SQUELCH** dial or +/–; buttons change one step.
- **LISTEN**: upper half starts audio; lower half stops.
- **AF GAIN** adjusts listening level. **SOL** shows squelch setting.
- Air/Marine restart rockers restart that receiver; allow time to reconnect.

## 3 TUNE AND SAVE

- **Main dial** tunes channel/frequency; wheel or arrows make small steps.
- **CHANNEL** moves previous/next. **SCAN** resumes channel cycle.
- **HOLD** parks the frequency; tuning while held fine-tunes.
- **MEM / RCL** save and recall in this browser.
- **STEP** changes tuning increment. **LOCK** prevents accidental tuning.
- **BFO / TONE** fine-tune and adjust voice tone filtering.

## NUMBERED CONTROL KEY

Match each number to the callout on the radio face.

**1 POWER**
Display and panel lights off; receivers keep running.

**2 LCD DISPLAY**
Shows frequency, map, channel list, and views.

**3 BAND**
Select Air, Marine, Ham, or Local.

**4 VOLUME**
Adjust listening level; Squelch knob is below it.

**5 LISTEN**
Upper half starts audio; lower half stops it.

**6 TUNING DIAL**
Tune frequency or channel.

**7 HOLD**
Stay on the current channel; release to resume scanning.

**8 RESTART**
Restart the Air or Marine receiver.

**9 FUNCTION KEYS**
Memory, channel, step, tone, and noise controls.

**10 USB / HISTORY**
Open History and nearby receiver information.

# Start listening in six steps

Choose a band, tune in, then listen. Mouse, touch, and keyboard controls are supported.

1

### Choose a band

Select Marine for VHF or Air for aviation; Ham and Local select those banks.

2

### Pick a view

Choose Marine, AIS, Weather, Ports, or Settings. The map switches between Marine and Air.

3

### Set the audio

Adjust Volume and Squelch. The +/– controls make small predictable changes.

4

### Listen

Press the upper half of LISTEN. Wait for audio; press the lower half to stop.

5

### Tune or scan

Use the main dial or listed channel. SCAN resumes the cycle; HOLD stays on one frequency.

6

### Save a frequency

MEM saves and RCL recalls. Saved frequencies belong to this browser.

### History and nearby receivers

- Open History with SETUP or the USB CLICK ME area.
- Review recorded ship and aircraft activity, including vessel categories when the feed provides them.
- Other Receivers lists three New Brunswick AIS-catcher stations, displayed status, and public links.
- Contact links open a draft or community page. Review before sending; nothing is sent automatically.

### Power off and recovery

- POWER blacks out the display and turns off Air/Marine indicators, Listen, Hold/Scan, and restart status lights.
- Local audio stops; receiver services continue in the background.
- Tap POWER to restore the console, then LISTEN to resume audio.
- If a receiver is not updating, use its restart rocker once and allow time to reconnect.

### Helpful notes

- Browser audio may need a click before playback is allowed.
- Higher squelch can hide weaker signals.
- EXPAND opens the larger map; close it with its dialog control.
- Reception depends on receiver, antenna, signal conditions, and channel activity.

Live reception is best-effort and may be delayed or incomplete. Use official sources for operational decisions.