# How to update firmware

To manually flash firmware using ST DFUSE tools, get a copy of ST DFUSE tools. Search for STSW-STM32080


#### Step 1

Detach your Netduino

Press and hold your Netduino's pushbutton while plugging it in via USB; this will put it in bootloader mode. Erase the firmware on your Netduino using the

#### STDFU Tester application

- a. Select the "Protocol" tab
- b. Press the "Create from Map" button
- c. Select the "Erase" radio button option
- d. Press the "Go" button
- e. Wait for the erase process to complete




#### Step 2

To create the DFU tinybooter.dfu file:

- a. Run "DFU File Manager" (from the ST DFU tools)
- b. Select "I want to GENERATE a DFU file" and press OK.
- c. Click "S19 or HEX..." and then select one of the firmware files in Netduino Update's respective Firmware folder.
- d. Click the "generate" button to generate the DFU file

Important Note: If you have a .hex file rename it to .S19


Example: Tinybooter.hex rename to Tinybooter.s19



### Step 3

## Using the DFUSE Demo Application

- a. Load TinyBooter
- b. With board still in DFU mode
- c. Click bottom right Choose select tinybooter.dfu
- d. Click Upgrade



### Step 4

Reboot
Open MFDeploy
Select USB
Bottom Browse – Select both config files
Deploy

Note: .s19 files are not shown in MFDeploy enter "\*.\*" as the File Name: and click the Open button. The .s19 files will be displayed

