



Technical Quick Guides

Enable Camera Audio

Log in to the **NVR**




At the upper right corner of the screen click the $\mathbf{settings}$ and \rightarrow select \mathbf{camera}






Under CAMERA tab click **Encode**




In the Encode tab, first select the channel of the camera you want to set up, then click the **"More"** button for both the Main Stream and Sub Stream.





Check the **"Audio"** box to enable audio for the camera. You can also adjust other settings such as Compression and Sampling Frequency, but it is recommended to keep them at the default values. Once done, click the **"OK"** button.



Click the **Apply button** after enabling the Audio.

