## Installation Guide for ALPHA release v.0.1.0

Once you download the package from web, the .dll files might be blocked. In order to
enable the dlls, please right click on each file and click Properties. Under "General"
tab, on the bottom check if there is Security item appears, then Click Unblock button to
enable the dlls.



- Before launch the Dynamo 0.7., copy the dll file under the folder "./dlls/EnergyAnalysisForDynamo\_Ul" into "C:\Program Files\Dynamo 0.7\Revit\_2014\nodes"
- 3. Now you need to importing EnergyAnalysisForDynamo library into Dynamo. Open Dynamo 0.7, go to "Libraries" tab and click "Import Library..." and select the "EnergyAnalysisForDynamo.dll" from "dlls/EnergyAnalysisForDynamo" folder.

Note: You need to repeat this step #3 every time you open a new instance of Dynamo.

