

1. Install MATLAB apps : AUTOSAR blockset , Embedded coder, Simulink Coder.
2. Follow below links to import a model and AUTOSAR arxml files to update model with connection information.

https://in.mathworks.com/help/autosar/ug/create-an-autosar-software-component-in-simulink.html#mw_1a65cc20-5f3b-469d-a7bc-55c987033eef

<https://in.mathworks.com/help/autosar/ug/configure-autosar-ports-using-sl-bus-ports.html>

<https://in.mathworks.com/help/autosar/ug/configure-autosar-adaptive-elements-and-properties.html>

3. To work on a model with all the expected AUTOSAR info , use command “openExample('autosar_swc')” in the MATLAB command window.

Demo :

1. Using the input provided by MATLAB “openExample('autosar_swc')” combining with our flex AUTOSAR data. Below test input is created. Changes done on file FlexECUDemoApplicationSoftware.arxml Line 46 and 51 , changed R and P port names.

FlexECUDemo Matlab.zip

2. Run the directory windows product on this input data.

3. Seamless (

