ETAS FlexECU-G1 0.7l 3 cyl. Turbo / V6.2.0 / 3

EHANDBOOK Demo

Generated by
EHANDBOOK Container-Build 14.4.0 RC 1
on 15.10.2026

© ETAS GmbH reserves all rights even in the event of industrial property rights.
We reserve all rights of disposal such as copying and passing on to third parties.

Table of Contents

1 About EHANDBOOK FlexECU Demo 4
2 Actuators - Actuators Value Treatment 5
3 Afr - Air Fuel Ratio 13
4 Amf - Air Mass Flow 14
5 CAN Calibration in Gasoline FlexECU 16
6 Dummy - Component Control 17
7 Epm - Engine Position Management 19
8 Fmc - Fuel Mass Calculation 20
9 Iac - Ignition Angle Calculation 21
10 Icc - Inter Cooler Calculation 22
11 Isc - Idle Speed Control 23
12 Itc - Injection Time Calculation 26
13 Lcc - Lambda Correction Calculation 28
14 Opm - Operation Mode 30
15 Sensors - Sensor Value Treatment 31
16 Stc - Starter Calculation 38
17 T2t - Torque to throttle calculation 40
18 Tqs - Torque Structure 43

Function view (alphabetical order)

About EHANDBOOK FlexECU Demo 4
Actuators - Actuators Value Treatment 5
Afr - Air Fuel Ratio 13
Amf - Air Mass Flow 14
CAN Calibration in Gasoline FlexECU 16
Dummy - Component Control 17
Epm - Engine Position Management 19
Fmc - Fuel Mass Calculation 20
Iac - Ignition Angle Calculation 21
Icc - Inter Cooler Calculation 22
Isc - Idle Speed Control 23
Itc - Injection Time Calculation 26
Lcc - Lambda Correction Calculation 28
Opm - Operation Mode 30
Sensors - Sensor Value Treatment 31
Stc - Starter Calculation 38
T2t - Torque to throttle calculation 40
Tqs - Torque Structure 43

About EHANDBOOK FlexECU Demo

© ETAS GmbH reserves all rights even in the event of industrial property rights. We reserve all rights of disposal such as copying and passing on to third parties.

Actuators - Actuators Value Treatment

2.1 Systemconstant-Parameter-Variable-Classinstance-Structure

2.1.1 Parameter

Name	Access	Long name	Mode	Type
Ais_flgAirInjReacPumpOverride	READ-WRITE	Codeword - Switches the secondary air pump on or off	local	VALUE
Ais_stAirInjReacPumpMan	READ-WRITE	Exemplary description for Ais_stAirInjReacPumpMan	local	VALUE
Amc_uSens2AirMassFlow_CUR	READ-WRITE	Linearisation of external HFM signal for comparison to pressure based engine air massflow	local	CUR
Apv_facAirPumpRateMan	READ-WRITE	Factor for calculating the duty cycle for secondary air pump valve - manually calibrateable override	local	VALUE
Apv_factor	READ-WRITE	Duty cycle for secondary air pump valve	local	VALUE
Apv_flgAirPumpRateOverride	READ-WRITE	Switch to override calculated duty cycle of secondary air pump valve by calibrateable one	local	VALUE
Apv_tiPeriod_C	READ-WRITE	Exemplary description for Apv_tiPeriod_C	local	VALUE
Cov_facChOverVlvRateMan	READ-WRITE	Exemplary description for Cov_facChOverVlvRateMan	local	VALUE
Cov_factor	READ-WRITE	Exemplary description for Cov_factor	local	VALUE
Cov_flgChOverVlvRateOverride	READ-WRITE	Exemplary description for Cov_flgChOverVlvRateOverride	local	VALUE
Cov_tiPeriod_C	READ-WRITE	Exemplary description for Cov_tiPeriod_C	local	VALUE
Cpc_atManiTmp2facPresCorr_CUR	READ-WRITE	Correction factor of charge pressure - temperature dependent	local	CUR
Cpc_uSens2pManiBase_CUR	READ-WRITE	Exemplary description for Cpc_uSens2pManiBase_CUR	local	CUR
Ctc_rSens2atCool_CUR	READ-WRITE	Engine coolant temperature - sensor linearisation	local	CUR
Doh_OutputDiagnosisOverride	READ-WRITE	Exemplary description for Doh_OutputDiagnosisOverride	local	VALUE

© ETAS GmbH reserves all rights even in the event of industrial property rights. We reserve all rights of disposal such as copying and passing on to third parties.

Name	Access	Long name	Mode	Type
Fps_flgFuelPumpOverride	READ-WRITE	Exemplary description for Fps_flgFuelPumpOverride	local	VALUE
Fps_stFuelPumpMan	READ-WRITE	Exemplary description for Fps_stFuelPumpMan	local	VALUE
Icc_degIgnMan	READ-WRITE	Exemplary description for Icc_degIgnMan	local	VALUE
Icc_flgIgnAngleOverride	READ-WRITE	Exemplary description for Icc_flgIgnAngleOverride	local	VALUE
Icc_flgIgnCutoffMan	READ-WRITE	Exemplary description for Icc_flgIgnCutoffMan	local	VALUE
Icc_flgIgnCutoffOverride	READ-WRITE	Exemplary description for Icc_flgIgnCutoffOverride	local	VALUE
Icc_nrFollowUpSparks	READ-WRITE	Exemplary description for Icc_nrFollowUpSparks	local	VALUE
Icc_tiDwell	READ-WRITE	Exemplary description for Icc_tiDwell	local	VALUE
Icc_tiDwellFollowUpSparks	READ-WRITE	Exemplary description for Icc_tiDwellFollowUpSparks	local	VALUE
Icc_tiOffFollowUpSparks	READ-WRITE	Exemplary description for Icc_tiOffFollowUpSparks	local	VALUE
Ics_flgIntercoolerOverride	READ-WRITE	Exemplary description for Ics_flgIntercoolerOverride	local	VALUE
Ics_stIntercoolerMan	READ-WRITE	Exemplary description for Ics_stIntercoolerMan	local	VALUE
Ivc_degInjAbort	READ-WRITE	Exemplary description for Ivc_degInjAbort	local	VALUE
Ivc_degIntakeClose	READ-WRITE	Exemplary description for Ivc_degIntakeClose	local	VALUE
Ivc_degOffsetInjEndSimultanInj	READ-WRITE	Exemplary description for Ivc_degOffsetInjEndSimultanInj	local	VALUE
Ivc_flgBattDelayOverride	READ-WRITE	Exemplary description for Ivc_flgBattDelayOverride	local	VALUE
Ivc_flgDiagEntryCondFulfilled	READ-WRITE	Exemplary description for Ivc_flgDiagEntryCondFulfilled	local	VALUE
Ivc_flgEndOfStartCond	READ-WRITE	Exemplary description for Ivc_flgEndOfStartCond	local	VALUE

© ETAS GmbH reserves all rights even in the event of industrial property rights. We reserve all rights of disposal such as copying and passing on to third parties.

Name	Access	Long name	Mode	Type
Ivc_flgInjCutoff	READ-WRITE	Exemplary description for Ivc_flgInjCutoff	local	VALUE
Ivc_flgInjCutoffOverride	READ-WRITE	Exemplary description for Ivc_flgInjCutoffOverride	local	VALUE
Ivc_flgInjTimeOverride	READ-WRITE	Exemplary description for Ivc_flgInjTimeOverride	local	VALUE
Ivc_flgOverrunCutoff	READ-WRITE	Exemplary description for Ivc_flgOverrunCutoff	local	VALUE
Ivc_flgPostInjCond	READ-WRITE	Exemplary description for Ivc_flgPostInjCond	local	VALUE
Ivc_tiBatVoltDelay	READ-WRITE	Exemplary description for Ivc_tiBatVoltDelay	local	VALUE
Ivc_tiBattDelayMan	READ-WRITE	Exemplary description for Ivc_tiBattDelayMan	local	VALUE
Ivc_tiInjEff	READ-WRITE	Exemplary description for Ivc_tiInjEff	local	VALUE
Ivc_tiInjMan	READ-WRITE	Exemplary description for Ivc_tiInjMan	local	VALUE
Ivc_tiMinThresDeltaEffInjPeriod	READ-WRITE	Exemplary description for Ivc_tiMinThresDeltaEffInjPeriod	local	VALUE
Ivc_weea0	READ-WRITE	Exemplary description for Ivc_weea0	local	VALUE
Ivc_weea1	READ-WRITE	Exemplary description for Ivc_weea1	local	VALUE
Ivc_weea2	READ-WRITE	Exemplary description for Ivc_weea2	local	VALUE
Ivc_weea3	READ-WRITE	Exemplary description for Ivc_weea3	local	VALUE
Ivc_weea4	READ-WRITE	Exemplary description for Ivc_weea4	local	VALUE
Ivc_weea5	READ-WRITE	Exemplary description for Ivc_weea5	local	VALUE
Ivc_weea6	READ-WRITE	Exemplary description for Ivc_weea6	local	VALUE
Ivc_weea7	READ-WRITE	Exemplary description for Ivc_weea7	local	VALUE
Lmc_VU2hPaP_CUR	READ-WRITE	Exemplary description for Lmc_VU2hPaP_CUR	local	CUR
Lmc_hPaP2facPresCompLean_CUR	READ-WRITE	Exemplary description for Lmc_hPaP2facPresCompLean_CUR	local	CUR
Lmc_hPaP2facPresCompRich_CUR	READ-WRITE	Exemplary description for Lmc_hPaP2facPresCompRich_CUR	local	CUR

© ETAS GmbH reserves all rights even in the event of industrial property rights. We reserve all rights of disposal such as copying and passing on to third parties.

Name	Access	Long name	Mode	Type
Lmc_uAlp2LambE85_CUR	READ-WRITE	Exemplary description for Lmc_uAlp2LambE85_CUR	local	CUR
Lmc_uAlp2LambGasol_CUR	READ-WRITE	Exemplary description for Lmc_uAlp2LambGasol_CUR	local	CUR
Mpc_atManiTmp2facPresCorr_CUR	READ-WRITE	Manifold air pressure - curve - temperature dependend drift correction of pressure sensor voltage	local	CUR
Mpc_uSens2pManiBase_CUR	READ-WRITE	Manifold air pressure - curve - linearization of pressure sensor voltage to pressure	local	CUR
Mrs_flgMainRelaisOverride	READ-WRITE	Exemplary description for Mrs_flgMainRelaisOverride	local	VALUE
Mrs_stMainRelaisMan	READ-WRITE	Exemplary description for Mrs_stMainRelaisMan	local	VALUE
Mtc_rSens2atMani_CUR	READ-WRITE	Manifold air temperature - curve - linearization of temperature sensor resistance to temperature	local	CUR
Str_flgStarterOverride	READ-WRITE	Exemplary description for Str_flgStarterOverride	local	VALUE
Str_stStarterMan	READ-WRITE	Exemplary description for Str_stStarterMan	local	VALUE
Tvc_facDutycyclePIDLimitMax	READ-WRITE	Exemplary description for Tvc_facDutycyclePIDLimitMax	local	VALUE
Tvc_facDutycyclePIDLimitMin	READ-WRITE	Exemplary description for Tvc_facDutycyclePIDLimitMin	local	VALUE
Tvc_facDutycyclePilotControlNeg	READ-WRITE	Exemplary description for Tvc_facDutycyclePilotControlNeg	local	VALUE
Tvc_facDutycyclePilotControlPos	READ-WRITE	Exemplary description for Tvc_facDutycyclePilotControlPos	local	VALUE
Tvc_facKDutycycle	READ-WRITE	Exemplary description for Tvc_facKDutycycle	local	VALUE
Tvc_facThrValveDutycycleMan	READ-WRITE	Exemplary description for Tvc_facThrValveDutycycleMan	local	VALUE
Tvc_facThrValveLimitMax	READ-WRITE	Exemplary description for Tvc_facThrValveLimitMax	local	VALUE

© ETAS GmbH reserves all rights even in the event of industrial property rights. We reserve all rights of disposal such as copying and passing on to third parties.

Name	Access	Long name	Mode	Type
Tvc_facThrValveLimitMin	READ-WRITE	Exemplary description for Tvc_facThrValveLimitMin	local	VALUE
Tvc_facThrValveReqMan	READ-WRITE	Exemplary description for Tvc_facThrValveReqMan	local	VALUE
Tvc_flgThrValveDutycycleOverride	READ-WRITE	Exemplary description for Tvc_flgThrValveDutycycleOverride	local	VALUE
Tvc_flgThrValveReqOverride	READ-WRITE	Exemplary description for Tvc_flgThrValveReqOverride	local	VALUE
Tvc_tiPeriod_C	READ-WRITE	Exemplary description for Tvc_tiPeriod_C	local	VALUE
Tvc_tiTnDutycycle	READ-WRITE	Exemplary description for Tvc_tiTnDutycycle	local	VALUE
Tvc_tiTvDutycycle	READ-WRITE	Exemplary description for Tvc_tiTvDutycycle	local	VALUE
Tvc_uSens2facThrValve1_CUR	READ-WRITE	Exemplary description for Tvc_uSens2facThrValve1_CUR	local	CUR
Tvc_uSens2facThrValve2_CUR	READ-WRITE	Exemplary description for Tvc_uSens2facThrValve2_CUR	local	CUR
Tvc_uSensMaxValid	READ-WRITE	Exemplary description for Tvc_uSensMaxValid	local	VALUE
Tvc_uSensMinValid	READ-WRITE	Exemplary description for Tvc_uSensMinValid	local	VALUE
Wcc_atCoolantHyst	READ-WRITE	Exemplary description for Wcc_atCoolantHyst	local	VALUE
Wcc_atCoolantMax	READ-WRITE	Exemplary description for Wcc_atCoolantMax	local	VALUE
Wcs_flgWaterCoolerOverride	READ-WRITE	Water cooling system - override the actual status with the manually preset one - for calibration purpose only	local	VALUE
Wcs_stWaterCoolerMan	READ-WRITE	Water cooling system - desired, manually set status - for calibration purpose only	local	VALUE
Wgc_facWasteGateRateMan	READ-WRITE	Desired, manually set waste gate rate - for calibration purpose only	local	VALUE
Wgc_factor	READ-WRITE	Exemplary description for Wgc_factor	local	VALUE
Wgc_flgWastegateRateOverride	READ-WRITE	Override the actual waste gate rate with the manually preset one -	local	VALUE

© ETAS GmbH reserves all rights even in the event of industrial property rights. We reserve all rights of disposal such as copying and passing on to third parties.

Name	Access	Long name	Mode	Type
		for calibration purpose only		
Wgc_tiPeriod_C	READ-WRITE	Exemplary description for Wgc_tiPeriod_C	local	VALUE

2.1.2 Variable

Name	Access	Long name	Mode	Type
Ais_flgError	READ-ONLY	Exemplary description for Ais_flgError	local	VALUE
Ais_stAirInjReacPump	READ-ONLY	Exemplary description for Ais_stAirInjReacPump	local	VALUE
Apv_facAirPumpRate	READ-ONLY	Factor for calculating the duty cycle for secondary air pump valve	local	VALUE
Apv_flgError	READ-ONLY	Error flag of Air Pump Valve	local	VALUE
Cov_facChOverVlvRate	READ-ONLY	Exemplary description for Cov_facChOverVlvRate	local	VALUE
Cov_flgError	READ-ONLY	Exemplary description for Cov_flgError	local	VALUE
Ctc_atCool	READ-ONLY	Engine Coolant Temperature	import	VALUE
Doh_flgErrorDiagnosis	READ-ONLY	Exemplary description for Doh_flgErrorDiagnosis	export	VALUE
Eoh_flgOutputError	READ-ONLY	Error Flag of Error Evaluation Output	export	VALUE
Epm_rpmEngSpd	READ-ONLY	Engine speed	import	VALUE
Fps_flgError	READ-ONLY	Error Flag of Fuel Mass Calculation	local	VALUE
Fps_stFuelPump	READ-ONLY	Exemplary description for Fps_stFuelPump	local	VALUE
Iac_degIgnIdleSpeed	READ-ONLY	Exemplary description for Iac_degIgnIdleSpeed	import	VALUE
Iac_flgIgnCutoff	READ-ONLY	Exemplary description for Iac_flgIgnCutoff	import	VALUE
Icc_flgError	READ-ONLY	Exemplary description for Icc_flgError	local	VALUE
Icc_stIgnFadeOutReq	READ-ONLY	Exemplary description for Icc_stIgnFadeOutReq	local	VALUE
Ics_flgError	READ-ONLY	Exemplary description for Ics_flgError	local	VALUE
Ics_stIntercooler	READ-ONLY	Exemplary description for Ics_stIntercooler	local	VALUE

© ETAS GmbH reserves all rights even in the event of industrial property rights. We reserve all rights of disposal such as copying and passing on to third parties.

Name	Access	Long name	Mode	Type
Itc_flgInjCutoff	READ-ONLY	Exemplary description for Itc_flgInjCutoff	import	VALUE
Itc_tiBattDelay	READ-ONLY	Exemplary description for Itc_tiBattDelay	import	VALUE
Itc_tiInj	READ-ONLY	Exemplary description for Itc_tiInj	import	VALUE
Ivc_flgError	READ-ONLY	Exemplary description for Ivc_flgError	local	VALUE
Ivc_stCutoffPattern	READ-ONLY	Exemplary description for Ivc_stCutoffPattern	local	VALUE
Ivc_tiBatVoltDelay_1	READ-ONLY	Exemplary description for Ivc_tiBatVoltDelay_1	local	VALUE
Ivc_tiBattDelay	READ-ONLY	Exemplary description for Ivc_tiBattDelay	local	VALUE
Mrs_flgError	READ-ONLY	Exemplary description for Mrs_flgError	local	VALUE
Mrs_stMainRelais	READ-ONLY	Exemplary description for Mrs_stMainRelais	local	VALUE
Opm_idxMode	READ-ONLY	Engine status - off / normal / IOerror - protect the engine in case of serious faults	import	VALUE
Stc_stStarter	READ-ONLY	Exemplary description for Stc_stStarter	import	VALUE
Str_flgError	READ-ONLY	Exemplary description for Str_flgError	local	VALUE
Str_stStarter	READ-ONLY	Exemplary description for Str_stStarter	local	VALUE
T2t_facWasteGateRate	READ-ONLY	Exemplary description for T2t_facWasteGateRate	import	VALUE
Tvc_facDutycycle	READ-ONLY	Exemplary description for Tvc_facDutycycle	local	VALUE
Tvc_facDutycycleCorr	READ-ONLY	Exemplary description for Tvc_facDutycycleCorr	local	VALUE
Tvc_facThrValve	READ-ONLY	Exemplary description for Tvc_facThrValve	local	VALUE
Tvc_facThrValve1	READ-ONLY	Exemplary description for Tvc_facThrValve1	local	VALUE
Tvc_facThrValve2	READ-ONLY	Exemplary description for Tvc_facThrValve2	local	VALUE
Tvc_facThrValveReq	READ-ONLY	Exemplary description for Tvc_facThrValveReq	local	VALUE
Tvc_flgError	READ-ONLY	Exemplary description for Tvc_flgError	local	VALUE
Tvc_flgPosError	READ-ONLY	Exemplary description for Tvc_flgPosError	local	VALUE

© ETAS GmbH reserves all rights even in the event of industrial property rights. We reserve all rights of disposal such as copying and passing on to third parties.

Name	Access	Long name	Mode	Type
Tvc_stIO1	READ-ONLY	Exemplary description for Tvc_stIO1	local	VALUE
Tvc_stIO2	READ-ONLY	Exemplary description for Tvc_stIO2	local	VALUE
Tvc_uSens1	READ-ONLY	Exemplary description for Tvc_uSens1	local	VALUE
Tvc_uSens2	READ-ONLY	Exemplary description for Tvc_uSens2	local	VALUE
Wcs_flgError	READ-ONLY	Water cooling system - status flag - consolidated error	local	VALUE
Wcs_stWaterCooler	READ-ONLY	Status of engine cooling system - large / small cooling circle active	local	VALUE
Wgc_facWasteGateRate	READ-ONLY	Actual waste gate rate	local	VALUE
Wgc_flgError	READ-ONLY	Exemplary description for Wgc_flgError	local	VALUE
dummy_facAirPumpRate	READ-ONLY	Exemplary description for dummy_facAirPumpRate	import	VALUE
dummy_facChOverVlvRate	READ-ONLY	Exemplary description for dummy_facChOverVlvRate	import	VALUE
dummy_facThrValveReq	READ-ONLY	Exemplary description for dummy_facThrValveReq	import	VALUE
dummy_stAirInjReacPump	READ-ONLY	Exemplary description for dummy_stAirInjReacPump	import	VALUE
dummy_stFuelPump	READ-ONLY	Exemplary description for dummy_stFuelPump	import	VALUE
dummy_stIntercooler	READ-ONLY	Exemplary description for dummy_stIntercooler	import	VALUE
dummy_stMainRelais	READ-ONLY	Exemplary description for dummy_stMainRelais	import	VALUE

© ETAS GmbH reserves all rights even in the event of industrial property rights. We reserve all rights of disposal such as copying and passing on to third parties.

Afr - Air Fuel Ratio

3.1 Systemconstant-Parameter-Variable-Classinstance-Structure

3.1.1 Parameter

Name	Access	Long name	Mode	Type
Afr_atCool2facLambdaReqCorr_CUR	READ-WRITE	Lambda correction - offset - dependent on engine coolant temperature	local	CUR
Afr_atMani2facLambdaReqCorr_CUR	READ-WRITE	Lambda correction - offset - dependent on intake air temperature	local	CUR
Afr_facLambdaReqMan	READ-WRITE	Lambda Correction Factor - manual Override	local	VALUE
Afr_facRatioMan	READ-WRITE	Air fuel ratio - correction factor - manual override	local	VALUE
Afr_facStoich	READ-WRITE	Stoichiometric factor for calculation of air fuel ratio	local	VALUE
Afr_flgLambdaReqOverride	READ-WRITE	Codeword - switches between lambda of O2-sensor and calibrated lambda	local	VALUE
Afr_flgRatioOverride	READ-WRITE	Air Fuel Ratio - manually calibrateable override	local	VALUE
Afr_rpmEngSpdfacRelAir2facLambdaReqBase_MAP	READ-WRITE	Lambda correction map - dependent on engine speed and engine load	local	MAP

3.1.2 Variable

Name	Access	Long name	Mode	Type
Afr_facLambdaReq	READ-ONLY	Dump Storage - Lambda Correction Factor of Fuel Injection Quantity	export	VALUE
Afr_facLambdaReqCalc	READ-ONLY	Dump storage - lambda correction factor of fuel injection quantity	local	VALUE
Afr_facRatio	READ-ONLY	Air fuel ratio	export	VALUE
Afr_facRatioCalc	READ-ONLY	Air fuel ratio - calculation result buffer	local	VALUE
Amf_facRelAir	READ-ONLY	Relative air charge	import	VALUE
Ctc_atCool	READ-ONLY	Engine Coolant Temperature	import	VALUE
Epm_rpmEngSpd	READ-ONLY	Engine speed	import	VALUE
Mtc_atMani	READ-ONLY	Manifold air temperature	import	VALUE

© ETAS GmbH reserves all rights even in the event of industrial property rights. We reserve all rights of disposal such as copying and passing on to third parties.

Amf - Air Mass Flow

4.1 Systemconstant-Parameter-Variable-Classinstance-Structure

4.1.1 Parameter

Name	Access	Long name	Mode	Type
Amf_facRelAirMan	READ-WRITE	Relative air charge - manually Calibrateable	local	VALUE
Amf_flgAirMassPerStrOverride	READ-WRITE	Codeword - switches between ECU calculated engine air mass and manually Calibrateable one	local	VALUE
Amf_flgRelAirOverride	READ-WRITE	Codeword - switches between ECU calculated engine air mass and manually Calibrateable one	local	VALUE
Amf_flgSwitch2AirMassFlowMeter	READ-WRITE	Codeword - switches between ECU calculated engine air mass and manually Calibrateable one	local	VALUE
Amf_mAirPerStrMan	READ-WRITE	Calibrateable engine air mass per stroke	local	VALUE
Amf_pManiEngSpd2facRelAirCorr_MAP	READ-WRITE	Engine air mass dependent on engine speed and manifold pressure	local	MAP
Amf_rpmEngSpd2facTempCorr_CUR	READ-WRITE	Correction factor of engine air temperature dependent on engine speed	local	CUR
Amf_shcSpecGasConst_C	READ-WRITE	Specific gas constant	local	VALUE
Amf_volEngDisp_C	READ-WRITE	Engine displacement	local	VALUE

4.1.2 Variable

Name	Access	Long name	Mode	Type
Amc_AirMassFlow	READ-ONLY	Engine Air Massflow	import	VALUE
Amf_atAirIntake	READ-ONLY	Air temperature at air intake	local	VALUE
Amf_facMRelAir100	READ-ONLY	Factor for air mass per stroke calculation	local	VALUE
Amf_facRelAir	READ-ONLY	Relative air charge	export	VALUE
Amf_facRelAirBase	READ-ONLY	Relative air charge - basis value dependent on manifold pressure	local	VALUE
Amf_facRelAirCalc	READ-ONLY	Buffer for calculating the relative air charge	local	VALUE
Amf_facRelAirTempCorr	READ-ONLY	Correction factor - ratio between standard tem	local	VALUE

© ETAS GmbH reserves all rights even in the event of industrial property rights. We reserve all rights of disposal such as copying and passing on to third parties.

Name	Access	Long name	Mode	Type
		perature and real temp erature at air intake		
Amf_facRelAir_AirMas sFlowMeter	READ-ONLY	Exemplary description for Amf_facRelAir_Air MassFlowMeter	local	VALUE
Amf_mAirCalc	READ-ONLY	Engine air mass per s troke	local	VALUE
Amf_mAirPerStr	READ-ONLY	Exemplary description for Amf_mAirPerStr	export	VALUE
Amf_mAirPerStrCalc	READ-ONLY	Calculated engine air mass per stroke	local	VALUE
Amf_mAirPerStroke_A irMassFlowMeter	READ-ONLY	Engine air mass per s troke	local	VALUE
Amf_rohAirDen	READ-ONLY	Calculated engine air density	local	VALUE
Ctc_atCool	READ-ONLY	Engine Coolant Temp erature	import	VALUE
Epm_rpmEngSpd	READ-ONLY	Engine speed	import	VALUE
Mpc_pManiFilt	READ-ONLY	Manifold air pressure - filtered - temperature c ompensated	import	VALUE
Mtc_atMani	READ-ONLY	Manifold air temperatu re	import	VALUE

© ETAS GmbH reserves all rights even in the event of industrial property rights. We reserve all rights of disposal such as copying and passing on to third parties.

CAN Calibration in Gasoline FlexECU

5.1 Systemconstant-Parameter-Variable-Classinstance-Structure

5.1.1 Parameter

Name	Access	Long name	Mode	Type
CAN_ChID_Enable	READ-WRITE	Enable the bit to 1 to c hange the message ID	local	VALUE
CAN_ChId_MsgId	READ-WRITE	Message Id for CAN	local	VALUE
CAN_Node_Select	READ-WRITE	Exemplary description for CAN_Node_Select	local	VALUE
CAN_Test_Param	READ-WRITE	Test parameter of 4 by tes	local	VALUE

5.1.2 Variable

Name	Access	Long name	Mode	Type
CAN_Present_Node	READ-ONLY	Exemplary description for CAN_Present_No de	local	VALUE
CAN_UpdateStatus_M sgId	READ-ONLY	Status for updation of message ID	export	VALUE
CAN_Update_Status_ Tx	READ-ONLY	Status message after the transfer of bytes in CAN	local	VALUE
Epm_rpmEngSpd	READ-ONLY	Engine speed	import	VALUE

© ETAS GmbH reserves all rights even in the event of industrial property rights. We reserve all rights of disposal such as copying and passing on to third parties.

Dummy - Component Control

6.1 Systemconstant-Parameter-Variable-Classinstance-Structure

6.1.1 Parameter

Name	Access	Long name	Mode	Type
dummy_StarterReq	READ-WRITE	Exemplary description for dummy_StarterReq	local	VALUE
dummy_facAirPumpRateReq	READ-WRITE	Exemplary description for dummy_facAirPumpRateReq	local	VALUE
dummy_facChOverVlvRateReq	READ-WRITE	Exemplary description for dummy_facChOverVlvRateReq	local	VALUE
dummy_flgInterCoolerOverride	READ-WRITE	Exemplary description for dummy_flgInterCoolerOverride	local	VALUE
dummy_flgKl50Override	READ-WRITE	Exemplary description for dummy_flgKl50Override	local	VALUE
dummy_flgT2tOverride	READ-WRITE	Exemplary description for dummy_flgT2tOverride	local	VALUE
dummy_rpmFuelPumpMin	READ-WRITE	Exemplary description for dummy_rpmFuelPumpMin	local	VALUE
dummy_stAirInjReacPumpReq	READ-WRITE	Exemplary description for dummy_stAirInjReacPumpReq	local	VALUE
dummy_stFuelPumpReq	READ-WRITE	Exemplary description for dummy_stFuelPumpReq	local	VALUE
dummy_stIntercoolerReq	READ-WRITE	Exemplary description for dummy_stIntercoolerReq	local	VALUE
dummy_stMainRelaisReq	READ-WRITE	Exemplary description for dummy_stMainRelaisReq	local	VALUE

6.1.2 Variable

Name	Access	Long name	Mode	Type
Egc_facEgas	READ-ONLY	Acc pedal position	import	VALUE
Epm_rpmEngSpd	READ-ONLY	Engine speed	import	VALUE
ICC_flgInterCooler	READ-ONLY	Exemplary description for ICC_flgInterCooler	import	VALUE
Kl50_stKlemme50	READ-ONLY	Exemplary description for Kl50_stKlemme50	import	VALUE
T2t_facThrValveReq	READ-ONLY	Exemplary description for T2t_facThrValveReq	import	VALUE
dummy_Starter	READ-ONLY	Exemplary description for dummy_Starter	export	VALUE

© ETAS GmbH reserves all rights even in the event of industrial property rights. We reserve all rights of disposal such as copying and passing on to third parties.

Name	Access	Long name	Mode	Type
dummy_facAirPumpRate	READ-ONLY	Exemplary description for dummy_facAirPumpRate	export	VALUE
dummy_facChOverVlvRate	READ-ONLY	Exemplary description for dummy_facChOverVlvRate	export	VALUE
dummy_facThrValveReq	READ-ONLY	Exemplary description for dummy_facThrValveReq	export	VALUE
dummy_stAirInjReacPump	READ-ONLY	Exemplary description for dummy_stAirInjReacPump	export	VALUE
dummy_stFuelPump	READ-ONLY	Exemplary description for dummy_stFuelPump	export	VALUE
dummy_stIntercooler	READ-ONLY	Exemplary description for dummy_stIntercooler	export	VALUE
dummy_stMainRelais	READ-ONLY	Exemplary description for dummy_stMainRelais	export	VALUE

© ETAS GmbH reserves all rights even in the event of industrial property rights. We reserve all rights of disposal such as copying and passing on to third parties.

Epm - Engine Position Management

7.1 Systemconstant-Parameter-Variable-Classinstance-Structure

7.1.1 Variable

Name	Access	Long name	Mode	Type
Epm_rpmEngSpd	READ-ONLY	Engine speed	export	VALUE
Epm_rpmEngSpd_get	READ-ONLY	Engine speed_get	local	VALUE

© ETAS GmbH reserves all rights even in the event of industrial property rights. We reserve all rights of disposal such as copying and passing on to third parties.

Fmc - Fuel Mass Calculation

8.1 Systemconstant-Parameter-Variable-Classinstance-Structure

8.1.1 Parameter

Name	Access	Long name	Mode	Type
Fmc_facKFuelMassCorr	READ-WRITE	Exemplary description for Fmc_facKFuelMassCorr	local	VALUE
Fmc_flgFuelMassCorrEnable	READ-WRITE	Exemplary description for Fmc_flgFuelMassCorrEnable	local	VALUE
Fmc_flgFuelMassOverride	READ-WRITE	Exemplary description for Fmc_flgFuelMassOverride	local	VALUE
Fmc_mFuelMan	READ-WRITE	Exemplary description for Fmc_mFuelMan	local	VALUE

8.1.2 Variable

Name	Access	Long name	Mode	Type
Afr_facRatio	READ-ONLY	Air fuel ratio	import	VALUE
Amf_mAirPerStr	READ-ONLY	Exemplary description for Amf_mAirPerStr	import	VALUE
Epm_rpmEngSpd	READ-ONLY	Engine speed	import	VALUE
Fmc_mFuel	READ-ONLY	Exemplary description for Fmc_mFuel	export	VALUE
Fmc_mFuelBase	READ-ONLY	Exemplary description for Fmc_mFuelBase	local	VALUE
Fmc_mFuelCalc	READ-ONLY	Exemplary description for Fmc_mFuelCalc	local	VALUE
Fmc_mFuelCorr	READ-ONLY	Exemplary description for Fmc_mFuelCorr	local	VALUE
Fmc_mFuelKgPerHour	READ-ONLY	Exemplary description for Fmc_mFuelKgPerHour	local	VALUE
Fmc_specific_fuel_consumption	READ-ONLY	Exemplary description for Fmc_specific_fuel_consumption	local	VALUE
Fmc_tiTaFuelMassCorr	READ-ONLY	Exemplary description for Fmc_tiTaFuelMassCorr	local	VALUE
Itc_tiInjOffset	READ-ONLY	Exemplary description for Itc_tiInjOffset	import	VALUE
Lcc_facLambdaCorr	READ-ONLY	Exemplary description for Lcc_facLambdaCorr	import	VALUE
Tqs_tqReq	READ-ONLY	Exemplary description for Tqs_tqReq	import	VALUE

© ETAS GmbH reserves all rights even in the event of industrial property rights. We reserve all rights of disposal such as copying and passing on to third parties.

Iac - Ignition Angle Calculation

9.1 Systemconstant-Parameter-Variable-Classinstance-Structure

9.1.1 Parameter

Name	Access	Long name	Mode	Type
Iac_degIgnOptOffset	READ-WRITE	Exemplary description for Iac_degIgnOptOffset	local	VALUE
Iac_deltaDegIgn	READ-WRITE	Exemplary description for Iac_deltaDegIgn	local	CUR
Iac_flgIgnCutoffReq	READ-WRITE	Exemplary description for Iac_flgIgnCutoffReq	local	VALUE
Iac_pManiReqMin	READ-WRITE	Exemplary description for Iac_pManiReqMin	local	VALUE
Iac_rpmEngSpdfacRelAir2degBase_MAP	READ-WRITE	Exemplary description for Iac_rpmEngSpdfacRelAir2degBase_MAP	local	MAP
Iac_rpmEngSpdfacRelAir2degMinAdvBestTq_MAP	READ-WRITE	Exemplary description for Iac_rpmEngSpdfacRelAir2degMinAdvBestTq_MAP	local	MAP

9.1.2 Variable

Name	Access	Long name	Mode	Type
Amf_facRelAir	READ-ONLY	Relative air charge	import	VALUE
Epm_rpmEngSpd	READ-ONLY	Engine speed	import	VALUE
Iac_degIgn	READ-ONLY	Exemplary description for Iac_degIgn	export	VALUE
Iac_degIgnBase	READ-ONLY	Exemplary description for Iac_degIgnBase	local	VALUE
Iac_degIgnIdleSpeed	READ-ONLY	Exemplary description for Iac_degIgnIdleSpeed	export	VALUE
Iac_degMinAdvBestTq	READ-ONLY	Exemplary description for Iac_degMinAdvBestTq	export	VALUE
Iac_flgIgnCutoff	READ-ONLY	Exemplary description for Iac_flgIgnCutoff	export	VALUE
Isc_flgIdleSpdCtrlActive	READ-ONLY	Exemplary description for Isc_flgIdleSpdCtrlActive	import	VALUE
Mpc_pManiFilt	READ-ONLY	Manifold air pressure - filtered - temperature compensated	import	VALUE
T2t_pManiReqFast	READ-ONLY	Exemplary description for T2t_pManiReqFast	import	VALUE

© ETAS GmbH reserves all rights even in the event of industrial property rights. We reserve all rights of disposal such as copying and passing on to third parties.

Icc - Inter Cooler Calculation

10.1 Systemconstant-Parameter-Variable-Classinstance-Structure

10.1.1 Parameter

Name	Access	Long name	Mode	Type
ICC_atManiOff	READ-WRITE	Exemplary description for ICC_atManiOff	local	VALUE
ICC_atManiOn	READ-WRITE	Exemplary description for ICC_atManiOn	local	VALUE

10.1.2 Variable

Name	Access	Long name	Mode	Type
ICC_flgInterCooler	READ-ONLY	Exemplary description for ICC_flgInterCooler	export	VALUE
Mtc_atMani	READ-ONLY	Manifold air temperature	import	VALUE

© ETAS GmbH reserves all rights even in the event of industrial property rights. We reserve all rights of disposal such as copying and passing on to third parties.

Isc - Idle Speed Control

11.1 Systemconstant-Parameter-Variable-Classinstance-Structure

11.1.1 Parameter

Name	Access	Long name	Mode	Type
Isc_CatHeatTime2HeatingSpeed	READ-WRITE	Exemplary description for Isc_CatHeatTime2HeatingSpeed	local	CUR
Isc_EngSpdStabLimit	READ-WRITE	Exemplary description for Isc_EngSpdStabLimit	local	VALUE
Isc_EngSpdStabOverride	READ-WRITE	Exemplary description for Isc_EngSpdStabOverride	local	VALUE
Isc_FuelCutoffDelay	READ-WRITE	Exemplary description for Isc_FuelCutoffDelay	local	VALUE
Isc_FuelCutoffEnable	READ-WRITE	Exemplary description for Isc_FuelCutoffEnable	local	VALUE
Isc_IPartMax	READ-WRITE	Exemplary description for Isc_IPartMax	local	VALUE
Isc_IPartMaxCatHeat	READ-WRITE	Exemplary description for Isc_IPartMaxCatHeat	local	VALUE
Isc_IPartMin	READ-WRITE	Exemplary description for Isc_IPartMin	local	VALUE
Isc_IPartMinCatHeat	READ-WRITE	Exemplary description for Isc_IPartMinCatHeat	local	VALUE
Isc_IdleSpeedReq	READ-WRITE	Exemplary description for Isc_IdleSpeedReq	local	VALUE
Isc_Leerlaufoverride	READ-WRITE	Exemplary description for Isc_Leerlaufoverride	local	VALUE
Isc_facCatalyserHeating_CUR	READ-WRITE	Exemplary description for Isc_facCatalyserHeating_CUR	local	CUR
Isc_facEgasMin	READ-WRITE	Exemplary description for Isc_facEgasMin	local	VALUE
Isc_facEngSpdStab	READ-WRITE	Exemplary description for Isc_facEngSpdStab	local	VALUE
Isc_facIPartCatHeat_CUR	READ-WRITE	Exemplary description for Isc_facIPartCatHeat_CUR	local	CUR
Isc_facIPart_CUR	READ-WRITE	Exemplary description for Isc_facIPart_CUR	local	CUR
Isc_facIdleSpeedReq	READ-WRITE	Exemplary description for Isc_facIdleSpeedReq	local	VALUE

© ETAS GmbH reserves all rights even in the event of industrial property rights. We reserve all rights of disposal such as copying and passing on to third parties.

Name	Access	Long name	Mode	Type
Isc_facPPartCatHeat_CUR	READ-WRITE	Exemplary description for Isc_facPPartCatHeat_CUR	local	CUR
Isc_facPPart_CUR	READ-WRITE	Exemplary description for Isc_facPPart_CUR	local	CUR
Isc_flgIdleSpeedCtrlEnable	READ-WRITE	Exemplary description for Isc_flgIdleSpeedCtrlEnable	local	VALUE
Isc_rpmIdleCtrlActivMax	READ-WRITE	Exemplary description for Isc_rpmIdleCtrlActivMax	local	VALUE
Isc_rpmIdleCtrlActivMin	READ-WRITE	Exemplary description for Isc_rpmIdleCtrlActivMin	local	VALUE

11.1.2 Variable

Name	Access	Long name	Mode	Type
EdgeFalling	READ-ONLY	Exemplary description for EdgeFalling	local	VALUE
EdgeRising	READ-ONLY	Exemplary description for EdgeRising	local	VALUE
EdgeRising_1	READ-ONLY	Exemplary description for EdgeRising_1	local	VALUE
Egc_facEgas	READ-ONLY	Acc pedal position	import	VALUE
Epm_rpmEngSpd	READ-ONLY	Engine speed	import	VALUE
Isc_IdleSpdCtrlIPart	READ-ONLY	Exemplary description for Isc_IdleSpdCtrlIPart	export	VALUE
Isc_IdleSpdCtrlPPart	READ-ONLY	Exemplary description for Isc_IdleSpdCtrlPPart	export	VALUE
Isc_IdleSpeedReq1	READ-ONLY	Exemplary description for Isc_IdleSpeedReq1	local	VALUE
Isc_facIdleSpdStab	READ-ONLY	Exemplary description for Isc_facIdleSpdStab	export	VALUE
Isc_flgFuelCutoff	READ-ONLY	Exemplary description for Isc_flgFuelCutoff	export	VALUE
Isc_flgIdleSpdCtrlActive	READ-ONLY	Exemplary description for Isc_flgIdleSpdCtrlActive	export	VALUE
Stc_CatalyserHeatingTime	READ-ONLY	Exemplary description for Stc_CatalyserHeatingTime	import	VALUE
Stc_flgCalalyserHeatingDelay	READ-ONLY	Exemplary description for Stc_flgCalalyserHeatingDelay	local	VALUE
Stc_flgCatalyserHeating	READ-ONLY	Exemplary description for Stc_flgCatalyserHeating	import	VALUE

© ETAS GmbH reserves all rights even in the event of industrial property rights. We reserve all rights of disposal such as copying and passing on to third parties.

Name	Access	Long name	Mode	Type
Stc_flgStarterActive	READ-ONLY	Exemplary description for Stc_flgStarterActive	import	VALUE
cont	READ-ONLY	Exemplary description for cont	local	VALUE
cont_1	READ-ONLY	Exemplary description for cont_1	local	VALUE

© ETAS GmbH reserves all rights even in the event of industrial property rights. We reserve all rights of disposal such as copying and passing on to third parties.

Itc - Injection Time Calculation

12.1 Systemconstant-Parameter-Variable-Classinstance-Structure

12.1.1 Parameter

Name	Access	Long name	Mode	Type
Itc_flgInjCutoffMan	READ-WRITE	Exemplary description for Itc_flgInjCutoffMan	local	VALUE
Itc_flgInjTimeOverride	READ-WRITE	Exemplary description for Itc_flgInjTimeOverride	local	VALUE
Itc_mFuelMass2tiInjBase_CUR	READ-WRITE	Exemplary description for Itc_mFuelMass2tiInjBase_CUR	local	CUR
Itc_pManiFiltMax	READ-WRITE	Exemplary description for Itc_pManiFiltMax	local	VALUE
Itc_rpmEngSpdHyst	READ-WRITE	Exemplary description for Itc_rpmEngSpdHyst	local	VALUE
Itc_rpmEngSpdMax	READ-WRITE	Exemplary description for Itc_rpmEngSpdMax	local	VALUE
Itc_tiInjMan	READ-WRITE	Exemplary description for Itc_tiInjMan	local	VALUE
Itc_tiInjMin	READ-WRITE	Exemplary description for Itc_tiInjMin	local	VALUE
Itc_tiInjOffsetMan	READ-WRITE	Exemplary description for Itc_tiInjOffsetMan	local	VALUE
Itc_uBatt2tiBattDelay_CUR	READ-WRITE	Exemplary description for Itc_uBatt2tiBattDelay_CUR	local	CUR

12.1.2 Variable

Name	Access	Long name	Mode	Type
Bvc_uBatt	READ-ONLY	System voltage	import	VALUE
Epm_rpmEngSpd	READ-ONLY	Engine speed	import	VALUE
Fmc_mFuel	READ-ONLY	Exemplary description for Fmc_mFuel	import	VALUE
Hysteresis_Delta_RSP	READ-ONLY	Exemplary description for Hysteresis_Delta_RSP	local	VALUE
Iac_flgIgnCutoff	READ-ONLY	Exemplary description for Iac_flgIgnCutoff	import	VALUE
Isc_flgFuelCutoff	READ-ONLY	Exemplary description for Isc_flgFuelCutoff	import	VALUE
Itc_flgInjCutoff	READ-ONLY	Exemplary description for Itc_flgInjCutoff	export	VALUE
Itc_tiBattDelay	READ-ONLY	Exemplary description for Itc_tiBattDelay	export	VALUE
Itc_tiInj	READ-ONLY	Exemplary description for Itc_tiInj	export	VALUE

© ETAS GmbH reserves all rights even in the event of industrial property rights. We reserve all rights of disposal such as copying and passing on to third parties.

Name	Access	Long name	Mode	Type
Itc_tiInjCalc	READ-ONLY	Exemplary description for Itc_tiInjCalc	local	VALUE
Itc_tiInjOffset	READ-ONLY	Exemplary description for Itc_tiInjOffset	export	VALUE
Mpc_pManiFilt	READ-ONLY	Manifold air pressure - filtered - temperature compensated	import	VALUE
Stc_facFuelCorr	READ-ONLY	Exemplary description for Stc_facFuelCorr	import	VALUE

© ETAS GmbH reserves all rights even in the event of industrial property rights. We reserve all rights of disposal such as copying and passing on to third parties.

Lcc - Lambda Correction Calculation

13.1 Systemconstant-Parameter-Variable-Classinstance-Structure

13.1.1 Parameter

Name	Access	Long name	Mode	Type
Lcc_EngSpd2facIntegrator_CUR	READ-WRITE	Exemplary description for Lcc_EngSpd2facIntegrator_CUR	local	CUR
Lcc_IntStartValueTPC	READ-WRITE	Exemplary description for Lcc_IntStartValueTPC	local	VALUE
Lcc_LambdaCorrMaxPID	READ-WRITE	Exemplary description for Lcc_LambdaCorrMaxPID	local	VALUE
Lcc_LambdaCorrMaxTPC	READ-WRITE	Exemplary description for Lcc_LambdaCorrMaxTPC	local	VALUE
Lcc_LambdaCorrMinPID	READ-WRITE	Exemplary description for Lcc_LambdaCorrMinPID	local	VALUE
Lcc_LambdaCorrMinTPC	READ-WRITE	Exemplary description for Lcc_LambdaCorrMinTPC	local	VALUE
Lcc_StartValuePID	READ-WRITE	Exemplary description for Lcc_StartValuePID	local	VALUE
Lcc_facInitValue	READ-WRITE	Exemplary description for Lcc_facInitValue	local	VALUE
Lcc_facKLambdaCorrPID_MAP	READ-WRITE	Exemplary description for Lcc_facKLambdaCorrPID_MAP	local	MAP
Lcc_flgLambdaControlActive	READ-WRITE	Exemplary description for Lcc_flgLambdaControlActive	local	VALUE
Lcc_flgSwitch2PIDController	READ-WRITE	Exemplary description for Lcc_flgSwitch2PIDController	local	VALUE
Lcc_tiTnLambdaCorrPID_MAP	READ-WRITE	Exemplary description for Lcc_tiTnLambdaCorrPID_MAP	local	MAP
Lcc_tiTvLambdaCorrPID_MAP	READ-WRITE	Exemplary description for Lcc_tiTvLambdaCorrPID_MAP	local	MAP

13.1.2 Variable

Name	Access	Long name	Mode	Type
Afr_facLambdaReq	READ-ONLY	Dump Storage - Lambda Correction Factor of Fuel Injection Quantity	import	VALUE
EdgeFalling_1	READ-ONLY	Exemplary description for EdgeFalling_1	local	VALUE
Epm_rpmEngSpd	READ-ONLY	Engine speed	import	VALUE

© ETAS GmbH reserves all rights even in the event of industrial property rights. We reserve all rights of disposal such as copying and passing on to third parties.

Name	Access	Long name	Mode	Type
Isc_flgFuelCutoff	READ-ONLY	Exemplary description for Isc_flgFuelCutoff	import	VALUE
Lamsoni	READ-ONLY	Measured lambda	import	VALUE
Lcc_IntInitValvue	READ-ONLY	Exemplary description for Lcc_IntInitValvue	local	VALUE
Lcc_facLambdaCorr	READ-ONLY	Exemplary description for Lcc_facLambdaCorr	export	VALUE
Lcc_flgLambdacontrolActive_1	READ-ONLY	Exemplary description for Lcc_flgLambdacontrolActive_1	local	VALUE
Mpc_pManiFilt	READ-ONLY	Manifold air pressure - filtered - temperature compensated	import	VALUE
Stc_flgFuelCorrActive	READ-ONLY	Exemplary description for Stc_flgFuelCorrActive	import	VALUE

© ETAS GmbH reserves all rights even in the event of industrial property rights. We reserve all rights of disposal such as copying and passing on to third parties.

Opm - Operation Mode

14.1 Systemconstant-Parameter-Variable-Classinstance-Structure

14.1.1 Parameter

Name	Access	Long name	Mode	Type
Opm_stDiagnosisOverride	READ-WRITE	Exemplary description for Opm_stDiagnosisOverride	local	VALUE
Opm_stEngControl	READ-WRITE	Exemplary description for Opm_stEngControl	local	VALUE
Opm_stIOErrorOverride	READ-WRITE	Exemplary description for Opm_stIOErrorOverride	local	VALUE
Opm_tiIOErrorDelay	READ-WRITE	Exemplary description for Opm_tiIOErrorDelay	local	VALUE

14.1.2 Variable

Name	Access	Long name	Mode	Type
Doh_flgErrorDiagnosis	READ-ONLY	Exemplary description for Doh_flgErrorDiagnosis	import	VALUE
Eih_flgInputError	READ-ONLY	Exemplary description for Eih_flgInputError	import	VALUE
Eoh_flgOutputError	READ-ONLY	Error Flag of Error Evaluation Output	import	VALUE
Opm_flgIOErrorAct	READ-ONLY	Exemplary description for Opm_flgIOErrorAct	local	VALUE
Opm_flgInputErrorMem	READ-ONLY	Exemplary description for Opm_flgInputErrorMem	local	VALUE
Opm_flgOutputDiagnosisErrorMem	READ-ONLY	Exemplary description for Opm_flgOutputDiagnosisErrorMem	local	VALUE
Opm_flgOutputErrorMem	READ-ONLY	Exemplary description for Opm_flgOutputErrorMem	local	VALUE
Opm_idxMode	READ-ONLY	Engine status - off / normal / IOerror - protect the engine in case of serious faults	export	VALUE

© ETAS GmbH reserves all rights even in the event of industrial property rights. We reserve all rights of disposal such as copying and passing on to third parties.

Sensors - Sensor Value Treatment

15.1 Systemconstant-Parameter-Variable-Classinstance-Structure

15.1.1 Parameter

Name	Access	Long name	Mode	Type
Amc_flgAirMassFlowOverride	READ-WRITE	Switch to override calculated air massflow by calibrateable one	local	VALUE
Amc_uSensMinValid	READ-WRITE	Minimum threshold for plausible air massflow sensor voltage	local	VALUE
Amc_usensMaxValid	READ-WRITE	Maximum threshold for plausible air massflow sensor voltage	local	VALUE
Bvc_rVoltDivHigh	READ-WRITE	Exemplary description for Bvc_rVoltDivHigh	local	VALUE
Bvc_rVoltDivLow	READ-WRITE	Exemplary description for Bvc_rVoltDivLow	local	VALUE
Bvc_uBattAlt	READ-WRITE	Exemplary description for Bvc_uBattAlt	local	VALUE
Bvc_uBattMax	READ-WRITE	Fault threshold for maximum permitted system voltage	local	VALUE
Bvc_uBattMin	READ-WRITE	Fault threshold for minimum permitted system voltage	local	VALUE
Cpc_flgPChargeOverride	READ-WRITE	Switch to disable charge pressure sensor diagnostic function	local	VALUE
Cpc_uSensMinValid	READ-WRITE	Minimum threshold for plausible charge pressure sensor voltage	local	VALUE
Cpc_usensMaxValid	READ-WRITE	Maximum threshold for plausible charge pressure sensor voltage	local	VALUE
Ctc_rPullUp_C	READ-WRITE	Resistance of pull up resistor	local	VALUE
Ctc_uSensMaxValid	READ-WRITE	Fault threshold for maximum permitted ECT sensor voltage	local	VALUE
Ctc_uSensMinValid	READ-WRITE	Fault threshold for minimum permitted ECT sensor voltage	local	VALUE
Ctc_uSupply	READ-WRITE	ECT sensor supply voltage	local	VALUE
Egc_facEgasMan	READ-WRITE	Exemplary description for Egc_facEgasMan	local	VALUE
Egc_flgEgasOverride	READ-WRITE	Exemplary description for Egc_flgEgasOverride	local	VALUE

© ETAS GmbH reserves all rights even in the event of industrial property rights. We reserve all rights of disposal such as copying and passing on to third parties.

Name	Access	Long name	Mode	Type
Egc_stEgasFilt	READ-WRITE	Exemplary description for Egc_stEgasFilt	local	VALUE
Egc_tiTEgasFilt	READ-WRITE	Exemplary description for Egc_tiTEgasFilt	local	VALUE
Egc_uSens2facEgas1_CUR	READ-WRITE	Exemplary description for Egc_uSens2facEgas1_CUR	local	CUR
Egc_uSens2facEgas2_CUR	READ-WRITE	Exemplary description for Egc_uSens2facEgas2_CUR	local	CUR
Egc_uSensMaxValid	READ-WRITE	Exemplary description for Egc_uSensMaxValid	local	VALUE
Egc_uSensMinValid	READ-WRITE	Exemplary description for Egc_uSensMinValid	local	VALUE
Knk_Bsp	READ-WRITE	Exemplary description for Knk_Bsp	local	VALUE
Lmc_CJ125_DIAG_HEATER_C	READ-WRITE	Exemplary description for Lmc_CJ125_DIAG_HEATER_C	local	VALUE
Lmc_CJ125_DIAG_IAIP_C	READ-WRITE	Exemplary description for Lmc_CJ125_DIAG_IAIP_C	local	VALUE
Lmc_CJ125_DIAG_UN_C	READ-WRITE	Exemplary description for Lmc_CJ125_DIAG_UN_C	local	VALUE
Lmc_CJ125_DIAG_VM_C	READ-WRITE	Exemplary description for Lmc_CJ125_DIAG_VM_C	local	VALUE
Lmc_E85active	READ-WRITE	Exemplary description for Lmc_E85active	local	VALUE
Lmc_IP_Nominal	READ-WRITE	Exemplary description for Lmc_IP_Nominal	local	VALUE
Lmc_IP_PresComp_measured	READ-WRITE	Exemplary description for Lmc_IP_PresComp_measured	local	VALUE
Lmc_LSU0_C	READ-WRITE	Exemplary description for Lmc_LSU0_C	local	VALUE
Lmc_LSU1_C	READ-WRITE	Exemplary description for Lmc_LSU1_C	local	VALUE
Lmc_PumpCurrent_replacement	READ-WRITE	Exemplary description for Lmc_PumpCurrent_replacement	local	VALUE
Lmc_Temp_K	READ-WRITE	Exemplary description for Lmc_Temp_K	local	VALUE
Lmc_Temp_TN	READ-WRITE	Exemplary description for Lmc_Temp_TN	local	VALUE
Lmc_Temp_TV	READ-WRITE	Exemplary description for Lmc_Temp_TV	local	VALUE

© ETAS GmbH reserves all rights even in the event of industrial property rights. We reserve all rights of disposal such as copying and passing on to third parties.

Name	Access	Long name	Mode	Type
Lmc_Temp_soll	READ-WRITE	Exemplary description for Lmc_Temp_soll	local	VALUE
Lmc_noError	READ-WRITE	Exemplary description for Lmc_noError	local	VALUE
Lmc_period	READ-WRITE	Exemplary description for Lmc_period	local	VALUE
Lmc_uSensMaxValid	READ-WRITE	Exemplary description for Lmc_uSensMaxValid	local	VALUE
Lmc_uSensMinValid	READ-WRITE	Exemplary description for Lmc_uSensMinValid	local	VALUE
MaxDutyCycle	READ-WRITE	Exemplary description for MaxDutyCycle	local	VALUE
MinDutyCycle	READ-WRITE	Exemplary description for MinDutyCycle	local	VALUE
Mpc_uSensMaxValid	READ-WRITE	Manifold air pressure - fault threshold - maximum permitted voltage of sensor	local	VALUE
Mpc_uSensMinValid	READ-WRITE	Manifold air pressure - fault threshold - minimum permitted voltage of sensor	local	VALUE
Mtc_rPullUp_C	READ-WRITE	Manifold air temperature - pull up resistor value for calculation of sensor restistance	local	VALUE
Mtc_uSensMaxValid	READ-WRITE	Manifold air temperature - fault threshold - maximum permitted voltage of sensor	local	VALUE
Mtc_uSensMinValid	READ-WRITE	Manifold air temperature - fault threshold - minimum permitted voltage of sensor	local	VALUE
Mtc_uSupply	READ-WRITE	Manifold air temperature - sensor supply voltage for calculation of sensor resistance	local	VALUE
Opc_rpmEngMinOilPressure	READ-WRITE	Engine Oil Pressure - fault threshold - minimum permitted rpm without oil pressure signal	local	VALUE
SchalterDuty	READ-WRITE	Exemplary description for SchalterDuty	local	VALUE
abweichungsSchwelle	READ-WRITE	Exemplary description for abweichungsSchwelle	local	VALUE
dT_applizierbar	READ-WRITE	Exemplary description for dT_applizierbar	local	VALUE

© ETAS GmbH reserves all rights even in the event of industrial property rights. We reserve all rights of disposal such as copying and passing on to third parties.

Name	Access	Long name	Mode	Type
resetPID	READ-WRITE	Exemplary description for resetPID	local	VALUE

15.1.2 Variable

Name	Access	Long name	Mode	Type
Amc_AirMassFlow	READ-ONLY	Engine Air Massflow	export	VALUE
Amc_flgError	READ-ONLY	Error flag of engine air massflow sensor system	local	VALUE
Amc_stIOError	READ-ONLY	Error Flag	local	VALUE
Amc_uSens	READ-ONLY	Sensor Voltage	local	VALUE
Bvc_flgError	READ-ONLY	Error Flag of Battery Voltage	local	VALUE
Bvc_stIA	READ-ONLY	Status of rationality check of system voltage	local	VALUE
Bvc_uBatt	READ-ONLY	System voltage	export	VALUE
Bvc_uBattCalc	READ-ONLY	System voltage	local	VALUE
Bvc_uSens	READ-ONLY	System voltage sensor - raw value	local	VALUE
Cpc_flgError	READ-ONLY	Exemplary description for Cpc_flgError	local	VALUE
Cpc_nrValues	READ-ONLY	Charge pressure sensor - counter for calculation of filtered charge pressure	local	VALUE
Cpc_pMani	READ-ONLY	Exemplary description for Cpc_pMani	local	VALUE
Cpc_pchargeFilt	READ-ONLY	Exemplary description for Cpc_pchargeFilt	export	VALUE
Cpc_stIOError	READ-ONLY	Error status of charge pressure sensor system	local	VALUE
Cpc_uSens	READ-ONLY	Charge pressure - sensor voltage	local	VALUE
Ctc_atCool	READ-ONLY	Engine Coolant Temperature	export	VALUE
Ctc_flgError	READ-ONLY	Error Flag of Coolant Temperature System	local	VALUE
Ctc_rSens	READ-ONLY	Resistance of temperature sensor	local	VALUE
Ctc_stIA	READ-ONLY	Status of engine coolant temperature sensor	local	VALUE
Ctc_uSens	READ-ONLY	Engine coolant temperature sensor - raw value	local	VALUE
DutyCycle_out	READ-ONLY	Exemplary description for DutyCycle_out	local	VALUE
Egc_facEgas	READ-ONLY	Acc pedal position	export	VALUE

© ETAS GmbH reserves all rights even in the event of industrial property rights. We reserve all rights of disposal such as copying and passing on to third parties.

Name	Access	Long name	Mode	Type
Egc_facEgas1	READ-ONLY	Acc pedal position - sensor 1	local	VALUE
Egc_facEgas2	READ-ONLY	Acc pedal position - sensor 2	local	VALUE
Egc_facEgasCalc	READ-ONLY	Exemplary description for Egc_facEgasCalc	local	VALUE
Egc_facEgasFilt	READ-ONLY	Exemplary description for Egc_facEgasFilt	local	VALUE
Egc_flgError	READ-ONLY	Error Flag of Egas	local	VALUE
Egc_stIA1	READ-ONLY	Exemplary description for Egc_stIA1	local	VALUE
Egc_stIA2	READ-ONLY	Exemplary description for Egc_stIA2	local	VALUE
Egc_uSens1	READ-ONLY	Exemplary description for Egc_uSens1	local	VALUE
Egc_uSens2	READ-ONLY	Exemplary description for Egc_uSens2	local	VALUE
Eih_flgInputError	READ-ONLY	Exemplary description for Eih_flgInputError	export	VALUE
Epm_rpmEngSpd	READ-ONLY	Engine speed	import	VALUE
KI50_flgError	READ-ONLY	Exemplary description for KI50_flgError	local	VALUE
KI50_stIO	READ-ONLY	Exemplary description for KI50_stIO	local	VALUE
KI50_stKlemme50	READ-ONLY	Exemplary description for KI50_stKlemme50	export	VALUE
KnockSignal	READ-ONLY	Exemplary description for KnockSignal	local	VALUE
Lamsoni	READ-ONLY	Measured lambda	export	VALUE
Lmc_IPRoh	READ-ONLY	Exemplary description for Lmc_IPRoh	local	VALUE
Lmc_IP_PresComp	READ-ONLY	Exemplary description for Lmc_IP_PresComp	local	VALUE
Lmc_IP_adapted	READ-ONLY	Exemplary description for Lmc_IP_adapted	local	VALUE
Lmc_Lambda_E85	READ-ONLY	Exemplary description for Lmc_Lambda_E85	local	VALUE
Lmc_Lambda_gasoline	READ-ONLY	Exemplary description for Lmc_Lambda_gasoline	local	VALUE
Lmc_Pressure	READ-ONLY	Exemplary description for Lmc_Pressure	local	VALUE
Lmc_Ready	READ-ONLY	Exemplary description for Lmc_Ready	local	VALUE
Lmc_Temp_duty	READ-ONLY	Exemplary description for Lmc_Temp_duty	local	VALUE
Lmc_Temp_ist	READ-ONLY	Exemplary description for Lmc_Temp_ist	local	VALUE

© ETAS GmbH reserves all rights even in the event of industrial property rights. We reserve all rights of disposal such as copying and passing on to third parties.

Name	Access	Long name	Mode	Type
Lmc_error00	READ-ONLY	Exemplary description for Lmc_error00	local	VALUE
Lmc_error01	READ-ONLY	Exemplary description for Lmc_error01	local	VALUE
Lmc_error02	READ-ONLY	Exemplary description for Lmc_error02	local	VALUE
Lmc_error03	READ-ONLY	Exemplary description for Lmc_error03	local	VALUE
Lmc_error10	READ-ONLY	Exemplary description for Lmc_error10	local	VALUE
Lmc_error11	READ-ONLY	Exemplary description for Lmc_error11	local	VALUE
Lmc_error12	READ-ONLY	Exemplary description for Lmc_error12	local	VALUE
Lmc_error13	READ-ONLY	Exemplary description for Lmc_error13	local	VALUE
Lmc_facPresComp	READ-ONLY	Exemplary description for Lmc_facPresComp	local	VALUE
Lmc_facPresCompLean	READ-ONLY	Exemplary description for Lmc_facPresCompLean	local	VALUE
Lmc_facPresConpRich	READ-ONLY	Exemplary description for Lmc_facPresConpRich	local	VALUE
Lmc_faccomp_Ovr	READ-ONLY	Exemplary description for Lmc_faccomp_Ovr	local	VALUE
Lmc_flgError	READ-ONLY	Exemplary description for Lmc_flgError	local	VALUE
Lmc_pressure_st	READ-ONLY	Exemplary description for Lmc_pressure_st	local	VALUE
Lmc_pumpCurrent	READ-ONLY	Exemplary description for Lmc_pumpCurrent	local	VALUE
Lmc_uRaw	READ-ONLY	Exemplary description for Lmc_uRaw	local	VALUE
Mpc_flgError	READ-ONLY	Manifold air pressure - status flag - consolidated error	local	VALUE
Mpc_nrValues	READ-ONLY	Manifold air pressure - number of valid pressure samples for filter algorithm - denominator	local	VALUE
Mpc_pAccu	READ-ONLY	Manifold air pressure - accumulated pressure value for filter algorithm - nominator	local	VALUE
Mpc_pMani	READ-ONLY	Manifold air pressure - unfiltered - temperature compensated	local	VALUE

© ETAS GmbH reserves all rights even in the event of industrial property rights. We reserve all rights of disposal such as copying and passing on to third parties.

Name	Access	Long name	Mode	Type
Mpc_pManiFilt	READ-ONLY	Manifold air pressure - filtered - temperature compensated	export	VALUE
Mpc_stIOError	READ-ONLY	Manifold air pressure - status flag - input /output error	local	VALUE
Mpc_uSens	READ-ONLY	Manifold air pressure - pressure sensor voltage	local	VALUE
Mtc_atMani	READ-ONLY	Manifold air temperature	export	VALUE
Mtc_flgError	READ-ONLY	Manifold air temperature - status flag - consolidated error	local	VALUE
Mtc_rSens	READ-ONLY	Manifold air temperature - calculated sensor restistance	local	VALUE
Mtc_stIA	READ-ONLY	Manifold air temperature - error flag - sensor status	local	VALUE
Mtc_uSens	READ-ONLY	Manifold air temperature - sensor voltage - raw - for sensor monitoring	local	VALUE
Opc_flgError	READ-ONLY	Engine Oil Pressure - status flag - consolidated error	local	VALUE
Opc_stIA	READ-ONLY	Engine Oil Pressure - error flag - sensor status	local	VALUE
Opc_stOilPressure	READ-ONLY	Status of oil pressure monitoring switch - normal / low	local	VALUE
Opc_stSens	READ-ONLY	Status of oil pressure monitoring switch - normal / low	local	VALUE
cpc_pAccu	READ-ONLY	Summing unit for calculation of filtered charge pressure	local	VALUE

© ETAS GmbH reserves all rights even in the event of industrial property rights. We reserve all rights of disposal such as copying and passing on to third parties.

Stc - Starter Calculation

16.1 Systemconstant-Parameter-Variable-Classinstance-Structure

16.1.1 Parameter

Name	Access	Long name	Mode	Type
Stc_CatalyserHeatingDelay	READ-WRITE	Exemplary description for Stc_CatalyserHeatingDelay	local	VALUE
Stc_EngSpdSetCatalyserHeating	READ-WRITE	Exemplary description for Stc_EngSpdSetCatalyserHeating	local	VALUE
Stc_EngSpdStartOverdrive	READ-WRITE	Exemplary description for Stc_EngSpdStartOverdrive	local	VALUE
Stc_facFuelCorr_CUR	READ-WRITE	Exemplary description for Stc_facFuelCorr_CUR	local	CUR
Stc_facFuelCorr_MAP	READ-WRITE	Exemplary description for Stc_facFuelCorr_MAP	local	MAP
Stc_rpmEngSpedMax	READ-WRITE	Exemplary description for Stc_rpmEngSpedMax	local	VALUE

16.1.2 Variable

Name	Access	Long name	Mode	Type
Ctc_atCool	READ-ONLY	Engine Coolant Temperature	import	VALUE
Epm_rpmEngSpd	READ-ONLY	Engine speed	import	VALUE
Opm_idxMode	READ-ONLY	Engine status - off / normal / IOerror - protect the engine in case of serious faults	import	VALUE
Stc_CatalyserHeatingTime	READ-ONLY	Exemplary description for Stc_CatalyserHeatingTime	export	VALUE
Stc_Memory	READ-ONLY	Exemplary description for Stc_Memory	local	VALUE
Stc_StarterHold	READ-ONLY	Exemplary description for Stc_StarterHold	local	VALUE
Stc_facFuelCorr	READ-ONLY	Exemplary description for Stc_facFuelCorr	export	VALUE
Stc_flgCatalyserHeating	READ-ONLY	Exemplary description for Stc_flgCatalyserHeating	export	VALUE
Stc_flgFuelCorrActive	READ-ONLY	Exemplary description for Stc_flgFuelCorrActive	export	VALUE
Stc_flgStarterActive	READ-ONLY	Exemplary description for Stc_flgStarterActive	export	VALUE

© ETAS GmbH reserves all rights even in the event of industrial property rights. We reserve all rights of disposal such as copying and passing on to third parties.

Name	Access	Long name	Mode	Type
Stc_stStarter	READ-ONLY	Exemplary description for Stc_stStarter	export	VALUE
dummy_Starter	READ-ONLY	Exemplary description for dummy_Starter	import	VALUE

© ETAS GmbH reserves all rights even in the event of industrial property rights. We reserve all rights of disposal such as copying and passing on to third parties.

T2t - Torque to throttle calculation

17.1 Systemconstant-Parameter-Variable-Classinstance-Structure

17.1.1 Parameter

Name	Access	Long name	Mode	Type
T2t_CatHeatTime2pManiRes	READ-WRITE	Exemplary description for T2t_CatHeatTime2pManiRes	local	CUR
T2t_KWastegateReqCorr	READ-WRITE	Exemplary description for T2t_KWastegateReqCorr	local	VALUE
T2t_RpmEngSpd2pMaxWithoutWasteGate	READ-WRITE	Exemplary description for T2t_RpmEngSpd2pMaxWithoutWasteGate	local	CUR
T2t_ThrPosStart	READ-WRITE	Exemplary description for T2t_ThrPosStart	local	VALUE
T2t_ThrValve2WasteGateThreshold	READ-WRITE	Exemplary description for T2t_ThrValve2WasteGateThreshold	local	VALUE
T2t_ThrValveReqCorrMax	READ-WRITE	Exemplary description for T2t_ThrValveReqCorrMax	local	VALUE
T2t_ThrValveReqCorrMin	READ-WRITE	Exemplary description for T2t_ThrValveReqCorrMin	local	VALUE
T2t_degIgnAngleDiff2facSparkEff_CUR	READ-WRITE	Exemplary description for T2t_degIgnAngleDiff2facSparkEff_CUR	local	CUR
T2t_facKThrValveReqCorr	READ-WRITE	Exemplary description for T2t_facKThrValveReqCorr	local	VALUE
T2t_facLambaReq2facLambdaEff_CUR	READ-WRITE	Exemplary description for T2t_facLambaReq2facLambdaEff_CUR	local	CUR
T2t_facThrValveReqCorrEnable	READ-WRITE	Exemplary description for T2t_facThrValveReqCorrEnable	local	VALUE
T2t_facWastegateReqCorrEnable	READ-WRITE	Exemplary description for T2t_facWastegateReqCorrEnable	local	VALUE
T2t_pManiReqMan	READ-WRITE	Exemplary description for T2t_pManiReqMan	local	VALUE
T2t_pManiReqMin	READ-WRITE	Exemplary description for T2t_pManiReqMin	local	VALUE
T2t_pManiReqOverride	READ-WRITE	Exemplary description for T2t_pManiReqOverride	local	VALUE
T2t_pManiRes	READ-WRITE	Exemplary description for T2t_pManiRes	local	VALUE
T2t_rpmEngSpdFilt	READ-WRITE	Exemplary description for T2t_rpmEngSpdFilt	local	VALUE

© ETAS GmbH reserves all rights even in the event of industrial property rights. We reserve all rights of disposal such as copying and passing on to third parties.

Name	Access	Long name	Mode	Type
T2t_rpmEngSpdpManiReq2facThrValveReqBase_MAP	READ-WRITE	Exemplary description for T2t_rpmEngSpdpManiReq2facThrValveReqBase_MAP	local	MAP
T2t_rpmEngSpdpManiReq2facWastegateReqBase_MAP	READ-WRITE	Exemplary description for T2t_rpmEngSpdpManiReq2facWastegateReqBase_MAP	local	MAP
T2t_rpmEngSpdtqReq2pManiReqBase_MAP	READ-WRITE	Exemplary description for T2t_rpmEngSpdtqReq2pManiReqBase_MAP	local	MAP
T2t_tiTnThrValveReqCorr	READ-WRITE	Exemplary description for T2t_tiTnThrValveReqCorr	local	VALUE
T2t_tiTnWastegateReqCorr	READ-WRITE	Exemplary description for T2t_tiTnWastegateReqCorr	local	VALUE
T2t_tiTvThrValveReqCorr	READ-WRITE	Exemplary description for T2t_tiTvThrValveReqCorr	local	VALUE
T2t_tiTvWastegateReqCorr	READ-WRITE	Exemplary description for T2t_tiTvWastegateReqCorr	local	VALUE

17.1.2 Variable

Name	Access	Long name	Mode	Type
Afr_facLambdaReq	READ-ONLY	Dump Storage - Lambda Correction Factor of Fuel Injection Quantity	import	VALUE
Epm_rpmEngSpd	READ-ONLY	Engine speed	import	VALUE
Iac_degIgn	READ-ONLY	Exemplary description for Iac_degIgn	import	VALUE
Iac_degMinAdvBestTq	READ-ONLY	Exemplary description for Iac_degMinAdvBestTq	import	VALUE
Isc_IdleSpdCtrlIPart	READ-ONLY	Exemplary description for Isc_IdleSpdCtrlIPart	import	VALUE
Isc_flgIdleSpdCtrlActive	READ-ONLY	Exemplary description for Isc_flgIdleSpdCtrlActive	import	VALUE
Mpc_pManiFilt	READ-ONLY	Manifold air pressure - filtered - temperature compensated	import	VALUE
Stc_CatalyserHeatingTime	READ-ONLY	Exemplary description for Stc_CatalyserHeatingTime	import	VALUE
Stc_flgCatalyserHeating	READ-ONLY	Exemplary description for Stc_flgCatalyserHeating	import	VALUE

© ETAS GmbH reserves all rights even in the event of industrial property rights. We reserve all rights of disposal such as copying and passing on to third parties.

Name	Access	Long name	Mode	Type
Stc_flgStarterActive	READ-ONLY	Exemplary description for Stc_flgStarterActive	import	VALUE
T2t_facLambdaEff	READ-ONLY	Exemplary description for T2t_facLambdaEff	local	VALUE
T2t_facSparkEff	READ-ONLY	Exemplary description for T2t_facSparkEff	local	VALUE
T2t_facThrValveReq	READ-ONLY	Exemplary description for T2t_facThrValveReq	export	VALUE
T2t_facThrValveReqBase	READ-ONLY	Exemplary description for T2t_facThrValveReqBase	local	VALUE
T2t_facThrValveReqCorr	READ-ONLY	Exemplary description for T2t_facThrValveReqCorr	local	VALUE
T2t_facWasteGateRate	READ-ONLY	Exemplary description for T2t_facWasteGateRate	export	VALUE
T2t_facWastegateReqBase	READ-ONLY	Exemplary description for T2t_facWastegateReqBase	local	VALUE
T2t_facWastegateReqCorr	READ-ONLY	Exemplary description for T2t_facWastegateReqCorr	local	VALUE
T2t_flgWasteGateControllerTrue	READ-ONLY	Exemplary description for T2t_flgWasteGateControllerTrue	local	VALUE
T2t_pManiReq	READ-ONLY	Exemplary description for T2t_pManiReq	local	VALUE
T2t_pManiReqCalc	READ-ONLY	Exemplary description for T2t_pManiReqCalc	local	VALUE
T2t_pManiReqFast	READ-ONLY	Exemplary description for T2t_pManiReqFast	export	VALUE
T2t_pManiReqSlow	READ-ONLY	Exemplary description for T2t_pManiReqSlow	local	VALUE
T2t_tiTaWastegateReqCorr	READ-ONLY	Exemplary description for T2t_tiTaWastegateReqCorr	local	VALUE
Tqs_tqReq	READ-ONLY	Exemplary description for Tqs_tqReq	import	VALUE

© ETAS GmbH reserves all rights even in the event of industrial property rights. We reserve all rights of disposal such as copying and passing on to third parties.

Tqs - Torque Structure

18.1 Systemconstant-Parameter-Variable-Classinstance-Structure

18.1.1 Parameter

Name	Access	Long name	Mode	Type
Tqs_atCool2tqDrag_CUR	READ-WRITE	Exemplary description for Tqs_atCool2tqDrag_CUR	local	CUR
Tqs_facKIdleSpdCtrl	READ-WRITE	Exemplary description for Tqs_facKIdleSpdCtrl	local	VALUE
Tqs_flgIdleSpdCtrlEnable	READ-WRITE	Exemplary description for Tqs_flgIdleSpdCtrlEnable	local	VALUE
Tqs_flgTorqueReqOverride	READ-WRITE	Exemplary description for Tqs_flgTorqueReqOverride	local	VALUE
Tqs_rpmEngSpd2tqMax_CUR	READ-WRITE	Exemplary description for Tqs_rpmEngSpd2tqMax_CUR	local	CUR
Tqs_rpmEngSpdIdle	READ-WRITE	Exemplary description for Tqs_rpmEngSpdIdle	local	VALUE
Tqs_rpmEngSpdfacEgas2facEgasFilt_MAP	READ-WRITE	Exemplary description for Tqs_rpmEngSpdfacEgas2facEgasFilt_MAP	local	MAP
Tqs_rpmEngSpdfacRelAir2tqDrag_MAP	READ-WRITE	Exemplary description for Tqs_rpmEngSpdfacRelAir2tqDrag_MAP	local	MAP
Tqs_tiTnIdleSpdCtrl	READ-WRITE	Exemplary description for Tqs_tiTnIdleSpdCtrl	local	VALUE
Tqs_tiTvIdleSpdCtrl	READ-WRITE	Exemplary description for Tqs_tiTvIdleSpdCtrl	local	VALUE
Tqs_tqIdleSpdCtrlMax	READ-WRITE	Exemplary description for Tqs_tqIdleSpdCtrlMax	local	VALUE
Tqs_tqIdleSpdCtrlMin	READ-WRITE	Exemplary description for Tqs_tqIdleSpdCtrlMin	local	VALUE
Tqs_tqReqMan	READ-WRITE	Exemplary description for Tqs_tqReqMan	local	VALUE

18.1.2 Variable

Name	Access	Long name	Mode	Type
Amf_facRelAir	READ-ONLY	Relative air charge	import	VALUE
Ctc_atCool	READ-ONLY	Engine Coolant Temperature	import	VALUE
Egc_facEgas	READ-ONLY	Acc pedal position	import	VALUE
Epm_rpmEngSpd	READ-ONLY	Engine speed	import	VALUE

© ETAS GmbH reserves all rights even in the event of industrial property rights. We reserve all rights of disposal such as copying and passing on to third parties.

Name	Access	Long name	Mode	Type
Isc_facIdleSpdStab	READ-ONLY	Exemplary description for Isc_facIdleSpdStab	import	VALUE
Tqs_facEgasFilt	READ-ONLY	Exemplary description for Tqs_facEgasFilt	local	VALUE
Tqs_tqDrag	READ-ONLY	Exemplary description for Tqs_tqDrag	local	VALUE
Tqs_tqIdleSpdCtrlCorr	READ-ONLY	Exemplary description for Tqs_tqIdleSpdCtrl Corr	local	VALUE
Tqs_tqMax	READ-ONLY	Exemplary description for Tqs_tqMax	local	VALUE
Tqs_tqMin	READ-ONLY	Exemplary description for Tqs_tqMin	local	VALUE
Tqs_tqReq	READ-ONLY	Exemplary description for Tqs_tqReq	export	VALUE
Tqs_tqReqCalc	READ-ONLY	Exemplary description for Tqs_tqReqCalc	local	VALUE

© ETAS GmbH reserves all rights even in the event of industrial property rights. We reserve all rights of disposal such as copying and passing on to third parties.